



# **Xgig Jammer and Delay Emulator**

Version 8.1

User's Guide





# Xgig Jammer and Delay Emulator

User's Guide



Viavi Solutions  
1-844-GO-VIAVI  
[www.viavisolutions.com](http://www.viavisolutions.com)

---

## **Notice**

Every effort was made to ensure that the information in this manual was accurate at the time of printing. However, information is subject to change without notice, and Viavi reserves the right to provide an addendum to this manual with information not available at the time that this manual was created.

## **Copyright/Trademarks**

© Copyright 2015 Viavi Solutions Inc. All rights reserved. No part of this guide may be reproduced or transmitted, electronically or otherwise, without written permission of the publisher. Viavi Solutions and the Viavi logo are trademarks of Viavi Solutions Inc. (“Viavi”). All other trademarks and registered trademarks are the property of their respective owners.

## **Copyright release**

Reproduction and distribution of this guide is authorized for US Government purposes only.

## **Terms and conditions**

Specifications, terms, and conditions are subject to change without notice. The provision of hardware, services, and/or software are subject to Viavi’s standard terms and conditions, available at [www.viavisolutions.com/en/terms-and-conditions](http://www.viavisolutions.com/en/terms-and-conditions).

## **Federal Communications Commission (FCC) Notice**

This product was tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this product in a residential area is likely to cause harmful interference, in which case you will be required to correct the interference at your own expense.

The authority to operate this product is conditioned by the requirements that no modifications be made to the equipment unless the changes or modifications are expressly approved by Viavi.

# ***Contents***

<b>About this Guide</b> .....	<b>1</b>
Who Should Read this Guide .....	2
What this Guide Contains .....	2
Conventions .....	4
Message Formats .....	4
Typographical Conventions .....	4
Technical Assistance .....	4
<b>PART ONE: Using Xgig Jammer</b> .....	<b>5</b>
<b>Chapter 1</b>	
<b>Introducing Xgig Jammer</b> .....	<b>7</b>
Xgig Jammer Overview .....	8
Features .....	10
Operation .....	10
Capabilities .....	10
New Features .....	12
<b>Chapter 2</b>	
<b>Using the Jammer Tab</b> .....	<b>13</b>
Using the Configuration Manager in Jammer .....	15
Configuration Manager Tool Bar in Jammer .....	17
Configuration Manager Context Menu in Jammer .....	18
Using the Parameters Status Table in Jammer .....	21
Parameters Category Descriptions .....	23
Using the Parameters Status Context Menu in Jammer .....	27
Changing the SAS/SATA Protocol Setting of a Jammer .....	29
Changing the Clock Rate of a Jammer .....	31
16G FC FEC .....	37
Scrambling .....	37
Changing the GigE Jumbo Frames Setting .....	37
Replace Received Invalid Data with Idles .....	38
Tuning and Equalization .....	39
Tuning for 12G SAS .....	39
Using the Ports Manager in Jammer .....	45
Actions Button .....	46
Ports Manager Columns .....	47
Using the Ports Manager Context Menu .....	49
Using the Log Manager in Jammer .....	50
Setting Log Options .....	51
Viewing a Log .....	52
Saving a Log .....	54
Customizing the Appearance of the Maestro/Jammer Main Window .....	55
Using the Window Menu .....	55

---

Customizing the Parameters Status table in Jammer .....	57
Performing Configuration Tasks in Jammer .....	60
Loading Jammer Configuration Files .....	60
Saving a Jammer Configuration File .....	60
Resetting a Jammer Configuration .....	60
Editing a Jammer Configuration .....	61
Running the Test Suite on a Jammer Device .....	62
Instant FEC Jam for 16G FC .....	64
<b>Chapter 3</b>	
<b>Creating Jammer Test Configurations for Fibre Channel .....</b>	<b>65</b>
Defining Your Own Test Configurations .....	66
Using the Jammer Configuration Window .....	68
Using the Jammer Test Suite Tools .....	68
Using the Current Jammer Test Window .....	70
Configuring Arm and Trigger Conditions .....	73
Setting Frame Conditions .....	74
Setting Ordered Set Conditions .....	75
Configuring the Jam Definition .....	77
Jamming an Ordered Set .....	77
Jamming a Frame .....	78
<b>Chapter 4</b>	
<b>Creating Jammer Test Configurations for Gigabit Ethernet .....</b>	<b>87</b>
Defining Your Own Test Configurations .....	88
Using the Jammer Configuration Window .....	91
Using the Jammer Test Suite Tools .....	91
The recently used Gigabit Ethernet Jammer configuration files appear in the file menu and are loaded when selected. ....	93
Using the Current Jammer Test Window .....	93
Configuring Arm and Trigger Conditions for Gigabit Ethernet .....	99
Setting Frame Conditions .....	100
Setting Ordered Set Conditions .....	102
Configuring the Jam Definition for Gigabit Ethernet .....	103
Jamming an Ordered Set .....	103
Jamming a Frame .....	104
<b>Chapter 5</b>	
<b>Creating Jammer Test Configurations for SAS and SATA/STP .....</b>	<b>113</b>
Defining Your Own SAS and SATA/STP Test Configurations .....	114
Using the Jammer Configuration Window .....	116
Using the Jammer Test Suite Tools .....	116
Using the Current Jammer Test Window .....	119
Configuring SAS Arm and Trigger Conditions .....	125
Setting Frame Conditions .....	128
Setting Primitive Sequence Conditions .....	129

---

Configuring the SAS Jam Definition .....	130
Jamming a Frame .....	131
Jamming a Primitive Sequence .....	140
Configuring SATA/STP Arm and Trigger Conditions .....	143
Setting Frame Conditions .....	146
Setting Primitive Sequence Conditions .....	148
Configuring the SATA/STP Jam Definition .....	148
Jamming a Frame .....	149
Jamming a Primitive Sequence .....	158
<b>Chapter 6</b>	
<b>Creating Jammer Test Configurations for 10GigE.....</b>	<b>161</b>
Defining Your Own Test Configurations for 10GigE .....	162
Using the Jammer Configuration Window for 10GigE .....	164
Using the Jammer Test Suite Tools for 10GigE .....	164
Using the Current Jammer Test Window for 10GigE .....	167
Configuring the Arm Condition for 10GigE .....	173
Setting Frame Conditions for 10GigE Arm .....	173
Setting Ordered Set Conditions for 10GigE Arm .....	175
Setting Control Character Conditions for 10GigE Arm .....	176
Configuring the Trigger Condition for 10GigE .....	177
Setting Frame Conditions for a 10GigE Trigger .....	179
Setting Ordered Set Conditions for a 10GigE Trigger .....	182
Setting Control Character Conditions for a 10GigE Trigger .....	182
Setting SOP Trigger for 10GigE .....	183
Setting EOP Trigger for 10GigE .....	183
Configuring the Jam Definition for 10GigE .....	184
Jamming an Ordered Set for 10GigE .....	184
Jamming a Control Character for 10GigE .....	185
Jamming a Frame for 10GigE .....	186
<b>Chapter 7</b>	
<b>Creating Jammer Test Configurations for 16G FC .....</b>	<b>201</b>
Defining Your Own Test Configurations for 16G FC .....	202
Using the Jammer Configuration Window for 16G FC .....	204
Using the Jammer Test Suite Tools for 16G FC .....	204
Using the Current Jammer Test Window for 16G FC .....	207
Configuring the Arm Condition for 16G FC .....	213
Setting Frame Conditions for 16G FC Arm .....	213
Setting Ordered Set Conditions for 16G FC Arm .....	215
Setting Control Character Conditions for 16G FC Arm .....	216
Setting SOF Conditions for 16G FC Arm .....	216
Setting EOF Conditions for 16G FC Arm .....	217
Configuring the Trigger Condition for 16G FC .....	218
Setting Frame Conditions for a 16G FC Trigger .....	220

---

Setting Ordered Set Conditions for a 16G FC Trigger .....	222
Setting Control Character Conditions for a 16G FC Trigger .....	222
Setting SOF Conditions for 16G FC Trigger .....	222
Setting EOF Conditions for 16G FC Trigger .....	223
Setting 66-bit Block Payload for Ordered Set Conditions for 16G FC Trigger .....	224
Configuring the Jam Definition for 16G FC .....	227
Jamming an Ordered Set for 16G FC .....	227
Jamming a Control Character for 16G FC .....	228
Jamming the SOF for 16G FC .....	228
Jamming the EOF for 16G FC .....	229
Jamming the Periodic FEC for 16G FC .....	229
Jamming a Frame for 16G FC .....	231
Jamming a 66-bit Block Payload for 16G FC .....	243
<b>Chapter 8</b>	
<b>Creating Jammer Test Configurations for PCIe .....</b>	<b>249</b>
Defining Your Own Test Configurations for PCIe .....	250
Using the Jammer Configuration Window for PCIe .....	252
Using the Jammer Test Suite Tools for PCIe .....	253
Using the Current Jammer Test Window for PCIe .....	255
Configuring the Arm Condition for PCIe .....	260
Setting TLP Conditions for PCIe Arm .....	261
Setting DLLP Conditions for PCIe Arm .....	263
Setting Ordered Set Conditions for PCIe Arm .....	265
Configuring the Trigger Condition for PCIe .....	266
Setting TLP Conditions for a PCIe Trigger .....	267
Setting DLLP Conditions for a PCIe Trigger .....	269
Setting Ordered Set Conditions for a PCIe Trigger .....	271
Configuring the Jam Definition for PCIe .....	272
Jamming a TLP for PCIe .....	272
Jamming a DLLP for PCIe .....	278
Jamming an Ordered Set for PCIe .....	283
<b>Chapter 9</b>	
<b>Xgig Jammer Application Notes .....</b>	<b>285</b>
Setting Up the Xgig Jammer and Xgig Analyzer to Capture a Jam .....	286
Testing Strategies for the Xgig Jammer .....	288
Replace Frame with Modified Traffic - Fibre Channel .....	289
Simple Frame Modification .....	289
Frame Truncation and/or Modification .....	289
Replacement of Frame with Multiple Frames .....	290
Replacement of Frame with Ordered Sets .....	290
Using Domains and External Triggering .....	291
How to Setup a Single Port Xgig Jammer .....	292

<b>PART TWO: Using Xgig Delay Emulator .....</b>	<b>293</b>
<b>Chapter 10</b>	
<b>Introducing Xgig Delay Emulator .....</b>	<b>295</b>
Xgig Delay Emulator Overview .....	296
Features .....	296
Operation .....	296
Capabilities .....	296
New Features for Xgig Delay Emulator .....	297
Cabling .....	298
<b>Chapter 11</b>	
<b>Using the Delay Emulator Tab .....</b>	<b>299</b>
Using the Configuration Manager in Delay Emulator .....	301
Configuration Manager Tool Bar in Delay Emulator .....	303
Configuration Manager Context Menu in Delay Emulator .....	304
Using the Parameters Status Table in Delay Emulator .....	307
Parameters Category Descriptions .....	309
Using the Parameters Status Context Menu in Delay Emulator .....	311
Log .....	312
Change Port to Delay/Reorder Mode .....	312
Using the Ports Manager in Delay Emulator .....	313
Actions Button .....	314
Ports Manager Columns .....	314
Using the Ports Manager Context Menu .....	315
Using the Real Time Tab .....	317
Delay-Mode .....	317
Reorder-Mode .....	319
Using the Log Manager in Delay Emulator .....	320
Setting Log Options .....	321
Viewing a Log .....	322
Saving a Log .....	323
Customizing the Appearance of the Maestro/Delay Emulator Main Window .....	324
Using the Window Menu .....	324
Customizing the Parameters Status table in Delay Emulator .....	326
Performing Configuration Tasks in Delay Emulator .....	329
Loading Delay Emulator Configuration Files .....	329
Saving a Delay Emulator Configuration File .....	329
Resetting a Delay Emulator Configuration .....	330
Editing a Delay Emulator Configuration .....	330
Running the Test Suite on a Delay Emulator Device .....	331
<b>Chapter 12</b>	
<b>Creating Delay Emulator Test Configurations for Delay Mode.....</b>	<b>333</b>
Defining Your Own Test Configurations for Delay Mode .....	334

Using the Delay-Mode Configuration Window .....	336
Using the Delay Emulator Test Suite Tools .....	336
Using the Current Delay Emulator Test Window: Delay-Mode .....	338
Configuring the Classify Condition in Delay-Mode .....	342
Setting Frame Conditions for Classify in Delay-Mode .....	344
Configuring the Arm Condition in Delay-Mode .....	347
Setting Frame Conditions for Arm in Delay-Mode .....	347
Configuring the Trigger Condition in Delay-Mode .....	350
Setting Frame Conditions for a Trigger in Delay-Mode .....	352
<b>Chapter 13</b>	
<b>Creating Delay Emulator Test Configurations for Reorder Mode .....</b>	<b>355</b>
Defining Your Own Test Configurations for Reorder Mode .....	356
Using the Reorder-Mode Configuration Window .....	359
Using the Delay Emulator Test Suite Tools in Reorder-Mode .....	359
Using the Current Delay Emulator Test Window: Reorder-Mode .....	361
Configuring the Arm Condition in Reorder-Mode .....	363
Setting Frame Conditions for Arm for Reorder .....	364
Configuring the Trigger Condition in Reorder-Mode .....	366
Setting Frame Conditions for a Trigger in Reorder-Mode .....	367
Configuring the Reorder Condition .....	370
<b>PART THREE: Appendices .....</b>	<b>371</b>
<b>Appendix A</b>	
<b>Fibre Channel Ordered Sets - Partial List.....</b>	<b>373</b>
<b>Appendix B</b>	
<b>8-Bit/10-Bit Mapping .....</b>	<b>375</b>
Legal 8-Bit/10-Bit Characters Sorted by 10-Bit Value .....	376
10-Bit Values with No 8-bit Mapping Sorted by 10-Bit Value .....	380
Legal 10-Bit Values Sorted by 8-Bit Hex Code .....	385
Legal 10-bit Values Sorted by K/D Code .....	389
<b>Appendix C</b>	
<b>Fibre Channel Legal Arbitrated Loop Physical Addresses .....</b>	<b>393</b>
<b>Appendix D</b>	
<b>Gigabit Ethernet Ordered Sets - Partial List.....</b>	<b>395</b>
<b>Appendix E</b>	
<b>Primitive Encoding .....</b>	<b>397</b>
<b>Index .....</b>	<b>401</b>



# ***About this Guide***

This guide discusses the following Xgig Maestro products:

- Xgig Jammer
- Xgig Delay Emulator

## Who Should Read this Guide

This guide is intended for networking professionals in research and development who need to monitor and test network performance. It is assumed that users of this guide have an engineering background.

## What this Guide Contains

This guide is organized into three parts:

- PART ONE: Using Xgig Jammer which includes chapters 1 through 9.
- PART TWO: Using Delay Emulator which includes chapters 10 through 13.
- PART THREE: Appendices which includes appendices A through E.

The chapters contain the following information:

Chapter 1, “Introducing Xgig Jammer” describes the Jammer features and capabilities.

Chapter 2, “Using the Jammer Tab” describes the Jammer tab interface and provides procedures to use it.

Chapter 3, “Creating Jammer Test Configurations for Fibre Channel” describes the elements on the Xgig Jammer Configuration FC window and how to use them.

Chapter 4, “Creating Jammer Test Configurations for Gigabit Ethernet” describes the elements on the Xgig Jammer Configuration GE window and how to use them.

Chapter 5, “Creating Jammer Test Configurations for SAS and SATA/STP” describes the elements on the Xgig Jammer SAS/SATA/STP Configuration window and how to use them.

Chapter 6, “Creating Jammer Test Configurations for 10GigE” describes the elements in the Xgig Jammer Configuration 10GigE window and how to use them.

Chapter 7, “Creating Jammer Test Configurations for 16G FC” describes the elements in the Xgig Jammer Configuration 16G Fibre Channel window and how to use them.

Chapter 8, “Creating Jammer Test Configurations for PCIe” describes the elements in the Xgig Jammer Configuration PCIe window and how to use them.

Chapter 9, “Xgig Jammer Application Notes” provides examples of how to use the Jammer in practical situations.

Chapter 10, “Introducing Xgig Delay Emulator” describes the Jammer features and capabilities.

Chapter 11, “Using the Delay Emulator Tab” describes the Jammer tab interface and provides procedures to use it.

Chapter 12, “Creating Delay Emulator Test Configurations for Delay Mode” describes the elements on the Xgig Delay Emulator Configuration Delay window and how to use them.

Chapter 13, “Creating Delay Emulator Test Configurations for Reorder Mode” describes the elements on the Xgig Delay Emulator Configuration Reorder window and how to use them.

Appendix A, “Fibre Channel Ordered Sets - Partial List” contains some of the Ordered Set values that are used in this application.

Appendix B, “8-Bit/10-Bit Mapping” contains three tables: one is legal 8-bit/10-bit characters sorted by 10-bit value; the second is 10-bit values with no 8-bit mapping sorted by 10-bit value; the third is legal 10-bit values sorted by K/D code.

Appendix C, “Fibre Channel Legal Arbitrated Loop Physical Addresses” contains translation tables.

Appendix D, “Gigabit Ethernet Ordered Sets - Partial List” contains a table of these values.

Appendix E, “Primitive Encoding” contains a table of K28.5-based Primitive encoding whose 40-bit values have a Hamming distance of at least 8.

---

## Conventions

The following conventions are used in this guide.

### Message Formats

This guide uses the following format to highlight special messages:



**Note:** This format is used to highlight information of importance or special interest.

---



**Caution:** This format is used to highlight information that will help you prevent equipment failure or loss of data.

---

### Typographical Conventions

This guide uses the following typographical conventions:

<b>bold sans serif</b>	Commands
<i>italics</i>	Directory names, book titles, named key, for example the <i>Enter</i> key
courier font	Screen text, user-typed command-line entries

### Technical Assistance

If you require technical assistance, call 1-844-GO-VIAVI (1-844-468-4284) or e-mail [Techsupport-snt@viavisolutions.com](mailto:Techsupport-snt@viavisolutions.com).

For the latest TAC information, go to <http://www.viavisolutions.com/en/services-and-support/support/technical-assistance>.

## ***PART ONE:*** Using Xgig Jammer



# ***Chapter 1***

## Introducing Xgig Jammer

### **In this chapter:**

- Xgig Jammer Overview
- Features
- New Features

---

## Xgig Jammer Overview

The Xgig Jammer includes hardware (Xgig Multi-function Blade) and software that performs real-time data modification for PCIe, Fibre Channel, Gigabit Ethernet, 10GigE, Serial Attached SCSI (SAS), and Serial ATA (SATA) protocols. You can use the Jammer with Xgig Analyzers or Bus Doctor to capture and display the network traffic associated with the data modification.

The Xgig Jammer should be used as a digital retiming device. The Xgig Jammer blade re-times the data and re-transmits it with a new clock transparent to the data link (it passes every bit of data.) The Xgig Jammer blade functions in any PCIe, Fibre Channel, Gigabit Ethernet, 10GigE, SAS, or SATA architecture. It does not log onto a loop, switch, or fabric; it only passes data between two devices. The Xgig Jammer blade can pass PCIe, Fibre Channel, Gigabit Ethernet, 10GigE, SAS, or SATA traffic, or it can recognize an event or event sequence and modify the traffic. The events can be Ordered Sets, frames, Primitives, Control Characters, SOF, or EOF depending on the selected protocol. A specific Ordered Set, series of Ordered Sets, Primitive Sequence, or Control Character can be modified or replaced. A specific frame or series of frames can be modified in many ways: replacing a frame with idles, truncating a frame, inserting a frame, or changing any bits within a frame.



**Note:** The events and traffic modification options vary with each protocol.


---

The data modifications are performed on the 8-bit representations of the Ordered Sets, frames, Primitives, Control Characters SOF, and EOF. This ensures that the Xgig Jammer module always produces consistent PCIe, Fibre Channel, Gigabit Ethernet, 10GigE, SAS, and SATA traffic without disparity errors or clock discontinuities. The exception to this is when the Xgig Jammer is used to insert disparity errors or code violations into a frame, Ordered Set, or Primitive.

Figure 1 shows an example of a configuration where the Xgig Jammer and Xgig Analyzer are inserted into a network with two data paths, designated A and B.

The Xgig Jammer module can detect a Trigger Event and modify data in Path A. The response from Device 2 is detected on Path B.

**Figure 1: Duplex Xgig Jammer in Crossover Configuration with Xgig Analyzers**



**Note:** When the Jammer is used in a SATA (or Serial ATA Tunneling Protocol—STP) environment, the Jammer is required to modify the traffic automatically in order to support the flow control mechanism. This happens even if the Jammer is not started, and is only passing through traffic. Therefore, SATA\_HOLD and SATA\_HOLD A Primitive Sequences are usually not passed through the Jammer, but instead, the Jammer generates its own SATA\_HOLD and SATA\_HOLD A Primitive Sequences on the fly to maintain flow control with Device 1 and Device 2. Consequently, the Jammer does not allow Jamming of SATA\_HOLD or SATA\_HOLD A Primitive Sequences because it would not be Jamming actual received traffic.

## Features

Xgig Jammer has the following features:

### Operation

The Xgig Jammer system (hardware and software), allows you to perform the following operations:

- Change predefined network serial traffic patterns to new patterns.

The Xgig Jammer modifies Trigger Events in the manner you specify. It does not insert or remove network traffic, except for the re-timing circuit that adds or drops appropriate Ordered Sets or Primitives. An exception is in the SAS protocol, where the Jammer might need to rearrange the ordering of Primitives inside a frame so that the first thirty-two, 32-bit words of a frame are not too spread apart for accurate triggering. Another exception is the automatic SATA flow control that is performed.

- Pass traffic, unchanged, that does not match the Trigger Condition pattern.
- Reproduce a pattern change at will.

You can define multiple, sequential, arbitrary Jam cases by entering each of them into a test suite list. Each case can be unique or you can repeat a case within the suite.

### Capabilities

The Xgig Jammer has the following capabilities:

- Operates with Fibre Channel, Gigabit Ethernet, 10GigE, SAS, and SATA protocols

Depending on the license you purchase, you can select the protocol that your network uses and display the graphical user interface for that protocol.

- Supports the following line rates:

— Fibre Channel:

- 1.0625 Gbps
- 2.1250 Gbps
- 4.2500 Gbps
- 8.5000 Gbps
- 14.0250 Gbps

— Gigabit Ethernet:

- 1.2500 Gbps (GigE blades run only at this rate.)
- 10.3125 Gbps (10GigE blades run only at this rate.)

— SAS/SATA:

- 1.5 Gbps
- 3.0 Gbps
- 6.0 Gbps
- 12.0 Gbps (SAS only)

- Operates in digital re-timing mode at all times.
- In SAS and SATA, the Jammer auto negotiates out of band (OOB) with other hardware on your network.  
You can also force the link to perform OOB at any time. You can force the Jammer to speed-negotiate to a particular speed.
- Allows you to generate a test suite with up to 1024 separate Test Cases per run.  
Contains standard editing features such as copy, cut, paste, add, insert, and delete to edit the test suite. An option lets you run the test suite forever in a repeating loop.
- Provides the appropriate MAC (media access control) layer for Fibre Channel, Gigabit Ethernet, 10GigE, or SAS/SATA when you load the application.

### Triggering Capabilities

The Xgig Jammer module provides the following Triggering capabilities:

- You have two levels of triggering:
  - Arm (first level)
  - Trigger (second level)
- You can set an Arm condition as a specific Ordered Set, frame, or Primitive Sequence, or as an external Trigger Condition. An external Trigger Condition comes from outside the port (from another port in the same domain or from a TTL-in connector in the same domain).
- You can set the Jammer to repeatedly Arm and/or Trigger on an Ordered Set, frame, Primitive Sequence, Control Character, SOF, or EOF.
- You can set the Jammer to create an external trigger output when the Trigger condition is met. This triggers everything in the same domain as the Jammer port.

### Jamming Capabilities

The Xgig Jammer can perform the following types of Jams on the contents of frames:

- Pass a 32-bit word unchanged
- Replace a 32-bit word with a new value, masked nibble by nibble
- Corrupt a 32-bit word with a code violation (Fibre Channel, Gigabit Ethernet, and 10GigE)
- Corrupt a byte with a disparity error or code violation (SAS and SATA only)
- Invert a 32-bit word's specified bit(s)
- Replace a 32-bit word with a new value, masked bit by bit, according to a preset global definition
- Invert a 32-bit word's specified bit(s) according to a preset global definition.
- Replace a 32-bit word with a calculated CRC value (Fibre Channel, SAS and SATA only)
- Set a 32-bit word's specified bit(s) to 1
- Set a 32-bit word's specified bit(s) to 0
- Replace triggered frame with a 10 bit frame (SAS/SATA only)

- Insert a frame after the triggered frame (10GigE and 16G FC only)
- Insert D.C. Idle into a frame (SAS/SATA only)
- Truncate the target frame to a shorter length
- Duplicate a frame (10GigE and 16G FC only)
- 66-bit Block Jam (16G FC only)
- Insert Dword within frame (10GigE and 16G FC only)

The Xgig Jammer can perform the following types of Jams on Ordered Sets Primitive Sequences, Control Characters, EOF and SOF:

- Pass the Ordered Set or Primitive Sequence unchanged
- Replace the Ordered Set or Primitive Sequence with another standard or user-defined Ordered Set or Primitive Sequence
- Corrupt the Ordered Set with a code violation (Fibre Channel and Gigabit Ethernet)
- Corrupt any byte(s) in the Primitive Sequence with a disparity error or code violation (SAS and SATA only)
- Replace the 32-bit word containing an /S/ character with idles [I] (10GigE and 16G FC only).
- Replace the 32-bit word containing an /S/ character with idles [I] (10GigE and 16G FC only).
- Insert a frame after a standard or user defined Ordered Set (10GigE and 16G FC only)
- Perform FEC error injection (16G FC only)

## New Features

The following new features have been released in this version of Xgig Jammer.

- Xgig Jammer 32-bit client software is supported on both 32-bit and 64-bit versions of the Windows operating systems. Refer to the *Xgig Maestro Software Installation Guide* for the complete list of supported operating systems.

# ***Chapter 2***

## Using the Jammer Tab


### **In this chapter:**

- Using the Configuration Manager in Jammer
- Using the Parameters Status Table in Jammer
- Using the Parameters Status Context Menu in Jammer
- Using the Ports Manager in Jammer
- Using the Log Manager in Jammer
- Customizing the Appearance of the Maestro/Jammer Main Window
- Performing Configuration Tasks in Jammer
- Running the Test Suite on a Jammer Device

After you have discovered and locked the Jammer ports that you want to use and have set up your capturing and monitoring applications, such as Xgig Analyzer or Bus Doctor, you are ready to run the Xgig Jammer application. This chapter provides an overview of the Jammer tab, on the Xgig Maestro main window, and its functions; it also includes steps to run predefined tests supplied with the Xgig Jammer application or tests you have defined and saved.

You should have launched Xgig Maestro and locked at least one device as described in the *Xgig Maestro Introduction Guide*. The Xgig Maestro window is displayed with the Jammer tab on the right. This tab is where you operate the Jammers you have locked.

**Figure 2: Xgig Jammer Tab on Xgig Maestro Window**




## Using the Configuration Manager in Jammer

The Configuration manager (Figure 3) is associated with the device function tab, BERT and Jammer. This window allows you to select the protocol you want to use. This window also displays the configuration files specific to the function tab displayed. The **Sample Configurations** folder includes configurations that are provided with the application. The **User Configurations** folder is where the configurations you create are saved. The **Most Recently Used** folder allows you easy access to those configuration files most recently used. The Configuration Manager also includes a list of all the drives on your system allowing you to locate any configuration files on your system quickly.

The Configuration manager has the following features:


- The Configuration manager provides a list of test configurations organized into folders and lists all the drives on your system allowing you to easily browse to locate all of your configuration files on your system

**Figure 3: File Location in Jammer Configuration Manager**




- The configurations files in the **Configurations**, **Sample**, and **User Configurations** folders are organized according to protocol. When you open one of these folders, the Configuration Manager provides you with a list of protocols to select.

**Figure 4: Protocol Selection in Jammer Configuration Manager**



- List of configuration files in a folder

**Figure 5: Configuration Files and Description Pane**



- Description pane
  - When you select a configuration file in the list, a description of the file is displayed in the description pane below. It also displays the name of the file, the path where the file is located, the size of the file, the date and time when the file was created, the date and time the file was modified, whether the file is read-only and the Map path where the file is located on your system.
  - When you click the Show/Hide button below the Description pane, you display or hide this pane.
- Drag and drop files

You can drag any configuration from the Configuration manager list onto a device column to load it.
- Tool bar that lets you create, load, copy, cut, and paste configuration files. See “[Configuration Manager Tool Bar in Jammer](#)” on page 17 for more information on this tool bar.
- Context menu

Select a configuration file name, and right-click to display a menu where you can choose to create and edit configuration files, and additional operations. See “[Configuration Manager Context Menu in Jammer](#)” on page 18 for more information about these menus.
- Browse to map folders of files stored in locations other than the default Sample and User Configuration folders.

## Configuration Manager Tool Bar in Jammer

The Configuration manager tool bar (Figure 6) allows you to perform the following functions:

**New Configuration**  allows you to open the Configuration window and create a new Jammer configuration from scratch.

**New Folder**  allows you to create a new folder.

**Load**  allows you to load a configuration file into a port or ports. This icon is only active when a port has been locked and is selected in the Port Manager. See “[Loading Jammer Configuration Files](#)” for details.

**Map**  allows you to select a folder that you want to be listed in the Configuration Manager for the selected function tab.

**Unmap**  allows you to unmap a folder that has been mapped.

**Cut**  allows you to cut a file from its current location. This is not the same as deleting a file.

**Copy**  allows you to copy a file.

**Paste**  allows you to paste a file you have cut or copied.

**Delete**  allows you to delete a file or folder.

**Path**  allows you to go up one level in the folder tree. This field next to this icon displays the current folder name.

**Refresh**  allows you to refresh the Configuration Files and Description pane.

**Show/Hide**  allows you to show or hide the details for the selected file. These details appear in the lower section of the Configuration Manager pane.


**View**  allows you to view the files in the Configuration Manager as a list including only the file name or to view the details of the files in the list.

**Figure 6: Configuration Manager Tool Bar in Jammer**



## Configuration Manager Context Menu in Jammer

**Figure 7: Configuration Manager Context Menu in Jammer**



Right-click in the list to choose the following actions from the context-sensitive menu:

- **Up**  
Displays the contents one folder level up from the current display.
- **New Jammer Configuration**  
Opens a new Jammer configuration window for editing.
- **New Folder**  
Opens the Configuration manager dialog where you can enter the name of a new folder you want to add.
- **Edit Jammer Configuration**  
Opens the file highlighted in the list, the same as double-clicking on the file name.

- **Load Jammer Configuration into Selected Port(s)**

Loads the file highlighted in the list into the port(s) selected in the Ports Manager. See “Using the Ports Manager in Jammer.”
- **Cut**

Removes a selected file or folder from the list.
- **Copy**

Copies a selected file or folder to a clipboard making it available to paste in another location.
- **Paste**

Pastes a file or folder you cut or copied to the location you choose.
- **Rename**


Opens a dialog with the current file or folder name displayed in an entry field that you can modify. It also shows the protocol, path, and current file or folder name.
- **Delete**

Opens a dialog where you can confirm whether you want to delete the highlighted file (configuration) or folder from the list.
- **Must Confirm Delete**

Sets this choice as a preference that opens a dialog to confirm that you want to delete a file or folder from the list. When you select it, a check mark is displayed next to it. It is selected by default.
- **Map Folder**

Opens the Map Folder dialog box that lets you map a folder to a name of your choice.

**Figure 8: Map Folder dialog box**



Enter a name of your choice in the Mapped Folder Name field, and use the **Browse** button to select the folder on your system or network you want to map to this name.

- **Edit Mapping Path**

Allows you to edit the mapping path.
- **Unmap Folder**

Removes a highlighted mapped folder from the Configuration manager.
- **Explore**

Opens a Windows Explorer window showing the directory where the current configuration files are located.

- **Open Command Prompt**

Opens a Windows Command Prompt window showing the directory where the current configuration files are located.

- **Refresh**

Refreshes the Configuration Manager window.

- **View**

Has two choices:

- List

Displays the list of files or folders in the path you choose.

- Details

Displays the list of files or folders with the size and modification date.

## Using the Parameters Status Table in Jammer

Each Jammer device (a simplex Jammer or a duplex Jammer is considered as one device) is displayed by a column on the Jammer tab (Figure 9). At the top of each column is the protocol, the chassis name, and in parenthesis the chassis number, the slot number and port number(s) in parenthesis.

To configure how to display the ports in the Parameters Status Table, click on the Views button and do the following:

Select or unselect **Configuration** to display or hide the Configurations tab and Parameters tab where you manage Jammer configuration files and select the Parameters to display, respectively.

Click **Ports** to display or hide the Port Status table.

Figure 9: Jammer Parameters Status Table

PCIe XGIG1K20012297 (1.1.1)	
State	 Stopped
Jam Status	 Done
Configuration	 ( Not configured from a file )
Start / Stop	 Start
Pause / Resume	 Pause
	 Skip
	Operation
<b>Status</b>	
Protocol	 PCIe
Clock rate	 5.0 GT/s
Signal LED A	 Link up
Signal LED B	 Link up
PCIe Link Speed	Gen 2
PCIe Link Width	x8
Progress	Completed test 1
Log	Log available
<b>Settings</b>	
Protocol	PCIe
Clock rate	5.0 GT/s
Number of tests	1
Run suite...	
<b>Current test</b>	
Name	
Mode	Trigger + Jam on A
Arm name	
Trigger name	 SKP
Jam name	
Arm status	N/A
Arm-Trigger timeout	N/A
Trigger occurred	Yes
Trigger timed out	N/A
Repeat Mode	Trigger -> Jam once
Repeat Test Count	Test once
Test timeout	 No timeout

Not all parameters can be displayed at the same time. Refer to the following list for a complete list of parameters.

The first column on the tab is the legend for each row in the device columns and contains the following categories:

- State
- Jam Status
- Configuration
- Status
- Settings
- Current test

## Parameters Category Descriptions

### **State**

This row shows the state of the Jammer: Disconnected, Connecting, Paused, Pausing, Running, Skipped, Skipping, Starting, Stopped, or Stopping.

### **Jam Status**

Displays the state of the Jam defined in the currently loaded configuration file: Idle, Waiting for Trigger, Done, Skipped, Timed Out.

### **Configuration...**

Displays the name of the configuration file, if any, loaded into the port.

### **Start/Stop**

Click this button to Start or Stop a test. The green arrow icon indicates you can click the button to Start the test. The red box indicates you can click the button to stop the test.

### **Pause/Resume**

Click this button to pause or resume a test suite that is running.

### **Skip**

Click this button to skip a test that is running and move to the next test in the suite.

### **Operation**

Opens the Operation dialog box.

### **Status Category**

This category gives the status of the test suite that you have loaded into the Jammer.

### ***Protocol***

Indicates the protocol of the Jammer: Fibre Channel, Gigabit Ethernet, SAS, or SATA. You choose a protocol in the Port Selection and Domain Setup window when you lock ports. The small lock icon indicates that the protocol cannot be changed at this stage. For SAS and SATA Jammer, you may choose the protocol between SAS and SATA using the **Edit protocol and speed settings** option.

### ***Clock rate***

Indicates the Jammer clock rate. The closed lock icon indicates you cannot currently change the clock rate; the open lock icon indicates you can change the clock rate.

In Gigabit Ethernet, the clock rate is always 1.2500 Gbps, therefore, the icon is always locked.

In 10 Gigabit Ethernet, the clock rate can be either 1.0625 or 10.3125 Gbps.

In Fibre Channel, the clock rate can be 1.0625 Gbps, 2.1250 Gbps, 4.2500 Gbps, 8.5000, or 14.0250 Gbps.

In SAS and SATA, you can choose to auto-negotiate to any speed. You can also set the Jammer to force the link to only negotiate to either 1.5 Gbps, 3.0 Gbps, or 6.0 Gbps.

Both ports in a port pair must always be set to the same clock rate. Therefore, if you have two single Jammers, and one of them is running, the clock rate is locked on both.

### **Signal LED A and Signal LED B**

These two indicators change color, green, red, yellow, black, depending on the link status. They also match the **Link** status LEDs on the front panel of the blade in the Xgig chassis. Refer to the table below for the description of each LED color.

**Table 1: Xgig Jammer Blade LEDs**

Label on Blade	Blade	Parameters Status table-Signal A, Signal B
<b>In Use</b>	<ul style="list-style-type: none"> <li>Green when port locked by client application</li> <li>Black otherwise</li> </ul>	
<b>Link (3G) Signal (6G)</b>	<ul style="list-style-type: none"> <li>Green -FC, GE: when traffic is good</li> <li>Green-SAS/SATA: Speed set</li> <li>Yellow -FC, GE: Loss Of Synchronization</li> <li>Yellow-SAS/SATA: No speed set (Before OOB/In OOB)</li> <li>Blinking Yellow -SAS/SATA: In OOB</li> <li>Off-FC, GE:Loss Of Signal</li> <li>Off-SAS/SATA: No signal (nothing connected)</li> </ul>	<ul style="list-style-type: none"> <li>Green -FC, GE: when traffic is good</li> <li>Green-SAS/SATA: Speed set</li> <li>Yellow -FC, GE: Loss Of Synchronization</li> <li>Yellow-SAS/SATA: No speed set (Before OOB/In OOB)</li> <li>Blinking Yellow -SAS/SATA: In OOB</li> <li>Black-SAS/SATA: No signal (nothing connected)</li> </ul>
<b>Signal (12G)</b>	<ul style="list-style-type: none"> <li>Green (solid) - Link present</li> <li>Green (flashing) Traffic is coming</li> </ul>	

### **16G FC FEC**

This setting is only for 16G FC with the speed set at 14.0250 Gbps. Unlocked indicates that the setting is Auto. This is the default setting. To set this setting, select FEC Mode from the context menu, then select Auto, On, or Off. When this is set to On, the table will read “Locked”, and there will be a green dot next to the table entry.

### **PCIe Link Speed**

Indicates the link speed of the PCIe generation, Gen1 or Gen2.

### **PCIe Link Width**

Indicates the link width of the PCIe link in lanes.

### **Progress**

Indicates where the Jammer is in the test suite while it is running or where it is stopped or paused.

**Log**

Indicates if a log from the last operation is available for viewing.

**Settings Category**

This category indicates the current physical setup of the Jammer device. You can change most of the settings in this category by using the Parameters Status context menu for each device you have locked.

**Protocol**

Indicates the current protocol setting for the Jammer: Fibre Channel, 16G FC, Gigabit Ethernet, 10GigE, SAS, or SATA. To change the Protocol, you must select a device (port) from the port context menu in the Port Selection and Domain Setup window.

For SAS and SATA you can edit the protocol and the speed from the Parameters Status context menu.

**Clock Rate**

Indicates the Jammer clock rate. The clock rate options and behavior is different for the protocols and speeds. The clock rate options may include 1.0625 Gbps, 1.2500 Gbps, 2.1250 Gbps, 2.5000 Gbps, 4.2500 Gbps, 8.5000, 10.3125, or 14.0250 Gbps, depending on the blade. Both ports in a port pair must always be set to the same clock rate. Therefore, if you have two Jammers, and one of them is running, the clock rate is locked on both of them. See [“Changing the Clock Rate of a Jammer” on page 31](#) for instructions on changing the clock rate.

**Number of tests**

Displays the number of Test Cases in the currently loaded test suite. You can change the number of Test Cases to run in the Jammer Configuration window.

**Run suite...**

Indicates if the test suite is set to run only once or to loop forever (until you click **Stop**).

**GigE Jumbo Frames**

This indicates if Gigabit Ethernet jumbo frame support is enabled. (This is only available in the Gigabit Ethernet Jammer.) When enabled, the Jammer supports jumbo frames up to 16 KB in size, however, the latency through the port is about 136 microseconds. Otherwise, only normal 1500 byte frames are supported, with a latency of about 17 microseconds.

**Current Test Category**

This group of parameters gives information and status about the current test in the test suite that the Jammer is running or about to run.

***Name***

Displays the name of the current test.

***Mode***

Displays the current test mode setting that you set in the Jammer Configuration window.

***Arm name, Trigger name, and Jam name***

Displays the names given to each of the components of the current test.

***Arm status***

For a Test Case with an Arm condition, this indicates if that condition has been met.

***Arm-Trigger timeout***

Displays the number of 32-bit words the Jammer waits for the Trigger condition to be met after the Arm condition has been met. After this expires, the Jammer rolls back to wait again for the Arm condition.

***Trigger occurred***

Indicates if a trigger and Jam have occurred for this test case.

***Trigger timed out***

Indicates if the Arm-Trigger timeout has ever occurred for this Test Case.

***Repeat Mode***

Indicates the Test Case mode and whether or not it is repeated. You set this in the Jammer Configuration window, Test Case Repeat settings dialog.

***Repeat Count***

Indicates the number of times the Test Case is repeated.

***Test Timeout***

Indicates the total amount of time you have set the Jammer to wait for a Test Case to fully complete (including all repeats) before aborting and going to the next Test Case, preceded by the amount of time currently left. For example, when the Jammer is in the running state, the timer would show 59 sec/1:30 for a test configured to timeout after one minute, thirty seconds, while 59 seconds remain before the timeout.


## Using the Parameters Status Context Menu in Jammer

Right-click on the Parameters Status table to display the context menus shown in Figure 10. Each protocol has a unique context menu. The available operations are displayed for the column in which you click. This menu provides controls for configuration files, for setting clock rates, allowing jumbo frames, logging test activity, removing a Jammer from the Parameters Status table, and the appearance of the status table.

Refer to the following pages for more information about the how to use the context menu choices:

- [“Using the Parameters Status Table in Jammer”](#) on page 21 for information about the parameter settings you make from these menus.
- [“Running the Test Suite on a Jammer Device”](#) on page 62 for information about running the Jammer.
- [“Using the Log Manager in Jammer”](#) on page 50 for choosing log preferences.
- [“Performing Configuration Tasks in Jammer”](#) on page 60 for information about using the Load configuration file, Save configuration file, Reset configuration, and Edit configuration selections from these menus.

Figure 10: Jammer Parameters Status Table Context Menus



## Changing the SAS/SATA Protocol Setting of a Jammer

The procedure for changing the SAS/SATA protocol setting depend on the blade's speed.


### Changing the Protocol Setting for 3G Blades

To edit the SAS and SATA protocol setting on a 3G blade:

- 1 Select **Edit protocol and speed settings** from the Parameters Status context menu.

A dialog is displayed that lets you choose Auto-Negotiate between SAS and SATA (the default), SAS only, SATA only (Figure 11).

**Figure 11: SAS/SATA Protocol Setting Dialog for 3G Blades**



- 2 Click a radio button to choose the protocol.
- 3 Click **OK** to close the dialog and apply the settings.

You will receive a warning message. Click **OK** to apply the setting and reset the link, or click **Cancel** to discard the changes.

## Changing the Protocol Setting for 6G Blades

To edit the SAS and SATA protocol setting on a 6G blade:

- 1 Select **Edit protocol and speed settings** from the Parameters Status context menu.

A dialog is displayed that lets you choose Auto-Negotiate between SAS and SATA (the default), SAS only, SATA only (Figure 12).

**Figure 12: SAS/SATA Protocol Setting Dialog for 6G Blades**



- 2 Click a radio button to choose the protocol on the Protocol tab.
- 3 If you made a change from the previous setting, the option below will appear at the bottom of the dialog.

**Reset link after changes are applied to the settings above**

Check this check box if you want the link to reset when the change is applied upon clicking **OK**. Otherwise, clicking **OK** will apply the change, but the protocol will not change until the next time OOB initialization occurs.

- 4 Click **OK** to close the dialog and apply the setting.

## Changing the Clock Rate of a Jammer

The procedure for changing the clock rate for a port depend of the blade's speed and selected protocol.


### Changing the Fibre Channel Clock Rate for All But 6G Blades

To change the clock rate or speed on all but 6G blades for the Fibre Channel protocol:

- 1 Right-click anywhere on the specific device column to open the Parameters context menu.
- 2 Select **Clock rate**.

The speed choices are displayed (Figure 13).

**Figure 13: Fibre Channel Clock Rate Menu (except 6G blades)**



- 3 Click to choose one.

A bullet is displayed to the left of the currently operating selection.

- 4 Click **OK** to close the dialog.

You will receive a warning message. Click **OK** to apply the setting and reset the link, or click **Cancel** to discard the changes.

### Changing the Gigabit Ethernet Clock Rate for All But 6G Blades

To change the clock rate or speed on all but 6G blades for the gigabit ethernet protocol:

- 1 Right-click anywhere on the specific device column to open the Parameters context menu.
- 2 Select **Clock rate**.

The speed choices are displayed (Figure 13).

- 3 Click to choose one.

A bullet is displayed to the left of the currently operating selection.

- 4 Click **OK** to close the dialog.

You will receive a warning message. Click **OK** to apply the setting and reset the link, or click **Cancel** to discard the changes.


### Changing the SAS/SATA Clock Rate for 3G Blades

To change the clock rate or speed 3G blades for the SAS/SATA protocol:

- 1 Right-click anywhere on the specific device column to open the Parameters context menu.
- 2 Select **Edit Protocol and speed settings** for SAS or SATA Jammer.

The speed choices are displayed (Figure 14).

**Figure 14: SAS/SATA 3Gbps Speed Settings Dialog**



- 3 Click to choose one.

You can also specify one or both protocols. Refer to “Protocol” on page 25.


- 4 Click to choose one.
- 5 Click a radio button in the in the **Speed** section of the **Protocol and speed setting** dialog.
- 6 Click **OK** to close the dialog.

You will receive a warning message. Click **OK** to apply the setting and reset the link, or click **Cancel** to discard the changes.

### Changing the SAS/SATA Clock Rate for 6Gbps Blades

To change the clock rate or speed 6Gbps blades for the SAS/SATA protocol:

- 1 Select **Edit protocol and speed settings** from the context menu.
- 2 The **Protocol and speed settings** dialog appears.

**Figure 15: Speed Settings Menu for SAS and SATA on a 6Gbps blade**

If you made a change from the previous setting, the option below will appear at the bottom of the dialog.

**Reset link after changes are applied to the settings above**

- 3 Check this check box if you want the link to reset when the change is applied upon clicking **OK**. Otherwise, clicking **OK** will apply the change, but the protocol will not change until the next time OOB initialization occurs.
- 4 Select either the SAS Speed Settings or the SATA Speed Settings tab. See [Figure 15](#).



**Note:** Both ports of the port pair share one protocol and one clock rate; therefore, two adjacent simplex Jammers always have the same protocol and clock rate.


- 5 Select the speed setting you want for SAS or SATA.
- 6 Click **OK** to close the dialog and apply the setting.

The 6Gbps blade also has a **Without OOB (Advanced)** tab at the top of the window see [Figure 16](#). This allows you to set the speed the Jammer if no OOB is detected after a broken link. This can be useful if, for some reason, you want to attach equipment without going through OOB.



**Note: For Fibre Channel and SAS/SATA only** The clock rate is not saved in the configuration file. This allows Jammer scripts to run independently of the clock rate setting and avoids breaking the link to which the Jammer is connected.

**Figure 16: Without OOB (Advanced) Tab 6G**





**Caution:** Changing the clock rate disrupts the traffic passed through the FC and 3 Gbps SAS/SATA Jammer. A warning message appears when you change the setting ([Figure 17](#)).

**Figure 17: Changing Clock Rate and Protocol/Speed Warning Dialogs**

**Fibre Channel and Gigabit Ethernet**

**SAS and SATA on a 3Gbps Blade**



### Changing the SAS Clock Rate for 12G Blades

To change the clock rate or speed 12Gbps blades for the SAS protocol:

- 1 Select **Edit protocol and speed settings** from the context menu.
- 2 The **Protocol and speed settings** dialog appears.

**Figure 18: Speed Settings Menu for SAS on a 12Gbps blade**

Protocol and Speed Settings

Port : QA\_5000\_GEN4 (2,3)

Settings for OOB and Speed Negotiation Without OOB (Advanced)

Auto-negotiate to the highest speed 12 Gbps, 6 Gbps, 3 Gbps

Use advanced SAS speed negotiation settings

Allow SNW-2 window (G2/3.0 Gbps window in SAS-1.1)

Allow SNW-3 window

Allow Train-SNW 3.0 Gbps without SSC window

Allow Train-SNW 6.0 Gbps without SSC window

Allow Train-SNW 12.0 Gbps without SSC window

Train-SNW 12.0 Gbps Parameters

Transmitter Mode

Mode Mode 4

Jammer initiates a set of 6 pairs of increment, and decrement to each coefficient for a net effect of zero, and then go to the wait state at the Train Complete state.

Programming Coefficients

	Coefficient 1	Coefficient 2	Coefficient 3
Max	38	255	76
Min	0	1	0
NoEqualization	0	255	0
Reference 1	38	154	63
Reference 2	19	205	31
Default	19	1	38

Restore all parameters to default

Reset link after changes are applied to the settings above

OK Cancel

You can either use the Auto-negotiation settings or the advanced SAS speed negotiation settings. The options available from the **Auto-negotiate to the highest speed** drop-down menu are:

- 12Gbps, 6Gbps, 3Gbps
- 6Gbps, 3Gbps
- 3Gbps



**Important:** It is recommended that if you have a 6Gbps device, you select the **6Gbps, 3Gbps** option, and if you have a 3Gbps device, you select the **3Gbps** option.

### 3 Set advanced speed negotiation settings.

For Train-SNW 12.0 Gbps Parameters, you can set the **Transmitter Mode**, which determines how the Tx training transmitter state machine behaves. When you select a transmitter mode, the mode's description appears below the drop-down menu.

You can also set the **Programming Coefficients**. The coefficient values are initially set to the default when you initiate the SAS link reset. The coefficient values will be changed based on requests from devices under test and will be within the range of the Min and Max values. For example, if the device requests that the Jammer to go to Reference 1, the coefficient values will be moved to current Reference 1 values. All coefficient values must be between 0 and 255.

Changing the pointer value for each coefficient does not affect the signal. It is only for logical testing of devices under test.

If you set the coefficients and do not want to keep the new values, click the **Restore all parameters to default** button.

If you made a change from the previous setting, the option below will appear at the bottom of the dialog.

**Reset link after changes are applied to the settings above**

### 4 Check this check box if you want the link to reset when the change is applied upon clicking **OK**. Otherwise, clicking **OK** will apply the change, but the protocol will not change until the next time OOB initialization occurs..



**Note:** Both ports of the port pair share one protocol and one clock rate; therefore, two adjacent simplex Jammers always have the same protocol and clock rate.

---

### 5 Select the speed setting you want for SAS.


### 6 Click **OK** to close the dialog and apply the setting.

The 12Gbps blade also has a Without OOB (Advanced) tab at the top of the window see [Figure 19](#). This allows you to set the speed the Jammer if no OOB is detected after a broken link. This can be useful if, for some reason, you want to attach equipment without going through OOB.



**Note: For Fibre Channel and SAS only** The clock rate is not saved in the configuration file. This allows Jammer scripts to run independently of the clock rate setting and avoids breaking the link to which the Jammer is connected.

---

**Figure 19: Without OOB (Advanced) Tab 12G**

## 16G FC FEC

16G FC blades running at 14.0250 Gbps have a FEC (Forward Error Correction) setting that allows you to specify if FEC is enabled on the link. To set, select FEC Mode from the context menu. Then, select On, Off, or Auto. Auto is the default. This setting allows Jammer to automatically detect if FEC is enabled for a link.

## Scrambling

Some blades give the option of enabling Fibre Channel Frame Scrambling, which is part of the Fibre Channel Specification for 8.5000 Gbps. You may enable or disable scrambling at any speed. Select **Scrambling** from the Parameters context menu, and then select **Enabled** or **Disabled**. A check mark appears next to the current selection. When Scrambling is enabled, Fibre Channel Frame Scrambling is performed in the Configuration pattern starting after any SOF indicator template and continuing until the next word with a K character (usually EOF).



**Note:** When changing the clock rate from 8.5000 Gbps to any other speed, Scrambling is automatically set to Disabled. When changing to 8.5000 Gbps, it is automatically set to Enabled. You may then override this setting using the Parameters context menu.


## Changing the GigE Jumbo Frames Setting

To change the jumbo frame setting:

- 1 Open the Parameters context menu (Figure 20).
- 2 Select **Jumbo frames**.  
Another menu appears with the two choices.
- 3 Click to choose one.


A bullet is displayed to the left of the currently operating selection.

**Figure 20: GigE Jumbo Frames Menu**



**Caution:** Changing the supported frame size disrupts the traffic passed through the Jammer. A warning message appears when you change the setting (Figure 21).

**Figure 21: GigE Jumbo Frame Warning**



**Note:** The frame size (Gigabit Ethernet only) is not saved in the configuration file. This allows Jammer scripts to run independently of this setting and not disrupt the link when a new configuration is loaded.

## Replace Received Invalid Data with Idles

This option is for 10GigE only. It allows you to replace invalid data with Idles before it passes through the Jammer.

## Tuning and Equalization

Tuning and Equalization are procedures to optimize ports on the 6G SAS/SATA 4x/Wide-Port Blade for your environment. When you connect the Xgig SAS Analyzer, Jammer, or Generator in a new environment (for example, after changing devices or cable length) we recommend that you run the Tuning procedure detailed in the *Xgig Tuning and Equalization* document. Click **Tuning and Equalization** to open the **Tuning and Equalization** window.


### Tuning for 12G SAS

This option is for 12G SAS only. Click **Tuning** to open the **SAS Link Tuning** dialog. If two blades are being used, you must tune each blade independently by launching the **SAS Link Tuning** dialog twice.

The new **12G SAS Link Tuning** dialog introduces a new concept of port groups. It still focuses on the tuning of a single 12G blade, but the ports on the blade are aggregated into port groups. The port groups are named "Input #n" or "Output #n", referring to ports on the mini-SAS connectors. The dialog shows the port group for the selected configuration and allows you to load a preset tuning, auto-select the best preset, or auto-tune.

The top portion of the **12G SAS Link Tuning** dialog displays the lane steering diagram for the current link configuration. It is the same dialog as visible inside the Discovery dialog's Link Configuration, except that the wire colors uniquely identify port groups.

**Figure 22: 12G SAS Link Tuning Dialog**




Use the drop-down menu to select a tuning method. You can choose from the following options:

- Auto-select the best preset
- Auto-tune
- Change to [preset name]

### ***Auto-select the best preset***

To automatically select the best preset, select **Auto-select the best preset** from the Tunings drop-down menu. Then, click the **Apply Changes** button. The software selects the best preset from the list of saved presets and applies that tuning preset to the hardware. This selection is based on the preset with the lowest bit error rate (BER). When the preset selection is complete, the following dialog is displayed showing the selected preset.

**Figure 23: Auto-Select Complete Dialog**



The **Save** area is reserved for future use.

Click the **Back** button to close the dialog and returns to the **SAS Link Tuning** dialog where the name of the preset selected is shown as the current tuning.

Click the **Exit** button to close the dialog and return to the **Jammer** tab of the **Xgig Maestro** window.

## Auto-tune

Auto-tuning in Jammer is supported by the following configurations:

#32 – A-J-A,A


#34 – J-A

#41 – G-J-A,A

Before starting the auto-tuning process, try applying the best preset. If you are not sure which one is best, perform the Auto-Select the best preset process. This may shorten the time it takes to auto-tune. To auto-tune all the ports in the configuration loaded on the hardware for the ports you have selected, select **Auto-tune** from the Tunings drop-down menu. Then, click the **Apply Changes** button to begin the auto-tuning process. Note that when a configuration is selected in the **Discovery** dialog, auto-tuning will tune all the ports in that configuration regardless of whether the other ports in the configuration are locked or not.

A dialog appears showing the tuning progress. It includes the duration of the tuning and the bit error rate (BER).


**Figure 24: Auto-tuning In Progress Dialog**



The auto-tuning process concludes only when the ports are error free for the longest of a series of intervals. This may take six hours or more. You can stop the auto-tuning process at any time and keep the best settings found thus far by clicking the **Stop, Keep Best** button.


In this case, the dialog shown in Figure 25 appears.

**Figure 25: Auto-tuning Stopped Dialog**



When the auto-tuning process has completed, the following dialog appears showing the duration of the process.

**Figure 26: Auto-tuning Completed**



In the **Save** area, the group and the name of the tuning is displayed. The group is provided by default and is not editable. The default name of the auto-tuning is *MyLastTuning*. You can change the name by typing another name into the text field. When you enter a new name, a **Save** button is displayed. Click the **Save** button to save the auto-tuning with the new name.

Click the **Back** button to close the dialog and returns to the **SAS Link Tuning** dialog.

Click the **Exit** button to close the dialog and return to the **Jammer** tab of the **Xgig Maestro** window.

### ***Change to [preset name]***

To load a preset on the ports in a configuration, click **Change to [preset name]** from the Tunings drop-down list. Then, click the **Apply Changes** button. The software applies the tuned settings of the preset configuration hardware and returns to the **Jammer** tab on **Xgig Maestro** window.

In addition to the default settings, the tuned settings that you have saved after auto-tuning are also available.


The **Manage Presets...** button opens a dialog allowing you to delete or rename presets.

All the presets are listed in the right column. The left column shows the port groups affected by each preset. You cannot rename or delete the factory provided presets, nor any preset currently in use.

## Tx Equalization

Tx Equalization allows you to configure transmitter settings for the Jammer and Generator. Click the **Tx Equalization** button to open the dialog box. For each port, you can specify pre-emphasis and output levels. Tx Equalization is an advanced feature. These settings should normally be left at their defaults, unless changes are recommended by Viavi [“Technical Support”](#).

**Figure 27: Tx Equalization**



The pre-emphasis module in each transmitter boosts high frequencies in the transmit data signal to compensate for attenuation in the transmission media. Three pre-emphasis taps are provided: Tap 0 is the pre-tap, Tap 1 is the first post tap, and Tap 2 is the second post tap.

Tap 0 sets the pre-emphasis on the data bit before each transition. Tap 1 and Tap 2 set the pre-emphasis on the transition bit and the following bit, respectively. Tap 0 and Tap 2 also provide inversion, which is set by using a negative value for the tap setting.

Allowable ranges are -15 to 15 for Tap 0 and Tap 2 and 0 to 31 for Tap 1.

The output level sets the transmitter amplitude. The allowable range is 0 to 7, which corresponds to an amplitude range of approximately 200 – 1200mV.

Note that these settings are applied on internal signal paths in the hardware, and the full effect will not normally be seen at the cable outputs.

## Using the Ports Manager in Jammer

The Ports manager displays details about the ports you have locked. It shows the protocol, chassis name (with chassis number, slot number, and port numbers), and other port specific information. You can sort the rows from first to last or last to first by clicking the column heading. For more information about Xgig slot positions and numbering, refer to the Xgig Family Hardware Guide included with the product CD.



**Note:** If you are disconnected due to a network problem, you can reconnect to the ports by using the Port Selection and Domain Setup window.

**Figure 28: Jammer Ports Manager**

Select	Type	Protocol	Address	Start / Stop	Status	Domain of Port A	Domain of Port B
<input checked="" type="checkbox"/>	Jammer	SAS/SATA	XGIGSWDEV1 (1,1,7-8)	▶ Start	Operation	■ Stopped	
<input checked="" type="checkbox"/>	BERT - Bit error rate testing	Gigabit Ethernet	XGIGSWDEV1 (1,2,3)	▶ Start	Operation	■ Stopped	N/A
<input checked="" type="checkbox"/>	BERT - Bit error rate testing	Gigabit Ethernet	XGIGSWDEV1 (1,2,4)	▶ Start	Operation	■ Stopped	N/A

The following icons are displayed on the menu bar:



### Select All Ports

Selects all ports in the Ports Manager.



### Unselect All Ports

Unselect all ports in the Ports Manager.



### Load Configuration to Selected Ports

Load the selected configuration file to all selected ports in the Ports Manager.



### Start Selected Ports

Start BERT operation on the selected ports in the Ports Manager.



### Stop Selected Ports

Stop BERT operation on the selected ports in the Ports Manager.



### Show Properties of Selected Ports

Display the Port Properties dialog box, with information on the selected function, protocol, and clock rate (speed). It also shows the chassis name, IP address, slot and port(s).



### Disconnect Selected Ports

Disconnect the selected ports in the Ports Manager.




### Disconnect All Ports

Disconnect all ports in the Ports Manager.

## Actions Button

The **Actions** button contains menus for **Multiple speed Change** and **Toggle Display**. See Figure 29.

**Figure 29: Actions Button Options**




### Multiple Speed Change

This option allows you to change the speed of multiple Jammer ports simultaneously. If you have the All Devices tab selected, the menu will display BERT, Jammer, and Generator. For Jammer, you can choose to change the speed of 6.0 Gbps and 3.0 Gbps blades.

Select the ports you want to change the speed for, holding the Ctrl key down to select multiple ports, then click the speed you want to change to, and click **OK** to apply the change.

**Figure 30: Multiple Speed Change Menu**



#### ***For Jammer Fibre channel***

Select the ports you want to change the speed for, then click the speed you want to change to, and click **OK** to apply the change.

#### ***For Jammer SAS/SATA 3.0 Gbps***

- 1 Select the ports you want to change the speed for.
- 2 Select the protocol you want, Auto-negotiate, SAS only, or SATA only.
- 3 Select the speed you want to change to.
- 4 Check the **Reset link after and changes are applied** check box if you want the link to reset when the change is applied upon clicking **OK**. Otherwise, clicking **OK** will apply the change, but the protocol will not change until the next time OOB initialization occurs.

#### ***For Jammer SAS/SATA 6.0 Gbps***

- 1 Select the protocol you want, **Auto-negotiate**, **SAS only**, or **SATA only**.
- 2 Select either the **SAS Speed Settings** or the **SATA Speed Settings** tab.

If you made a change from the previous setting, a check box will appear at the bottom of the dialog highlighted in yellow with a message that reads, **Reset link after and changes are applied to above settings**.

- 3 Check the **Reset link after and changes are applied** check box if you want the link to reset when the change is applied upon clicking **OK**. Otherwise, clicking **OK** will apply the change, but the protocol will not change until the next time OOB initialization occurs.
- 4 Select the speed settings you want for SAS or SATA.
- 5 Click **OK** to close the dialog and apply the setting.

The 6Gbps blade also has a Without OOB (Advanced) tab at the top of the window see. This allows you to set the speed the Jammer if no OOB is detected after a broken link. This can be useful if, for some reason, you want to attach equipment without going through OOB.



**Note: For Fibre Channel and SAS/SATA only** The clock rate is not saved in the configuration file. This allows Jammer scripts to run independently of the clock rate setting and avoids breaking the link to which the Jammer is connected.

---

### Toggle Display

This option toggles between a horizontal and vertical view of the ports.

## Ports Manager Columns

The Ports Manager includes the following columns:

### Operation

**Operation** is a button you press to display the Operation bar for the device you are using. Refer to [“Running the Test Suite on a Jammer Device” on page 62](#) for additional information.

### Status

Information in this column displays the state of the device under test.


### Domain of Port A and Domain of Port B

Each of these fields indicates to which domain the respective port belongs. In a simplex Jammer, only port A is relevant. In a duplex Jammer, the lower port number is always port A. You set up domains in the Port Selection and Domain Setup window. Refer to the *Xgig Maestro Introduction Guide* for more information.

### Output Voltages

The Output Voltage settings are for the SAS and SATA protocols and display each port number and the corresponding output voltage setting.

Click on the Output Voltages field in the Port Manager to open the dialog box. This allows you to select the amplitude control for the output voltage buffers. There are two output voltage settings, High and Low.

**Figure 31: Output Signal Voltage Dialog**

**High:** The default setting is High. If the output voltage for a port is set to high, then the Output Voltages field in the Port Manager reads “Norm” Port 1 - Norm 2 - Low .

The High setting, is useful for driving extended length cables. This setting also provides a pre-emphasis circuit that boosts higher frequency signals to compensate for signal amplitude loss that affects the data eye in long trace length runs.




**Caution:** For ports on 6G blades using a SATA cable connected to a SATA device, it is possible for the SATA receiver voltage to exceed the maximum specifications. To keep the SATA receiver voltage within the specifications, it is advisable that you set the output voltage for these ports to “Low”.

**Low:** If the output voltage for a port is set to Low, then the Output Voltages field in the Port Manager reads “Low” Port 1 - Low 2 - Norm . You can set the signal to Low when you are using short cables with SATA devices.

## Using the Ports Manager Context Menu

You can right-click in the Ports Manager to open the context menu (Figure 32).

**Figure 32: Ports Manager Context Menu**



The menu contains the following choices:

### Text Size

Refer to “Changing Text Size” on page 58 for information.


### Columns

This choice opens a Customize table dialog (Figure 33) where you can choose to display **Domain of Port A**.

Click the check box next to this item to display this item in the Ports Manager.

The grayed out items are defaults; you cannot clear these items.

**Figure 33: Jammer Ports Manager Context Menu Parameters Selection**



## Using the Log Manager in Jammer

To access the Log Manager, click the Log tab at the bottom of the Jammer main window.

The purpose of logging is to automatically create a log that reports which Jam tests have occurred and which ones might have reached the timeout limit while not finding a trigger to Jam. You can view a log with any text editor.

The Filter icons next to the **Type** and **Address** column labels allow you to choose how you want to display device types, by protocol or All, and device addresses, by single address or All devices.

If the **All Devices** tab at the top of the Xgig Maestro main window is selected, then the **Log Source** menu  2 active log sources ▾ shows all log sources as active by default. You can choose to disable BERT logging, Jammer logging, Generator logging, Target Emulator logging, or all four by clicking the **Log Sources** menu and un-checking the selections. If the **BERT-Bit error rate testing**, **Jammer**, or **Generator** tabs in the main window are selected, then the Log Manager displays only the log entries for that tab, respectively.

The following icons are displayed on the Log Manager menu bar:



### Display Entry Contents

Lets you save the selected log to a file in the device Logs folder (for example: C:\Program Files\Viavi\Xgig Maestro\Jammer\Logs) or anywhere you want to save it on the network. Refer to the note on page 54 for information about installation on 64-bit operating systems.



### Save All Entries As

Lets you save all the logs in the Log Manager to a file.



### Save selected entries as

Lets you save the selected logs to a file.



### Select All

Selects all the logs in the Log Manager.



### Options

Opens the Log Manager Options dialog where you can enter your preferences for the information you want displayed in the Log Manager (Figure 34).



### Clear Filtering

Removes filtering by Type and Address and displays all the devices you have locked.



### Clear Selected Entries

Deletes the log entry you have highlighted.



### Clear All Entries


Deletes all the log entries in the Log Manager.

## Setting Log Options

To have log files automatically named and saved to a specific location:

- 1 Click the Log Manager Options icon to open the drop-down menu (Figure 34), and select **Jammer logging options**.

**Figure 34: Log Manager Options Menu**




Or:

Open the Parameters context menu and select **Options**.

Either of these commands opens the Jammer Log Options dialog (Figure 35). This dialog allows you to set up how you want the log files to be automatically named and the default location where you want them saved. You can also change the filename and folder when you save the log.

**Figure 35: Log Options Dialog**



- 2 Select a log filename template from the following choices:

- JammerLog\_[port]
- JammerLog\_[port]\_[date]\_[time]
- JammerLog\_[date]\_[time]
- JammerLog\_[date]\_[time]\_[port]

Or, you can type in your own template. Any [port], [date], and [time] in the template is replaced by the corresponding value. Port is displayed as:

protocol (FC, GE, or SAS), chassis name (chassis number in the cascade, blade number in the chassis, port number on the blade)

- 3 Enter the path to the folder where you want to save the log file.

You can browse to where you want to save the log file by clicking .

- 4 Click **OK**.

You have set up the log filename template and default folder to save the log.



**Note:** These settings apply to all Jammer logs. Log options are the same for all Jammer ports.

## Viewing a Log

The Jammer log shows the status of each Test Case during the entire length of the test run

To display a log:

>> Click the **Log Manager** tab at the bottom of the Xgig Maestro main window to view the log in a tabulated format (Figure 36).

Or:

>> Double-click on the log you want to view in the Log Manager to display the Log Entry Display (Figure 37).

Or:

>> Click the **Log** button on the Operation bar (with the appropriate Jammer device selected in the Parameters Status table; a green check mark indicates the device is selected).

Or you can:

>> Open the Parameters context menu and select **Log > View**.

These two latter commands open a window that allows you to quickly view the Xgig Jammer log. (Figure 38). In the case of these two methods, each time you run a Jammer, a new Jammer log is created for the device, and the previous log is discarded. Click **Print** at the bottom of the Jammer log to print a hard copy of the log.

On the other hand, the Log Manager continues to list the logs and display them depending on the Log Manager options you have selected. See “Setting Log Options” on page 51.


You can save a log to a .txt file or an HTML file. Refer to “Saving a Log” on page 54.

**Figure 36: Log Manager**


DateTime	Type	Address	Contents
4/12/2007 2:38:39 PM	BERT Fibre Channel	XGIGSWDEV1 (1,1,1)	Port used : XGIGSWDEV1 (1,1,1) Protocol : Fibre Channel Clock rate : 8.5000 Gbps ...
4/12/2007 2:38:38 PM	BERT Fibre Channel	XGIGSWDEV1 (1,1,2)	Port used : XGIGSWDEV1 (1,1,2) Protocol : Fibre Channel Clock rate : 8.5000 Gbps ...
4/12/2007 2:37:11 PM	BERT Fibre Channel	XGIGSWDEV1 (1,1,1)	Port used : XGIGSWDEV1 (1,1,1) Protocol : Fibre Channel Clock rate : 8.5000 Gbps

Ports: Log

**Figure 37: Viewing a Log in the Log Entry Display**



**Figure 38: Example of a Jammer Log Display**



## Saving a Log

You can save a log from the Log Manager tab or the Parameters context menu.

To save a log from the Log Manager tab as an HTML file or text file:

- 1 Highlight the log you want to save.
- 2 Click the **Save Selected Entries As...** button.

The Save Log Manager Contents As window is displayed that lets you name and save the log as an HTML file to the Saved Logs folder or to a location you prefer.

Or:

- >> Double-click on the log you want to save to display it in the Log Entry Display window (Figure 37), then click **Save As...**

The Save As window is displayed that lets you name and save the log to the Logs folder as a .txt file, or to a location you prefer.

To save a log to a .txt file using the Parameters context menu:

- >> Open the Parameters context menu (Figure 39) and select **Log > Save As**.

This command opens a File dialog where you can save the log with a file name you assign to it. The default location is C:\Program Files\Viavi\Xgig Maestro\Jammer\Logs.



**Note:** This software application can be loaded on 32-bit or 64-bit Windows operating systems. The path used above is for a 32-bit operating system.

If you are using a 64-bit operating system, the path would be:

C:\Program Files(x86)\Viavi\Xgig Maestro\Jammer\Logs

**Figure 39: Log Menu**



---

## Customizing the Appearance of the Maestro/Jammer Main Window

You can move and rearrange the individual device tabs on your monitor screen as you prefer. You can also select the information you want to display in the Parameters Status table. In addition, you can select the size of displayed text.

### Using the Window Menu

The **Window** menu allows you to arrange the window display:

#### **Layout**

Layout offers choices for rearranging the Maestro device tab windows. The Ports manager and Log Manager windows are not affected by this menu selection.

#### ***Internal Tabs***

Allows you to restore the Maestro main window to its default format.

#### ***Internal MDI***

Internal multiple document interface (MDI) lets you isolate each device tab as a separate window that you can activate by clicking anywhere on the window.

#### **Show Hidden Windows**

Restores any windows you have closed while using the Internal Tabs or Internal MDI display arrangement.

#### **Arrange Icons**

Arranges the icons for minimized windows at the bottom of the screen. If an open document window is at the bottom of the screen, some or all of the icons will be underneath this document window and will not be visible.

#### **Cascade**

Arranges all open windows in a cascade style from the top, left corner of the window.

#### **1 All Devices**

Brings the All Devices tab to the front as the active window. This window displays ports from all active devices (BERT, Jammer, Generator, and Target Emulator).

#### **2 BERT - Bit error rate testing**

Brings the BERT device tab to the front as the active window

#### **3 BERT - Latency measurement**

Brings the BERT Latency measurement device tab to the front as the active window

#### **4 Jammer**

Brings the Jammer device tab to the front as the active window

#### **5 Generator**

Brings the Generator device tab to the front as the active window

#### **6 Target Emulator**

Brings the Target Emulator device tab to the front as the active window

#### **Tile Horizontally**

After selecting **Layout > Internal MDI**, this command opens and aligns the BERT, BERT Latency measurement, Jammer, Generator, and Target Emulator device windows horizontally one over the other.

#### **Tile Vertically**

After selecting **Layout > Internal MDI**, this command opens and aligns the BERT, BERT Latency measurement, Jammer, and Generator, and Target Emulator device windows vertically one next to the other. You can view the individual device windows by dragging the sides out to resize them.

#### **Minimize All Windows**

After selecting **Layout > Internal MDI**, this command minimizes all the open windows. You can restore each window, individually, by using the standard window controls on the header or select **Internal Tabs** to restore the Maestro main window to its default format.

## Customizing the Parameters Status table in Jammer

You can change the appearance of the Parameters Status table by:

- Removing columns
- Resizing columns
- Changing the text size
- Displaying and hiding status table parameters

### Removing columns

If you have a number of devices locked, you can remove a column that you do not need to view without unlocking the port or affecting the operation.

To remove a column:


- 1 Right-click on the specific column you want and open the Parameters context menu.
- 2 Select **Do not show Jammer** (Figure 40).

Or:

In the Ports Manager, clear the **Show** check box next to the device you want to remove.

The column is removed, but the device is still locked (“in use”) and displayed in the Ports Manager.

**Figure 40: Removing a Device Column**



To replace the device column on the Parameters Status table:

- >> Click the **Show** check box for the device in the Ports Manager.

## Resizing columns

You can resize any of the columns by placing the mouse at the right edge at the top of a column, next to the chassis name. A resizing cursor appears. Hold down the mouse button, and drag the mouse to resize the column.

## Changing Text Size

You can choose the text size you want the Parameters Status table or the Ports Manager to display.




**Note:** You cannot change the text size in the Log Manager.

To change text size:


- 1 Open the context menu by clicking the right mouse button while the cursor is on the Parameters Status table or the Ports Manager.
- 2 Select **Text size** (Figure 41).  
You have five choices from which to select.  
Smallest is the default size.
- 3 Select the text size you want.  
A bullet is displayed next to the current selection.

**Figure 41: Text Size Menu**

Context menu over Ports manager



Context menu over device parameters status table



## Displaying and Hiding Parameters in Jammer

You can hide specific parameters on the Parameters Status table to simplify the status tables and show only the information in which you are interested.


To display or hide parameters on the Parameters Status table:

- 1 Click the Parameters tab at the top of the Configuration manager pane to switch to the Parameters manager (Figure 42).

You can expand the categories by clicking the plus signs on the left.

The default displays most of the parameters.

**Figure 42: Jammer Parameters Manager**



- 2 Click check box to set or clear the check mark next to the parameters. Checked parameters are displayed.

---

## Performing Configuration Tasks in Jammer

This section describes how to handle configuration files from the Jammer main window.

### Loading Jammer Configuration Files

You can load a configuration file on a Jammer using one of the following methods:

#### From the Configuration Manger:

- >> Drag the configuration file from the list in the Configuration Manager onto the Parameters Status table (column for the device) and release the mouse button.

You can drag configuration files from anywhere, including the list of configuration files in the Configuration Manager on the Xgig Maestro window, the system desktop, or Windows Explorer.

#### From the Parameters Context Menu

- 1 Right-click on the device column to open the Parameters context menu and select **Load configuration file**.

An Open File dialog is displayed.

- 2 Navigate to the Jammer `.tsk` file that you want to use and click **Open**.

The file is loaded and its name and parameters are displayed in the device column of the Parameters Status table.

#### From the Ports Manager:

- 1 Check the **Select** check box(es) in the Ports Manager for the port(s) you want to use.
- 2 Click the configuration file you want to load from the Configuration Manager.
- 3 Click the **Load Configuration to Selected Ports** button . This button is located in the Ports Manager and in the Configuration Manager. Both have the same function.

You can use the above methods to navigate to a mapped folder and load a configuration file.

### Saving a Jammer Configuration File

To save a Jammer configuration file you created or edited:

- 1 Right-click on the device column in the Parameters Status table to open the Parameters context menu, and select **Save configuration file**.

A Windows Save dialog is displayed.

- 2 Navigate to where you want to save the configuration file and assign a name to it.

Xgig Jammer configuration files are saved with a `.tsk` extension.


### Resetting a Jammer Configuration

To clear the configuration from a device:

- 1 Right-click on the device column in the Parameters Status table to open the Parameters context menu, and select **Reset configuration**.

A warning dialog may be displayed asking you to confirm the configuration reset.

**Figure 43: Reset Configuration Warning Dialog**



- 2 Click **Yes** to clear the configuration from the device.

## Editing a Jammer Configuration

To create a configuration file for a device, you can start from a blank default configuration or edit the configuration after you have loaded a configuration file to the device.

You can open the Configuration window using one of the following methods:

- 1 Right-click on the device column in the Parameters Status table to open the Parameters context menu.
- 2 Select **Edit configuration**.

Or:

- >> Click the **Configuration** button on the Parameters Status table

This opens the Configuration window for the device that is currently selected. Refer to or [“Using the Jammer Configuration Window”](#) on page 116 for more information.

## Running the Test Suite on a Jammer Device

After you have configured a Jammer device, you can start the operation. Three methods are available:

>> Click the **Start** button on the Parameters Status table.

**Figure 44: Parameters Status table Start Button**



Or you can:

>> Right-click on the device column to open the Parameters context menu where the **Start**, **Pause**, **Skip**, and **Stop** commands are available.

Or:

1 On the Ports manager, select the device.

2 Click the **Start** button  .


Or:



1 On the Ports manager, in the Operation column, click the **Operation** button for the device.

The Operation dialog is displayed (Figure 45, Figure 46, and Figure 47).

2 Click **Start**.

**Figure 45: Jammer Tab Operation Bar for Fibre Channel and Gigabit Ethernet**



**Figure 46: Jammer Operation Dialog for SAS and SATA****Figure 47: Jammer Operation Dialog for 16G FC**

Clicking any of the Operation buttons (including **Config**) takes effect on the Jammer device that is currently selected in the Parameters Status table.

**Start** runs the Test Suite from the beginning if you click it while the Jammer is stopped. The Start button label becomes a Stop label while the Test Suite is running.

**Pause** causes the Jammer to pause and not run the next Test Case in the Test Suite when the current Test Case is completed. When you click **Pause**, the State of the Jammer is “Pausing” while the current Test Case is still running. When the current Test Case completes (or is skipped), the Jammer is in the “Paused” state waiting for user intervention.

**Skip Current** causes the Jammer to abort the current Test Case and move on to the next test in the test case. If the Jammer is “Paused,” you can click **Skip** to jump through your Test Suite without running any Test Cases until you get to the Test Case you want to run and resume testing. If you skip past the last Test Case in the Test Suite and the Test Suite is not set to loop forever, then the Jammer goes to the Stopped state as if the Test Suite completed.

To let a test run to the end and then skip to another test:

- 1 Click **Pause**.  
Wait for the current test to finish.
- 2 Click **Skip To** to step through the tests.
- 3 Observe the progress field on the Parameters Status table to track tests in the queue.
- 4 Click **Start**.

**Skip To** allows you to skip to a specific test in the test case.

To skip to a specific test:

- 1 Select a test number from the drop-down menu next to the **Skip To** button.
- 2 Click **Skip To** to skip to the selected test.


**Stop** causes the Jammer to abort running the entire Test Suite and go to the Stopped state.

**Reset Link** (SAS and SATA only) causes the Jammer, at any time, to reset the link and enter OOB initialization. This does not affect any of the other buttons nor does it change the running state of the Jammer.



**Note:** Resetting the link disrupts the traffic passed through the Jammer. A warning message appears when you choose this action (Figure 48).

**Figure 48: Reset Warning**



**Log** indicates a log is available for viewing. Click **Log** to view the latest test log.

## Instant FEC Jam for 16G FC

When you open the Operation window for 16G FC, the window contains options to perform an instant FEC Jam on port A or port B. See Figure 47. You can select to invert a number (1-16) consecutive bits or use a bit mask to define which bits to invert at the beginning of the FEC block. Note that you cannot perform an instant FEC Jam when you are running a test suite.

# ***Chapter 3***

## Creating Jammer Test Configurations for Fibre Channel

**In this chapter:**

- [Defining Your Own Test Configurations](#)
- [Using the Jammer Configuration Window](#)
- [Configuring Arm and Trigger Conditions](#)
- [Configuring the Jam Definition](#)

## Defining Your Own Test Configurations

Xgig Jammer lets you define your own test configurations and save them with or without hardware available.

You can create a configuration from scratch, or you can open and edit an existing configuration. Also, you can edit a configuration in edit only mode, which is independent of any hardware, or you can edit a configuration that is currently loaded to a Jammer device.

To edit a configuration in edit only mode:

- >> Double-click on a configuration file in the Configuration manager.


Or:

- >> Right-click on the configuration in the Configuration manager and choose **Edit Jammer Configuration** from the context menu.

The edit only mode Jammer Configuration window opens (Figure 49).

This window allows you to set up your own Test Cases, name them, organize them, and save them to files so that you can use them again.


**Figure 49: Edit Only Jammer Configuration Window**



To start a configuration from scratch in edit only mode:

- >> Select **New Jammer Configuration** from the Configuration manager context menu or the File menu (Figure 50) on the Xgig Maestro menu bar.

**Figure 50: Maestro File Menu**



Or:

- >> Click the New Configuration icon  at the top of the Configuration manager.

Or:

- >> Right-click the configuration in the Configuration manager and choose **New Fibre Channel Jammer Configuration** from the context menu.

To save your configuration in edit only mode:

- >> Click **Save** at the bottom of the Jammer Configuration window or open the File menu at the top of the Jammer Configuration window and select **Save Configuration As...** or **Save Configuration**.

Any changes you make have no effect on actual Jammer devices you control.

To edit a configuration that is loaded to a Jammer port:

- >> Click **Configuration...** in the device column.

Or:

- >> Right-click in the Parameters Status table in the device column to open the context menu and select **Edit configuration**.

Or:

- >> Click **Operation** in the device column to open the Operation dialog, then click **Config**.

The Xgig Jammer Configuration window in hardware edit mode is displayed (Figure 51). This window allows you to set up your own Test Cases, name them, and save them to a file so that you can use them again.

Click **Apply** or **OK** and Jammer accepts the changes. They are immediately reflected in the Parameters Status table and affect the Jammer device the next time you run it.


To save your configuration edits:

- >> Open the File menu at the top of the Jammer Configuration window and select **Save Configuration As...** or **Save Configuration**.

Or:

- >> Right-click in the Parameters Status table in the device column to open the context menu and select **Save configuration file ...**

**Figure 51: Xgig Jammer Configuration Window**




## Using the Jammer Configuration Window

The Jammer Configuration window title bar indicates how many ports it is configuring, the protocol, and the configuration file name, if any. If you are using hardware edit mode, the chassis name, chassis number, slot number, and port number are also listed. The elements of the Jammer Configuration window are described in the following sections.

## Using the Jammer Test Suite Tools

The Test Suite lists the series of Xgig Jammer tests in the order in which you want them to execute. The suite includes one or more tests. The highlighted test appears as the Current Jammer Test on the upper right side of the window. Each test in the suite executes in sequence with a test reset time of approximately 130 (200 max) milliseconds.

## Repeat Test Suite



If you select **Repeat Test Suite**, the Jammer tests continuously run from the top of the Test Suite to the bottom and then loop back to the top until you click **Stop** on the Xgig Jammer Tab in Xgig Maestro.

## Creating a Test Suite

When you create a Test Suite you use the edit buttons at the top of the Test Suite window.

The edit button definitions for the Jammer Test Suite are:

<b>Cut</b>	Removes the highlighted test and holds its contents in the memory buffer.
<b>Copy</b>	Copies the highlighted test to the memory buffer.
<b>Paste</b>	Inserts the current memory buffer contents before the currently highlighted test.
<b>Add</b>	Adds a new blank test to the bottom of the suite.
<b>Insert</b>	Inserts a new blank test above the currently highlighted test.
<b>Delete</b>	Removes the highlighted test from the suite. If only one test is present, then the contents of this test are cleared.

To duplicate a test at another point in the Test Suite:

- 1 Highlight the test you want to duplicate.
- 2 Click **Copy**.
- 3 Highlight the test in the suite that is just after the point where you want the duplicate test inserted.
- 4 Click **Paste**.

The duplicate test is inserted.


Refer to “[Configuring Arm and Trigger Conditions](#)” on page 73 and “[Configuring the Jam Definition](#)” on page 77 for information about configuring each test.

## Using the Context Menu

The same operations (Cut, Copy, Paste, etc.) can be performed with the options available in the Context menu. In addition, the direction of an individual test can be reversed by selecting the ‘Reverse Current’ option. To reverse the direction of all tests, select the ‘Reverse All’ option.

## Using the Configuration File Menu

The File menu is the only menu on the menu bar (Figure 52).

**Figure 52: Configuration File Menu**

The choices are:

<b>Open Configuration</b>	Open a selected configuration file.
<b>Import to Selected Test</b>	Import a Test Case from a .tst file of an entire test suite, .tsk file, to the currently highlighted position.
<b>Export Selected Test</b>	Export and save the currently highlighted test to a .tst file.
<b>Save Configuration</b>	Save the entire Test Suite to the .tsk file you currently have loaded.
<b>Save Configuration As</b>	Save the entire Test Suite to a .tsk file with a name you assign to it.
<b>Close</b>	Close the Jammer Configuration Window.

The recently used FC Jammer configuration files appear in the file menu and are loaded when selected.



**Note:** The .tst files are only for storing individual Test Cases and swapping them between configuration files. You cannot load .tst files directly into a Jammer device on the Xgig Maestro window.


## Using the Current Jammer Test Window

The graphics in this section of the window represent the hardware configuration for the selected test in the Jammer Test Suite.

### Mode


Use Mode drop-down (Figure 53) near the top of the window to display a list of the possible configuration choices. In a duplex Jammer all path A and path B options are available. In a simplex Jammer, only path A is available. If you are editing a configuration without any associated Jammer ports, both paths are available.

The input to path A (on top) is always port A and the input to path B (on the bottom) is always port B. The external trigger input and output that are available on path A always are linked to the domain shown on the Xgig Maestro window as “Domain of port A.” The trigger input and output on the bottom on path B are in the “Domain of port B.”

**Figure 53: Mode Drop-down Menu**

The functions represented by the graphic are:

### Reverse

You can reverse the direction of the jam by selecting the Reverse button  .

### Arm

Use the Arm condition  to define the frame or Ordered Set to find prior to the frame or Ordered Set to be modified. You can also use an external trigger input to the Jammer.




**Note:** If you use an external trigger input to define the Arm condition, then you cannot select the external trigger output for that path in that Test Case, and vice versa. For information regarding using the external trigger input and output during a Test Case, refer to “[Using Domains and External Triggering](#)” on page 291.” However, you can use an external trigger in on port A with an external trigger out on port B, and vice versa.

### Trigger

The Trigger event  is the frame or Ordered Set to be modified. The Trigger event can be in the next word after the Arm event.

### Jam

The Jam definition  contains modifications to be made to the Trigger event. It is the same type (frame or Ordered Set) as the Trigger event.


### Rollback

The Rollback option  parameter defines the time or word count parameter between the Arm and Trigger events. If the Trigger does not follow the Arm event in the allotted time or word count, the Xgig Jammer begins looking for the Arm event again. Click **Rollback** to display the dialog box shown in Figure 54.



**Note:** This value is saved in terms of words, not time, so keep this in mind if you save a Test Case using a device running at 2.125 Gbps and later open the configuration on a Jammer running at 1.0625 Gbps.

**Figure 54: Rollback Condition Dialog**




**Timeout**

This **Timeout** option defines the period of time to wait for a specified test to complete before aborting and proceeding to the next test in the suite.

To set the timeout:

- 1 Click **Timeout** to display the dialog box in Figure 55.
- 2 Enter the hours, minutes, and seconds you want to wait.  
Use the check box to enable or disable this feature.

**Figure 55: Timeout Dialog**




- 3 Click **OK**.

**Repeat**

Click this option to repeat the **Arm > Trigger > Jam** sequence once, *n* times, or forever (Figure 56).


**Figure 56: Test Case Repeat Settings**



## Pause

Click **Pause** to open the dialog shown in Figure 57. The Pause setting allows you to insert a pause before the beginning of a test case.

**Figure 57: Pause Test Dialog**



## Trigger From Domain A (or B)

Click this option to arm when the domain associated with the port is triggered.

## Trigger Domain A (or B) upon Jam

Click this option to trigger a domain whenever the Trigger condition is met.

# Configuring Arm and Trigger Conditions

Arm and Trigger conditions recognize specific Ordered Sets or frames, depending on the protocol.

In Fibre Channel, you can specify any standard Ordered Set, or a user-defined Ordered Set (K28.5 followed by three data bytes). You can also use a frame as a condition, by specifying the SOF, the 6 word header, and up to the first 25 payload words.


You can save an arm or trigger condition as a `.jmt` file by clicking the **Save** button in the **Arm** or **Trigger** window. You can load a `.jmt` file by clicking the **Load** button in the **Arm** or **Trigger** window.

Depending on the Mode you select, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Jam event. If the Mode you select does not include an Arm condition, the Arm button remains disabled.

To set Arm and Trigger conditions:

- 1 For the Arm and/or Trigger, open the Type drop-down on the Current Jammer Test window and select Frame or Ordered Set.
- 2 Click on the **Arm** or **Trigger** button in the Xgig Jammer Configuration window.  
The window for the condition is displayed (Figure 58). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.
- 3 Set the values as required to specify a unique Arm and Trigger sequence for the specific test.  
The following sections describe the available values.

**Figure 58: Fibre Channel Arm and Trigger Windows for Frames**



### Setting Frame Conditions

You can specify frame conditions in two ways. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.


The condition is indicated on the right side of the window.

To manually specify a frame:

- >> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 59). In the hex view, partially defined hex characters appear as question marks:  
X001=?

**Figure 59: Binary Editor Dialog**

Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Highlight the folder and click the double left arrow button.

When you check the “Use inverse of condition specified (i.e. NOT)” option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Type selection, and on the main Xgig Maestro window.


### Setting Ordered Set Conditions

To set an Ordered Set condition, choose a value from the drop-down list. All legal Fibre Channel Ordered Sets are available as well as a User Defined selection at the bottom of the drop-down list as shown in Figure 60.

To edit the user-defined value:

>> Type a hex value into the byte field, or double-click on a byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character. You can also check the “Use inverse of condition specified (i.e. NOT)” option; this means the first word encountered that does not match what you have specified creates a “condition met” event.

**Figure 60: Fibre Channel Arm and Trigger Windows-Ordered Sets**

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Type selection and on the main Xgig Maestro window.

## Configuring the Jam Definition

The **Jam Definition** window defines how to modify the event specified on the **Trigger Condition** window.

The Jam is always the same type (frame or Ordered Set) as the Trigger.

For any Jam Definition, you can specify an optional name at the top of the window. This name is also displayed on the Jammer Configuration window under the Type selection and on the main Xgig Maestro window.


You can save a Jam definition as a .jmj file by clicking the **Save** button in the **Jam** window. You can load a .jmj file by clicking the **Load** button in the **Jam** window.

## Jamming an Ordered Set

If the Trigger Event is an Ordered Set, click the **Jam** button on the Xgig Jammer Configuration window, to open the Ordered Set Jam Definition window (Figure 61).

The Ordered Set Jam Definition window allows you to modify any Ordered Set by replacing it with a different Ordered Set, or by replacing it with a code violation. The code violation is a predefined 10-bit value that replaces the last 10 bits of the target Ordered Set in its 40-bit form. The control to edit the Ordered Set is similar to that in the Trigger Condition window.

**Figure 61: Fibre Channel Ordered Set Jam Definition Window**



For example, assume that the Trigger Event was a CLS, the Jam was set to replace it with an Idle and the repeat count was set to *forever*. This replaces every CLS in the link traffic with an Idle until you click **Stop** or the specified timeout occurs. Note that the number that you specify in the **Repeat** setting is the number of repetitions that occur including the first Jam. In addition, remember that if an Arm condition is specified, each repeat Jam requires the Arm and Trigger condition be met each time.

## Jamming a Frame


To define a Jam for a frame:

- 1 On the Configuration window, select one of the following from the Type drop-down menu for Jam:
  - Replace Frame with Modified Frame
  - Replace Frame with Truncated Frame
  - Replace Frame with Idles
  - Replace Frame with ARB(ff)
- 2 Click the **Jam** button to open the Frame Jam Definition Window.

### Jam Behavior

This controls the number of user-defined header/payload Jams performed relative to the target trigger frame. The **Jam Behavior** section is present on all tabs of the **Frame Jam Definition** window.

**Figure 62: Jam Behavior Selection**



- **Jam until end of trigger frame**

Jams defined in the Header and Payload tabs are performed until the end of the target trigger frame (or until an abnormal termination of the frame). All Jams defined that would take place on the original CRC or later are ignored. However, if the frame that is triggered on has more words than the Jams you specify, the remaining words are passed through. This is the standard way to Jam a frame, and is the way the GTX Jammer always Jams frames.

- **Execute full Jam pattern**

All Header and Payload Jams take place, even if they overwrite beyond the end of the target trigger frame. Use the control at the top of the Payload tab to define how many payload Jams should take place.

The last defined Jam is the last Payload Jam, unless there are no payload Jams defined then the sixth Header word is the last defined Jam. In any case, when you select this option, the options for modifying the CRC and EOF on the SOF/CRC/EOF tab are unavailable.

If the target trigger frame is longer than the number of Jams defined, then the portion of the target trigger frame that extends after the last defined Jam is overwritten with Idles. If the target trigger frame is shorter, then the Jammer switches back to pass-through immediately after the last defined Jam.



**Note:** Be careful when using this option because you may overwrite a portion of important traffic (a frame or Flow Control Ordered Sets).


## Replace Frame with Modified Frame

Each tab contains options relevant to different frame modifications.

### *Using the Global Tab*

Use this tab (Figure 63) to define Jam parameters that apply globally to the frame.

**Figure 63: Fibre Channel Global Tab**



### ***Global Replace Jam Option***

Use the Global Replace Jam Option to set specific bits in a word to 1 or 0 while passing through the remaining bits. You can apply this change globally to any word in the frame. Define one Global Replace Jam word for each Test Case.

To edit these bits:

>> Enter hex values, or double-click on a byte field to open the Binary Editor.

Any bits left as Xs are passed through.

### **Global Bit Errors**

The Jammer software can introduce bit errors repeatedly in sequential or random fashion to predefined fields. These bit errors are introduced to the 32-bit form of the target words (not the 40-bit form) so code violations are not created. The Global Bit Errors control allows you four options.

- Select **one bit for all fields** and **randomly**. This causes the Jammer to inject a single bit error in the group of all fields selected in the header or payload for a single Test Case. If the Jammer Test Suite is set to *loop*, then single bit errors are randomly injected into these fields, with one bit for each cycle of the Test Suite.
- Select **one bit for all fields** and **sequentially**. This also injects a single bit error in the group of all fields selected in the header or payload. If the Test Suite is set to loop forever, the bit error walks through all the selected fields.
- Select **one bit in each field** and **randomly** does the same thing as the first option; however, there will be one error for each word selected in the header or payload.
- Select **one bit in each field** and **sequentially** does the same thing as the second option; however, there will be one error for each word selected in the header or payload.

### **LRC Options**

This option is only available for Fibre Channel. The FICON protocol uses an LRC which is a special checksum located in the eighth payload word. This option controls what happens to that payload word during the Jam, as well as, for any other words that qualify as being an LRC (that is, if you select Replace Jams with SOFs, then the fourteenth word after each SOF is an LRC word).

- Pass through LRC unchanged

Whatever word is present in an LRC word is passed through regardless of what you have defined on the Payload tab for that word.

- Recalculate correct LRC

An LRC is calculated and placed wherever an LRC word occurs. The LRC only functions correctly in valid frames (SOF followed by at least 14 data words).

- Replace LRC with this


LRC words are all replaced with this new word, regardless of what you have defined on the Payload tab for that word.

- Disable LRC

The Jams defined on the Payload tab take place with no special cases for LRC words.

### **Using the SOF/CRC/EOF Tab for Fibre Channel**

Use the choices on this tab to modify the Start of Frame (SOF), Cyclic Redundancy Check (CRC), and End of Frame (EOF) words of the original target frame (Figure 64).

**Figure 64: Fibre Channel SOF/CRC/EOF Tab**

### ***Modifying SOF/EOF***

You can replace the start and end of frame characters with another SOF, EOF, or other Ordered Set. For example, you can change SOFn3 to an SOFi3, which changes a frame from a sequence member to the start of a new sequence.

### ***CRC Options***

CRC options include:


- Pass through CRC unchanged - Not changing the CRC in the original target frame
- Recalculate correct CRC - Recalculating the CRC to make it correct for the modified data
- Replace CRC with this - Replacing with a user-specified data word or Ordered Set

Depending on the changes made to a frame, the old CRC might be invalid. If the CRC is passed through, an invalid Fibre Channel frame might be created. The lowest layer of Fibre Channel error checking should recognize this type of error. The normal system response is to terminate the exchange and start over. If the frame is modified and the CRC is recalculated, a valid frame with modified data is created. If, for example, the modifications are made to SCSI commands embedded in the payload, the SCSI error checking routines should trap and handle the error.

### Using the Header/Payload Tab for Fibre Channel

Any parameter in the Fibre Channel header can be modified (Figure 65). Select either the **Replace Jam** or **All Jam Modes** radio button to define the Jam frame.

Figure 65: Fibre Channel Header/Payload Tab



Similar to defining an Arm or Trigger Condition, there are two ways to specify your frame Jam Definition. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Highlight a template in the Template Library tree on the left side of the window.
- 2 Click the double right arrow to display the Jam definition on the right side of the window.

When you use a template, the Jam definition is populated with Replace Jams of the specified data, while all other bits are passed through.


Notice the special choice at the bottom left, “Current Trigger.” This is a copy of the frame condition you have specified for the Trigger. Click the double right arrow to use this.

When you use a template, the Jam definition is populated with Replace Jams of the specified data, while all other bits are passed through.

To manually edit the values, enter a value into the byte field. An **X** in a nibble passes the original value through.

Select the **Replace 8b Jam Mode** radio button to open a dialog that allows you to replace an entire frame either by using a template or manually entering values. The Replace 8b Jam Mode dialog also contains a view of the frame contents, similar to those seen the Arm and Trigger Condition windows. These values correspond to the hex values defined in the center column.

**Figure 66: Replace 8b Jam Mode**



Select the **All Jam Modes** radio button opens a dialog that provides the following choices for each word in a frame on the Header/Payload tab:

- **Replace 8b Jam** - This function allows you to replace each nibble with a new value. Choose between a standard Ordered Set or a user-defined Ordered Set or data word. For user-defined values, you can specify a value for each nibble.
- **Apply Global Replace Jam** - This function allows individual bits to be set to 1, set to 0 or passed through unchanged according to the Global Replace Jam defined on the Global Tab.
- **Insert Code Violation Jam** - Introduce a pre-defined, fixed code violation to the current word.
- **Invert Jam** - Invert defined bits and pass through the rest. Enter 1s at the appropriate bit locations.
- **Pass Through Jam** - Pass through the current word unchanged.
- **Replace Jam with CRC** - This word contains the current CRC value. CRC calculation is reset and started at the word after any SOF. Note that there should be only valid data words between an SOF and its partner automatic CRC insertion or else the CRC value will be incorrect. Violations of this rule include using Ordered Sets or inserting code violations.

- **Set Bits To 0s Jam-** Set defined bits to 0s and pass through the rest. Enter 0s at the appropriate bit locations.
- **Set Bits To 1s Jam -** Set defined bits to 1s and pass through the rest. Enter 1s at the appropriate bit locations.
- **Apply Global Bit Error Jam -** Apply the Global Bit Error function set on the Global tab. Enter 1s at the appropriate bit locations.

You can modify any and all words in the payload. Decide what portion of the payload you want to modify. The larger the portion of the payload that is selected, the longer the time between Test Cases in the suite. Switching from one Test Case to the next is a software operation, so the time between cases will be on the order of hundreds of milliseconds.

Use the **Number of payload words** counter to define the number of payload Jams (Figure 67). Use the scroll bar to position the display to the desired word.

**Figure 67: Selecting Frame Jam Size**



The drop-down menus are the same as those found on the Header words. See page 83.



**Note:** If you place an SOF in header word 2, and an automatic CRC in payload word 10, the CRC is calculated over header words 3 to 6 and continues with payload words 1 to 9.

You can also use the List View controls at the top to cut, copy, paste, add, insert, or delete words.


Similar to defining an Arm or Trigger Condition, there are two ways to specify your frame Jam Definition. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Highlight a template in the Template Library tree on the left side of the window.
- 2 Click the double right arrow to display the Jam definition on the right side of the window.

Notice the special choice at the bottom left, Current Trigger (Figure 68). This is a copy of the frame condition you have specified for the Trigger. The name of the Trigger Condition (if any) is shown in parenthesis. Click the double right arrow to use this.

**Figure 68: Current Trigger Option**



When you use a template, the Jam definition is populated with Replace Jams of the specified data, while all other bits are passed through.

To manually specify a frame word Jam, select a Jam Type from the drop-down menu (under the Type column), then specify any additional definition (if necessary) by clicking on the data field (under the Description column).

## Replace Frame with Truncated Frame


This option truncates the target frame to a shorter length and sends Idles on top of the remainder of the target frame.

To replace a frame with a truncated frame:

- >> Use the up and down arrow buttons or type the number of words you want to truncate the frame to (including header and payload, not including SOF, CRC, and EOF).

The CRC is automatically recalculated. If the target frame is already shorter than the specified truncation length, no truncation occurs. In any case, the EOF is always replaced with the new EOF you select from the drop-down menu.

**Figure 69: Fibre Channel - Replace Frame with Truncated Frame**



## Replace Frame with Idles

This option replaces the target frame with Idles.

## Replace Frame with ARB(ff)

This option replaces the target frame with ARB(ff).

# ***Chapter 4***

## Creating Jammer Test Configurations for Gigabit Ethernet

### **In this chapter:**

- [Defining Your Own Test Configurations](#)
- [Using the Jammer Configuration Window](#)
- [Configuring Arm and Trigger Conditions for Gigabit Ethernet](#)
- [Configuring the Jam Definition for Gigabit Ethernet](#)

---

## Defining Your Own Test Configurations

Xgig Jammer lets you define your own test configurations and save them with or without hardware available.

You can create a configuration from scratch, or you can open and edit an existing configuration. Also, you can edit a configuration in edit only mode, which is independent of any hardware, or you can edit a configuration that is currently loaded to a Jammer device.

To edit a configuration in edit only mode:

>> Double-click on a configuration file in the Configuration manager.

Or:

>> Right-click on the configuration in the Configuration manager and choose **Edit Jammer Configuration** from the context menu.


>> Or:

>> Right-click the configuration file in the Configuration manager to open the context menu, and select **Edit Configuration**.

The edit only mode Jammer Configuration window opens (Figure 70).

This window allows you to set up your own Test Cases, name them, organize them, and save them to files so that you can use them again.

**Figure 70: Edit Only Jammer Configuration window**




To start a configuration from scratch in edit only mode:

- >> Select **New Jammer Configuration** from the context menu or the File menu (Figure 71) on the Xgig Maestro menu bar.

Or:

- >> Click the New Configuration icon at the top of the Configuration manager.

**Figure 71: Maestro File Menu**



To save your configuration in edit only mode:

- >> Click **Save** at the bottom of the Jammer Configuration window or open the File menu on the Jammer Configuration window and select **Save Configuration** or **Save Configuration As**.

Any changes you make have no effect on actual Jammer devices you control.

To edit a configuration that is loaded to a Jammer port:

- >> Click **Configuration...** in the device column.

Or:

- >> Right-click in the Parameters Status table in the device column to open the context menu and select **Edit configuration**.

Or:


- >> Click **Operation** in the device column to open the Operation dialog, then click **Config**.

The Xgig Jammer Configuration window in hardware edit mode is displayed (Figure 72). This window allows you to set up your own Test Cases, name them, and save them to a file so that you can use them again.

Click **Apply** or **OK** and Jammer accepts the changes. They are immediately reflected in the Parameters Status table and affect the Jammer device the next time you run it.

To save your configuration edits:

- >> Open the File menu at the top of the Jammer Configuration window and select **Save Configuration As...** or **Save Configuration**.

**Figure 72: Xgig Jammer Configuration Window**

## Using the Jammer Configuration Window

The Jammer Configuration window title bar indicates how many ports it is configuring, the protocol, and the configuration file name, if any. If you are using hardware edit mode, the chassis name, chassis number, slot number, and port number are also listed. The elements of the Jammer Configuration window are described in the following sections.


## Using the Jammer Test Suite Tools

The Test Suite lists the series of Xgig Jammer tests in the order in which you want them to execute. The suite includes one or more tests. The highlighted test appears as the Current Jammer Test on the upper right side of the window. Each test in the suite executes in sequence with a test reset time of approximately 130 (200 max) milliseconds.

### Creating a Test Suite

When you create a Gigabit Ethernet Jammer Test Suite, you use the toolbar in the Jammer Test Suite section of the Configuration window (Figure 73).

**Figure 73: 10GigE Jammer Test Suite Toolbar**



The following list describes the icons on the toolbar:

	Cut current test	Removes the highlighted test and holds its contents in the memory buffer.
	Copy current text	Copies the highlighted test to the memory buffer.
	Paste last test cut or copied	Inserts the current memory buffer contents before the currently highlighted test.
	Add new test to bottom of stack	Adds a new blank test to the bottom of the suite.
	Insert new test before current test	Inserts a new blank test above the currently highlighted test.
	Delete current test	Removes the highlighted test from the suite. If only one test is present, then the contents of this test are cleared.
	Move current test down the stack	Moves the highlighted test down one in the test order.
	Move current test up the stack	Moves the highlighted test up one in the test order.
	Toggle view	Toggles Test Suite between Card View and List View.
	Run test suite once or Repeat test suite	When you choose Repeat test suite, the tests run according the settings you define in the Jammer Current Test window.

To duplicate a test at another point in the Test Suite:

- 1 Highlight the test you want to duplicate.
- 2 Click **Copy**.
- 3 Highlight the test in the suite that is just after the point where you want the duplicate test inserted.
- 4 Click **Paste**.


The duplicate test is inserted.

Refer to “Configuring Arm and Trigger Conditions for Gigabit Ethernet” and “Configuring the Jam Definition for Gigabit Ethernet” for information about configuring each test.

## Using the Configuration File Menu

The File menu is the only menu on the menu bar (Figure 74).

**Figure 74: Configuration File Menu**



The choices are:

<b>Open Configuration</b>	Open an existing <code>.tsk</code> configuration file.
<b>Import to Selected Test</b>	Import a Test Case from a <code>.tst</code> file or an entire test suite, <code>.tsk</code> file, to the currently highlighted position. A Test Case is one line in the Jammer Test Suite.
<b>Export Selected Test</b>	Export and save the currently highlighted test to a <code>.tst</code> file.
<b>Save Configuration</b>	Save the entire Test Suite to the <code>.tsk</code> file you currently have loaded.
<b>Save Configuration As</b>	Save the entire Test Suite to a <code>.tsk</code> file with a name you assign to it.
<b>Close</b>	Close the Jammer Configuration Window.

The recently used Gigabit Ethernet Jammer configuration files appear in the file menu and are loaded when selected.

## Using the Current Jammer Test Window



**Note:** The `.tst` files are only for storing individual Test Cases and swapping them between configuration files. You cannot load `.tst` files directly into a Jammer device on the Xgig Maestro window.


The graphics in this section of the window represent the hardware configuration for the selected test in the Jammer Test Suite.

### Mode


For 10GigE, Mode menus are available near the top of the Current Jammer Test window (Figure 75) and also near the top of each Test Case in the Jammer Test Suite window (Figure 76).

The input to path A (on top) is always port A and the input to path B (on the bottom) is always port B. The external trigger input and output that is available on path A always are linked to the domain shown on the Xgig Maestro window as “Domain of port A.” The trigger input and output on the bottom on path B are in the “Domain of port B.”

**Figure 75: Mode Drop-down Menu in Current Jammer Test - Right Pane**



**Figure 76: Mode Drop-down Menu in Test Suite - Left Pane**



## Reverse

You can reverse the direction of the jam by selecting the **Reverse** button.

## Arm and Trigger

To define Arm and Trigger conditions, select a respective Type from each drop-down menu. Then click the Arm or Trigger button to open the corresponding definition window.

You can use an external input as an Arm condition. Check Trigger from Domain A (or B) to enable this feature. You must put the corresponding Jammer port into a domain for this to work properly.

The Trigger event can be in the next Dword after the Arm event in the traffic stream.

## Jam

To define a Jam:

- 1 Select a Type from the drop-down menu, if available.
- 2 Click the Jam button to open the Jam Definition window.

The Jam Definition specifies the modifications to be made to the traffic matching the Trigger Condition.

In addition, the Jammer port can trigger out to the Domain it is in when a Jam takes place. Check Trigger Domain A (or B) upon Jam to enable this feature.



**Note:** If you use an external trigger input to define the Arm condition, then you cannot select the external trigger output for that path in that Test Case, and vice versa. For information regarding using the trigger input and output during a Test Case, refer to “Using Domains and External Triggering” on page 291. However, you can use an external trigger in on port A with an external trigger out on port B, and vice versa. Figure 77 shows an example.

**Figure 77: Trigger In and Trigger Out**

Current Jammer Test : 1st of 1 test

Name : Create bit error on TCP sequence number

Mode : Arm on A, then Trigger + Jam on B Reverse

**Arm**

Type : Frame  Trigger from Domain A

Name : Any Ethemet Define : Arm A...

**Trigger**

Type : Frame

Name : Trigger on any TCP Frame Define : Trigger B...

**Jam**

Type : Replace Frame with Modified Frame  Trigger Domain B upon Jam

Name : Create bit error on TCP seq num Define : Jam B...

O  
n  
c  
e

Rollback

Repeat : Arm -> Trigger -> Jam once (Don't repeat the Test Case)

Timeout : No timeout

Pause : No pause


## Rollback

The Rollback option defines the time or Dword count parameter between the Arm and Trigger events. If the Trigger does not follow the Arm event in the allotted time or Dword count, the Jammer begins looking for the Arm event again. Click **Rollback** to display the dialog shown in Figure 78.



**Note:** This value is saved in terms of Dwords, not time, so keep this in mind if you save a Test Case using a device running at 3.0 Gbps and later open the configuration on a Jammer running at 1.5 Gbps.

**Figure 78: Rollback Condition Dialog**




## Timeout

The timeout option defines the period of time to wait for a specified test to complete before aborting and proceeding to the next test in the suite.

To set the timeout:

- 1 Click **Timeout** to display the dialog box in Figure 79.
- 2 Check **Enable Timeout**.
- 3 Enter the hours, minutes, and seconds you want to wait.


**Figure 79: Timeout Dialog**



- 4 Click **OK**.


## Repeat

Click **Repeat** to open the dialog shown in Figure 80. The Repeat Mode setting allows you to configure what is repeated when using an Arm condition. The first option means the Jammer will match the Arm condition once, then will repeat matching the Trigger condition as specified by the Repeat Count setting below. The second Repeat Mode option means that the Jammer must match the Arm condition each time before looking for a Trigger.

**Figure 80: Repeat Test Dialog**


## Pause

Click **Pause** to open the dialog shown in Figure 81. The Pause setting allows you to insert a pause before the beginning of a test case.

**Figure 81: Pause Test Dialog**

You can also configure options for each Test Case directly in the Test Suite, instead of clicking in the Current Jammer Test pane. Click on the area of the Test Case you want to modify to open the corresponding dialog (Figure 82).

Figure 82: Configuring Options Directly in the Test Suite



---

## Configuring Arm and Trigger Conditions for Gigabit Ethernet

Arm and Trigger conditions recognize specific Ordered Sets or frames, depending on the protocol.

In Gigabit Ethernet, you can specify any standard Ordered Set or any user-defined one or two bytes of K/D characters (of which standard Ordered Sets are a subset). You can also use a frame, for which you can specify the Gigabit Ethernet header and up to 114 bytes of payload.


You can save an arm or trigger condition as a `.jmt` file by clicking the **Save** button in the **Arm** or **Trigger** window. You can load a `.jmt` file by clicking the **Load** button in the **Arm** or **Trigger** window.

Depending on the Mode you select, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Jam event. If the Mode you select does not include an Arm condition, the Arm button remains disabled.

To set Arm and Trigger conditions:

- 1 Click on the **Arm** or **Trigger** button in the Xgig Jammer Configuration window.  
The window for the condition is displayed (Figure 83). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.
- 2 Open the Type drop-down in the Arm or Trigger Condition window and select Frame or Ordered Set.
- 3 Set the values as required to specify a unique Arm and Trigger sequence for the specific test.  
The following sections describe the available values.

**Figure 83: Gigabit Ethernet Arm and Trigger Windows for Frames**



## Setting Frame Conditions

You can specify frame conditions in two ways. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:

- >> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 84). In the hex view, partially defined hex characters appear as question marks:

X001=?

**Figure 84: Binary Editor Dialog**

Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Highlight the folder and click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Setting Ordered Set Conditions

To arm or trigger on an Ordered Set:

- 1 Click on the Arm or Trigger button in the Jammer Configuration window.
- 2 Open the Type drop-down in the Arm or Trigger Condition window and select Ordered Set.
- 3 Set the values as required to specify a unique Arm and Trigger sequence for the specific test.

You can choose from any standard Ordered Set or choose user-defined (Figure 85). All choices are either one byte or two bytes. A user-defined condition can use any K/D character(s).

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.


As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

You can also click on the K/D character display (for example, 16.2) to open drop down menus of possible values from which you can select. A period separates the two values. Click the K or D to toggle the Control Characters setting.



**Note:** In Gigabit Ethernet, if you choose a one byte Ordered Set Trigger condition, then the Jam definition must be one byte. If you choose a two byte Ordered Set, then the Jam must be two bytes.

**Figure 85: Gigabit Ethernet Arm and Trigger Windows-Ordered Sets**



**Note:** Two byte Ordered Set conditions are only met when aligned to the normal 16-bit boundary (in alignment with the I2 Ordered Sets). For example, if you specify a condition of 50-K28.5, hoping that the condition would be met by two I2 (K28.5-50-K28.5-50), this condition would not be met.

As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.

## Configuring the Jam Definition for Gigabit Ethernet

The **Jam Definition** window defines how to modify the event specified on the **Trigger Condition** window.

The Jam is always the same type (frame or Ordered Set) as the Trigger.

For any Jam Definition, you can specify an optional name at the top of the window. This name is also displayed on the Jammer Configuration window under Mode selection and on the main Xgig Maestro window.


You can save a Jam definition as a `.jnj` file by clicking the **Save** button in the **Jam** window. You can load a `.jnj` file by clicking the **Load** button in the **Jam** window.

### Jamming an Ordered Set

If the Trigger Event is an Ordered Set, click the **Jam** button on the Xgig Jammer Configuration window, to open the Ordered Set Jam Definition window (Figure 86).

The Ordered Set Jam Definition window allows you to modify any Ordered Set by replacing it with a different Ordered Set, or by replacing it with a code violation. The code violation is a predefined 10-bit value that replaces the last 10 bits of the target Ordered Set in its 40-bit form. The control to edit the Ordered Set is similar to that in the Trigger Condition window.

**Figure 86: Gigabit Ethernet Ordered Set Jam Definition Window**



For example, assume that the Trigger Event was an I1, the Jam was set to replace it with an I2 and the repeat count was set to *forever*. This replaces every I1 in the link traffic with an I2 until you click **Stop** or the specified timeout occurs. Note that the number that you specify in the **Repeat** setting is the number of repetitions that occur including the first Jam. In addition, remember that if an Arm condition is specified, each repeat Jam requires the Arm and Trigger condition be met each time. An exception is in Gigabit Ethernet: if the Trigger condition is met more than once in a 32-bit word, then the Jam occurs multiple times in that same word, and then begins looking for the Arm condition, again, on the next word.

## Jamming a Frame

To define a Jam for a frame:

- 1 Click the Jam button on the Xgig Jammer Configuration window to open the Frame Jam Definition window (Figure 87).
- 2 Under the Jam Type drop-down, choose to:
  - Modify traffic
  - Truncate a frame
  - Replace the frame with Idles (I2)

The following paragraphs describe these choices.

### Replace Frame with Modified Frame

Each tab contains options relevant to different frame modifications.

#### *Using the Global Tab*

Use this tab (Figure 87) to define Jam parameters that apply globally to the frame.

#### **Global Match/Mask Option**


Use the Global Match/Mask word to set specific bits in a word to 1 or 0 while passing through the remaining bits. You can apply this global mask to any word in the frame. Define one Global Match/Mask for each Test Case.

To edit these bits:

>> Enter hex values, or double-click on a byte field to open the Binary Editor.

Any bits left as Xs are passed through.

**Figure 87: Gigabit Ethernet Global Tab**



### Global Bit Errors


The Jammer software can introduce bit errors repeatedly in sequential or random fashion to predefined fields. These bit errors are introduced to the 32-bit form of the target words (not the 40-bit form) so code violations are not created. The Global Bit Errors control allows you four options.

- Select **one bit for all fields** and **randomly**. This causes the Jammer to inject a single bit error in the group of all fields selected in the header or payload for a single Test Case. If the Jammer Test Suite is set to *loop*, then single bit errors are randomly injected into these fields, with one bit for each cycle of the Test Suite.
- Select **one bit for all fields** and **sequentially**. This also injects a single bit error in the group of all fields selected in the header or payload. If the Test Suite is set to loop forever, the bit error walks through all the selected fields.
- Select **one bit in each field** and **randomly** does the same thing as the first option; however, there will be one error for each word selected in the payload or header.
- Select **one bit in each field** and **sequentially** does the same thing as the second option; however, there will be one error for each word selected in the payload or header.

### Using the Delimiters/CRC Tab for Gigabit Ethernet

Use the choices on this tab to modify the Start of Packet (SOP), Start Frame Delimiter (SFD), CRC, End of Packet (EOP), and Carrier Extend(s) of the original frame (Figure 88).

**Figure 88: Gigabit Ethernet Delimiters/CRC Tab**



**Modifying SOP/SFD/EOP/ Carrier Extend(s)**

To modify any of these special characters in the target trigger frame:


- 1 Check the appropriate box to select replacement.
- 2 Open the drop-down menu and choose a standard Gigabit Ethernet Ordered Set, or select User-defined.

If you choose User-defined, you can specify any value.

To edit the value enter a hex value into the byte field or double-click to display the Binary Editor.

You can also click on the K/D character display (for example, 16.2) to open drop-down menus of possible values from which you can select (Figure 89). A separator (a period) distinguishes the two values. Click the K or D to toggle the Control Character setting.

**Figure 89: K/D Character Value Drop-down Menus**



**CRC Options**


The CRC options include:

- Not changing the CRC in the original target frame
- Recalculating the CRC to make it correct for the modified data
- Replacing with a user-specified data word

## Using the Header/Payload Tab for Gigabit Ethernet

You can modify any parameter or word on the Gigabit Ethernet Header/Payload Tab (Figure 90).

**Figure 90: Gigabit Ethernet Header/Payload Tab**



The Gigabit Ethernet window always shows Jam definitions for the header and 4096 payload words (for the maximum supported 16 Kilobyte jumbo frames). If the frame that is Jammed has less than 4096 payload words, the extra Jam definitions do not take effect. The Jammer does not support Gigabit Ethernet frames larger than 4096 payload words.

Notice the first line of the Jam Definition (Ether 0001) has only the first two bytes of the Destination Address header field. This is to visually orient the frame in the same manner as the Arm and Trigger Condition windows.

Similar to defining an Arm or Trigger Condition, there are two ways to specify your frame Jam Definition. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Highlight a template in the Template Library tree on the left side of the window.
- 2 Click the double right arrow to display the Jam definition on the right side of the window.


Notice the special choice at the bottom left, “Current Trigger.” This is a copy of the frame condition you have specified for the Trigger. Click the double right arrow to use this.

When you use a template, the Jam definition is populated with Replace Jams of the specified data, while all other bits are passed through.

To manually edit the values, enter a value into the byte field. An **X** in a nibble passes the original value through.

Select the **Replace 8b Jam Mode** radio button to open a dialog that allows you to replace an entire frame either by using a template or manually entering values. The Replace 8b Jam Mode dialog also contains a view of the frame contents, similar to those seen the Arm and Trigger Condition windows. These values correspond to the hex values defined in the center column.

**Figure 91: Replace 8b Jam Mode**



Selecting the **All Jam Modes** radio button opens a dialog that provides the following choices for each word in a frame on the Header/Payload tab:


- **Apply Global Match Mask Jam** - This function allows individual bits to be set to 1, set to 0 or passed through unchanged according to the Global Match/Mask defined on the Global tab.
- **Invert Jam** - Invert defined bits and pass through the rest. Enter 1s at the appropriate bit locations.
- **Pass Through Jam** - Pass through the current word unchanged.

- **Replace 8b Jam** - Replace nibbles with new values. Each drop-down represents a byte so you can replace a byte with a standard Ordered Set. If you choose User-defined, you can specify any K/D character. To edit these values, enter a value into the byte field or double-click to display the Binary Editor. If you specify a bit as a 0 or 1, you must specify the values of the other three bits in that nibble also. Any nibbles with an X are passed through.
- **Set Bits To 0s Jam** - Set defined bits to 0s and pass through the rest. Enter 0s at the appropriate bit locations.
- **Set Bits To 1s Jam** - Set defined bits to 1s and pass through the rest. Enter 1s at the appropriate bit locations.
- **Apply Global Bit Error Jam** - Apply the Global Bit Error function set on the Global tab.
- **Insert Code Violation Jam** - Introduce a predefined, fixed code violation to a byte in that word. Which byte is corrupted depends on the alignment orientation of the frame. The Jam Definition of the word before a Code Violation Jam must always be a Pass Through Jam. A Code Violation Jam cannot be placed in the first word of a frame (Ether 0001).

### Using the Embedded Protocol(s) Tab for Gigabit Ethernet

Figure 92 shows the Embedded Protocol(s) tab for Gigabit Ethernet. The available functions are described in this section.

**Figure 92: Gigabit Ethernet Embedded Protocol(s) Tab**



#### Recalculate Checksum

Select the check boxes to choose recalculation of IP and TCP checksums.

#### Recalculate IP checksum for valid IP embedded frames

Checking this option replaces the IP checksum in the Jammed frame with a recalculated value. For the checksum to be inserted properly, the frame, after Jamming takes place, must have a Gigabit Ethernet header EtherType field value of 0x0800 and a valid IP header IHL field.

**Recalculate TCP checksum for valid TCP embedded frames**

Checking this option replaces the TCP checksum in the Jammed frame with a recalculated value. For the checksum to be inserted properly, the frame, after Jamming takes place, must meet the same requirements as those listed for the IP checksum, and, in addition, have an accurate IP header Total Length field, an IP header IP Protocol field value of 0x06, and a valid TCP header Data Offset field.

Also, the Jumbo Frames setting (see “GigE Jumbo Frames” on page 25) must be correct for the TCP checksum insertion to work. If the Jammed frame is “normal size” (1500 Gigabit Ethernet payload bytes or less) then either setting is correct. If the Jammed frame is a jumbo frame (16 KB Gigabit Ethernet payload bytes or less), then you must select the jumbo setting. The Jammer does not support recalculating the TCP checksum for larger frames.


The TCP checksum recalculation is not available when using the Repeat Jam feature.

**Replace Frame with Truncated Frame**

This option truncates the target frame to a shorter length and sends Idles (I2) on top of the remainder of the target frame.

In the Truncate Frame Options window:

- 1 Choose the type of payload you want to truncate from the drop-down menu:
  - Gigabit Ethernet
  - IP
  - TCP
- 2 Enter the number of bytes you want the payload to be truncated to (this does not include the CRC or other delimiters).

**Figure 93: Replacing a Frame with a Truncated Frame**

### ***Gigabit Ethernet Payload***

For a Gigabit Ethernet payload, the New Payload Size setting specifies how many bytes to leave after the Gigabit Ethernet header (the first 14 bytes of the frame). For normal sized frame support, you can specify from 0 to 1500 bytes, and for jumbo sized frame support, you can specify from 0 to 16383 bytes. If the target frame is shorter than the specified number of bytes, then no Jamming occurs.

### ***IP Payload***

For an IP payload, the New Payload Size setting specifies how many bytes to leave after the IP header. For normal sized frame support you can specify from 0 to 1480 bytes, and for jumbo sized frame support, you can specify from 0 to 16364 bytes. You also have the option to replace the IP checksum with a recalculated value, which also automatically updates the IP header Total Length field.

For the truncation or the IP checksum option to work properly, there are some requirements of the incoming target frame. The frame must have a Gigabit Ethernet header EtherType field value of 0x0800, a valid IP header IHL field, and a valid IP header Total Length field. If the Jammed frame is shorter than the specified number of bytes, then no truncation occurs, but the IP checksum can be recalculated if you select it.

### ***TCP Payload***

For a TCP payload, the New Payload Size setting specifies how many bytes to leave after the TCP header. For normal sized frame support you can specify from 0 to 1460 bytes, and for jumbo sized frame support you can specify from 0 to 16344 bytes. You also have the options to replace the IP and/or TCP checksums with recalculated values (either option also automatically updates the IP header Total Length field).

For the truncation to occur and for the checksum options to work, the incoming target frame must meet the same requirements listed earlier for IP payload truncation, and, in addition, have an IP header IP Protocol field value of 0x06 and a valid TCP header Data Offset field. If the Jammed frame is shorter than the specified number of bytes, then no truncation occurs, but the checksums can be recalculated if you select them.


In addition, TCP checksum recalculation is not available when using the Repeat Jam feature.

For any successful truncation, the Gigabit Ethernet CRC is automatically replaced with a recalculated value.

### Replace Frame with Idles

This option replaces the target frame with I2 Ordered Sets in the Gigabit Ethernet Jammer.

**Figure 94: Gigabit Ethernet - Replace Frame with Idles**



# ***Chapter 5***

## **Creating Jammer Test Configurations for SAS and SATA/STP**

### **In this chapter:**

- [Defining Your Own SAS and SATA/STP Test Configurations](#)
- [Using the Jammer Configuration Window](#)
- [Configuring SAS Arm and Trigger Conditions](#)
- [Configuring the SAS Jam Definition](#)
- [Configuring SATA/STP Arm and Trigger Conditions](#)
- [Configuring the SATA/STP Jam Definition](#)

## Defining Your Own SAS and SATA/STP Test Configurations

Xgig Jammer lets you define your own test configurations and save them with or without hardware available.

You can create a configuration from scratch, or you can open and edit an existing configuration. Also, you can edit a configuration in edit only mode, which is independent of any hardware, or you can edit a configuration that is currently loaded to a Jammer device.

To edit a configuration in edit only mode:

>> Double-click on a configuration file in the Configuration manager.

Or:

>> Right-click on the configuration in the Configuration manager and choose **Edit Jammer Configuration** from the context menu.

The edit only mode Jammer Configuration window opens.

This window allows you to set up your own Test Cases, name them, organize them, and save them to files so that you can use them again.


To start a configuration from scratch in edit only mode:

>> Select **New Jammer Configuration** from the context menu or the File menu (Figure 95) on the Xgig Maestro menu bar.

Or:

>> Click the New Configuration icon at the top of the Configuration manager with the appropriate protocol selected next to it.

**Figure 95: Maestro File Menu**



To save your configuration in edit only mode:

>> Click **Save** at the bottom of the Jammer Configuration window or open the File menu on the Jammer Configuration window and select **Save Configuration** or **Save Configuration As**.

Any changes you make have no effect on actual Jammer devices you control.

To edit a configuration that is loaded to a Jammer port:

>> Click **Configuration...** in the device column on the Parameters Status table.

Or:

>> Right-click in the Parameters Status table in the device column to open the context menu and select **Edit configuration**.

Or:

>> Highlight the configuration file in the Configuration manager, open the context menu, and select **Edit Configuration**.

Or:

>> Click **Operation** in the device column to open the Operation dialog, then click **Config**.


The Xgig Jammer Configuration window in hardware edit mode is displayed (Figure 96). This window allows you to set up your own Test Cases, name them, and save them to a file so that you can use them again.

Click **Apply** or **OK** and Jammer accepts the changes. They are immediately reflected in the Parameters Status table and affect the Jammer device the next time you run it.

To save your configuration edits:

>> Open the File menu at the top of the Jammer Configuration window and select **Save Configuration As...** or **Save Configuration**.

**Figure 96: Xgig SAS and SATA/STP Jammer Configuration Window**



## Using the Jammer Configuration Window


The Jammer Configuration window title bar indicates how many ports it is configuring, the protocol, and the configuration file name, if any. If you are using hardware edit mode, the chassis name, chassis number, slot number, and port numbers are also listed. The components of the Jammer Configuration window are described in the following sections.

### Using the Jammer Test Suite Tools

The Test Suite, the pane on the left side of the configuration window, lists the series of Xgig Jammer tests in the order in which you want them to execute (Figure 97). The suite includes one or more tests. The highlighted test appears as the Current Jammer Test on the right side of the window. Each test in the suite executes in sequence with a set up time from the end of one test to the start of the next of approximately 130 (200 max) milliseconds.

**Figure 97: SAS/SATA Jammer Test Suite Windows**

#### Card View




### List View

	Name	Mode	Arm	Trigger	Jam	Repeat	Timeout (hr:min:s)	Pause (min:sec)
1	Expander Test Ca	Arm on B, then Tri	SAS Frame	SAS Frame	Replace Frame wi	Arm -> Trigger ->	No timeout	No pause
2	Expander Test Ca	Trigger + Jam on B		SAS Frame	Replace Frame wi	Trigger -> Jam on	No timeout	No pause
3	Expander Test Ca	Arm on A, then Tri	SAS Frame	SAS Frame	Replace Frame wi	Arm -> Trigger ->	No timeout	No pause

### Using the SAS/SATA Jammer Test Suite Toolbar

When you create a SAS/SATA Jammer Test Suite, you use the toolbar in the Jammer Test Suite section of the Configuration window (Figure 98).

Figure 98: SAS/SATA Jammer Test Suite Toolbar



The following list describes the icons on the toolbar:

- 
Cut current test
Removes the highlighted test and holds its contents in the memory buffer.
- 
Copy current text
Copies the highlighted test to the memory buffer.
- 
Paste last test cut or copied
Inserts the current memory buffer contents before the currently highlighted test.
- 
Add new test to bottom of stack
Adds a new blank test to the bottom of the suite.
- 
Insert new test before current test
Inserts a new blank test above the currently highlighted test.
- 
Delete current test
Removes the highlighted test from the suite. If only one test is present, then the contents of this test are cleared.
- 
Move current test down the stack
Moves the highlighted test down one in the test order.
- 
Move current test up the stack
Moves the highlighted test up one in the test order.
- 
Toggle view
Toggles Test Suite between Card View and List View.
- 
Run test suite once or Repeat test suite
When you choose Repeat test suite, the tests run continuously from the top of the Test Suite to the bottom and loopback to the top until you click stop.

### Using the Context Menu

The same operations (Cut, Copy, Paste, etc.) can be performed with the options available in the Context menu. In addition, the direction of an individual test can be reversed by selecting the 'Reverse Current' option. To reverse the direction of all tests, select the 'Reverse All' option.

### Using the Configuration Menus

Two menus are available in the Configuration window: **File** and **Tools**.

The choices on the File menu are:

<b>Import to Selected Test</b>	Import a Test Case from a .tst file or an entire test suite, .tsk file, to the currently highlighted position. A Test Case is one test in the Jammer Test Suite.
<b>Export Selected Test</b>	Export and save the currently highlighted test to a .tst file.
<b>Save Configuration</b>	Save the entire Test Suite to the .tsk file you currently have loaded.
<b>Save Configuration As</b>	Save the entire Test Suite to a .tsk file with a name you assign to it.
<b>Close</b>	Close the Jammer Configuration Window.

The recently used FC Jammer configuration files appear in the file menu and are loaded when selected.



**Note:** The .tst files are only for storing individual Test Cases and swapping them between configuration files. You cannot load .tst files directly into a Jammer device on the Xgig Maestro window.

The Tools menu in the SAS/SATA Configuration window lets you open the SAS Hashed Address Calculator.

The SAS Hashed Address Calculator is also available by clicking the Hashed ID button at the bottom right corner of the SAS Frame Arm or Trigger Condition windows.

SSP frames use a hashed address that is derived from the SAS device address. The SAS Hashed Address Calculator allows you to calculate the hashed address from the SAS address. You must use the hashed address when setting an Arm Condition, Trigger Condition, or Jam Definition for an SSP frame.

To determine the hashed address:

>> Type the SAS address into the calculator.

The hashed address updates on the right.

**Figure 99: SAS Hashed Address Calculator**



## Using the Current Jammer Test Window

The graphics in this section of the window represent the hardware configuration for the selected test in the Jammer Test Suite (Figure 100).

**Figure 100: Current Jammer Test Window**

The screenshot shows the 'Current Jammer Test' window for a test named 'Replace NAK with ACK'. The mode is set to 'Arm on A, then Trigger + Jam on A or Rollback to Arm'. The diagram illustrates two paths: Path A (top) starts with 'Data Input A' leading to an 'Arm' block, then a 'Trigger' block, and finally a 'Jam' block leading to 'Data Output A'. Path B (bottom) starts with 'Data Input B' leading to an 'Arm' block, then a 'Trigger' block, and finally a 'Jam' block leading to 'Data Output B'. A 'Rollback' block is connected between the 'Trigger' and 'Jam' blocks of both paths. Below the diagram, there are configuration fields for 'Arm', 'Trigger', and 'Jam' components, each with a 'Define' button. The 'Arm' field is set to 'SAS Frame' and 'Trigger from Domain A' is unchecked. The 'Trigger' field is set to 'SAS Primitive' and 'Name' is 'Trigger on NAK'. The 'Jam' field is set to 'SAS Primitives Jam Type' and 'Trigger Domain A upon Jam' is unchecked. At the bottom, there are buttons for 'Rollback', 'Repeat', 'Timeout', and 'Pause', each with a corresponding text description.

Current Jammer Test : 1st of 1 test  
 Name : Replace NAK with ACK  
 Mode : Arm on A, then Trigger + Jam on A or Rollback to Arm [Reverse]

Arm  
 Type : SAS Frame OR  Trigger from Domain A  
 Name : Define : Arm A...

Trigger  
 Type : SAS Primitive  
 Name : Trigger on NAK Define : Trigger A...

Jam  
 Type : SAS Primitives Jam Type  Trigger Domain A upon Jam  
 Name : Replace with ACK Define : Jam A...


Rollback Rollback to Arm if Trigger not found within 16777214 Dwords  
 Repeat Arm -> Trigger -> Jam once (Don't repeat the Test Case)  
 Timeout No timeout  
 Pause No pause

### Mode


For SAS/SATA, Mode menus are available near the top of the Current Jammer Test window (Figure 101) and also near the top of each Test Case in the Jammer Test Suite window (Figure 102).

The input to path A (on top) is always port A and the input to path B (on the bottom) is always port B. The external trigger input and output that are available on path A always are linked to the domain shown on the Xgig Maestro window as “Domain of port A.” The trigger input and output on the bottom on path B are in the “Domain of port B.”

**Figure 101: Mode Drop-down Menu in Current Jammer Test - Right Pane**



**Figure 102: Mode Drop-down Menu in Test Suite - Left Pane**



**Reverse**

You can reverse the direction of the jam by selecting the Reverse button.

**Arm and Trigger**

To define Arm and Trigger conditions, select a respective Type from each drop-down menu. Then click the Arm or Trigger button to open the corresponding definition window.

You can use an external input as an Arm condition. Check Trigger from Domain A (or B) to enable this feature. You must put the corresponding Jammer port into a domain for this to work properly.

The Trigger event can be in the next Dword after the Arm event in the traffic stream.

**Jam**

To define a Jam:

- 1 Select a Type from the drop-down menu, if available.
- 2 Click the Jam button to open the Jam Definition window.

The Jam Definition specifies the modifications to be made to the traffic matching the Trigger Condition.

In addition, the Jammer port can trigger out to the Domain it is in when a Jam takes place. Check Trigger Domain A (or B) upon Jam to enable this feature.



**Note:** If you use an external trigger input to define the Arm condition, then you cannot select the external trigger output for that path in that Test Case, and vice versa. For information regarding using the trigger input and output during a Test Case, refer to “Using Domains and External Triggering” on page 291. However, you can use an external trigger in on port A with an external trigger out on port B, and vice versa. Figure 103 shows an example.

**Figure 103: Trigger In and Trigger Out**

Current Jammer Test : 1st of 1 test

Name : Jam R\_OK To R\_ERR

Mode : Arm on A, then Trigger + Jam on B Reverse

**Arm**

Type :  OR  Trigger from Domain A

Name : Trigger from Domain A Define : Arm

**Trigger**

Type : SATA/STP Frame

Name : Data FIS Define : Trigger B...

**Jam**

Type : Replace Frame with Modified Frame  Trigger Domain B upon Jam

Name : Replace EOF with SATA\_ERROR Define : Jam B...

Once

Rollback	
Repeat	Arm -> Trigger -> Jam once (Don't repeat the Test Case)
Timeout	No timeout
Pause	No pause


## Rollback

The Rollback option defines the time or Dword count parameter between the Arm and Trigger events. If the Trigger does not follow the Arm event in the allotted time or Dword count, the Jammer begins looking for the Arm event again. Click **Rollback** to display the dialog shown in Figure 104.



**Note:** This value is saved in terms of Dwords, not time, so keep this in mind if you save a Test Case using a device running at 3.0 Gbps and later open the configuration on a Jammer running at 1.5 Gbps.

**Figure 104: Rollback Condition Dialog**




## Timeout

The timeout option defines the period of time to wait for a specified test to complete before aborting and proceeding to the next test in the suite.

To set the timeout:

- 1 Click **Timeout** to display the dialog box in Figure 105.
- 2 Check **Enable Timeout**.
- 3 Enter the hours, minutes, and seconds you want to wait.

**Figure 105: Timeout Dialog**




- 4 Click **OK**.

## Repeat

Click **Repeat** to open the dialog shown in Figure 108. For Basic Jammer Configurations, the Repeat Mode setting allows you to configure what is repeated when using an Arm condition. The Repeat Mode option means that the Jammer must match the Arm condition each time before looking for a Trigger. The Repeat Count allows you set the number of times a test case is repeated. The limit for repeating a test for 6G SAS/SATA is 2,147,483,647, and for 12G SAS, the limit is 32,767.

**Figure 106: Repeat Test Dialog - Basic Jammer Configuration**



## Pause

Click **Pause** to open the dialog shown in Figure 107. The Pause setting allows you to insert a pause before the beginning of a test case.

**Figure 107: Pause Test Dialog**



For Advanced Jammer Configurations, this setting allows you to configure what is repeated when using an Arm or Trigger condition. The **Repeat** dialog uses counters to provide an increased level of control over the Jam allowing you to skip over extraneous instances of the arm or trigger condition and target the precise data you want to Jam.

You can force the Jammer to match the Arm condition a given number of times before triggering, and you can skip a given number of occurrences of the trigger before Jamming. Once you reach the Jam, you can Jam all occurrences of the trigger condition forever or jam a given number of sequential occurrences of the trigger condition.

Unless you select to Jam forever, you can choose to repeat all or part of the arm-trigger-Jam process either returning to the pre-armed state waiting for another occurrence of the arm condition or returning to the armed state waiting for another occurrence of the trigger condition.



**Note:** For 12G SAS blades, there is a eight clock latency between the arm and trigger/jam state and between the jam and arm state.

The Repeat Mode option means that the Jammer must match the Arm condition each time before looking for a Trigger. The Repeat Count allows you set the number of times a test case is repeated.

**Figure 108: Repeat Test Dialog- Advanced Jammer Configuration**

Test Case Counters and Repeat Settings

Step 1: Wait for 3 occurrence(s) of the Arm Condition.

Step 2: Then, ignore the next 1 occurrence(s) of the Trigger Condition before Triggering and Jamming.

Step 3:  Jam 1 (sequential) occurrence(s) of the Trigger Condition.  
 Jam all occurrences of the Trigger Condition forever (Stop only on Timeout, Skip button or Stop button).

Step 4: Then  begin Step 1 again.  
 begin Step 2 again.

Repeat Count

Test once (Don't repeat the Test Case)


Test 5 times (including the first time)

Repeat the Test Case forever (Stop only on Timeout, Skip button or Stop button)

OK Cancel

You can also configure options for each Test Case directly in the Test Suite, instead of clicking in the Current Jammer Test pane. Click on the area of the Test Case you want to modify to open the corresponding dialog (Figure 109).

**Figure 109: Configuring Options Directly in the Test Suite**



## Configuring SAS Arm and Trigger Conditions

SAS Arm and Trigger conditions recognize specific frames or Primitives.

For Frame conditions, you can specify SOF, SOAF, or either (use all Xs for “either”). You can specify up to 31 additional Dwords after the SOF or SOAF.

You can also define a wildcard specifying bits to be masked out of an arm word and passed through in the corresponding trigger word.

For Primitive Conditions, you can choose from groups of Single, Extended, Triple, or Redundant Primitive Sequences.

For a Single Primitive Sequence, you can specify any standard Single Primitive Sequence or you can specify any user-defined 4 bytes of K/D characters (of which standard Primitives are a subset). You can also specify where you want the Jammer to look for the matching Dword: only inside frames, only outside frames, or anywhere.



**Note:** The Jammer does not look for any matching conditions during OOB initialization or Speed Negotiation.

For Triple, Extended, and Redundant Primitive Sequences, you can choose any standard Extended, Triple or Redundant Primitive Sequence. To match the condition, the Jammer only needs to match one valid Primitive.

You can save an arm or trigger condition as a .jmt file by clicking the **Save** button in the **Arm** or **Trigger** window. You can load a .jmt file by clicking the **Load** button in the **Arm** or **Trigger** window.

The Arm and Trigger windows are identical. In addition, you can select the domain triggered input as an Arm condition.

Depending on the Mode you select, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Jam event. If the Mode you select does not include an Arm condition, the Arm button remains disabled.

To set Arm and Trigger conditions:


- 1 Click on the **Arm** or **Trigger** button in the Jammer Configuration window.

The window for the condition is displayed (Figure 110). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.


- 2 Set the values as required to specify a unique Arm and Trigger sequence for the specific test.

The following sections describe the available values.

Figure 110: SAS Frame Arm and Trigger Window Examples



**Figure 111: SAS Primitives Arm and Trigger Window Examples**



## Setting Frame Conditions

You can specify frame conditions in three ways:

- Load a template from the Template Library tree
- Manually specify bits in the frame
- Select fields from the tree view in the right pane

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Frame Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:


- >> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 112). In the hex view, partially defined hex characters appear as question marks:  
X001=?

When you use the tree view, values are automatically entered into the center column in the right window pane.

**Figure 112: Binary Editor Dialog**



### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e. NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Type selection, and on the main Xgig Maestro window.

### Setting Primitive Sequence Conditions

You can choose a Primitive Sequence from any of the categories listed on the left side of the window: Single, Extended, Triple, or Redundant. For Single Primitives, you can also choose where to match: anywhere, only outside of frames, or only inside of frames.

Single Primitives include a User-defined option.

To edit the user-defined value:

>> Type a hex value into the byte field.

Or


>> Double-click on a byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

Or

>> Click to toggle between K and D, and choose data from the drop-down menu of legal 8-bit characters.

**Figure 113: Selecting K and D Legal 8-bit Characters**



You can also check the “Use inverse of condition specified (i.e. NOT)” option; this means the first word encountered that does not match what you have specified creates a “condition met” event.

As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Type selection and on the main Xgig Maestro window.

## Configuring the SAS Jam Definition

The SAS **Jam Definition** window defines how to modify the event specified on the **Trigger Condition** window.

The Jam is always the same type (frame or Primitive Sequence) as the Trigger.

For any Jam Definition, you can specify an optional name at the top of the window. This name is also displayed on the Jammer Configuration window under the Type selection and on the main Xgig Maestro window.

You can save a Jam definition as a .jmq file by clicking the **Save** button in the **Jam** window. You can load a .jmq file by clicking the **Load** button in the **Jam** window.

## Jamming a Frame


If the Trigger Event is a frame, click the **Jam** button on the Jammer Configuration window to open the Frame Jam Definition window.

The content of the Jam Definition window corresponds to the type of frame Jam you choose on the Jammer Configuration window (modify frame, truncate frame, or replace frame with Idles). The following paragraphs describe these choices.

### Jam Behavior

This controls the number of user-defined header/payload Jams performed relative to the target trigger frame. The **Jam Behavior** section is present on all tabs of the **Frame Jam Definition** window.

**Figure 114: Jam Behavior Selection**



- Jam until end of trigger frame

Jams defined in the Header/Payload tab are performed until the end of the target trigger frame (or until an abnormal termination of the frame). All Jams defined that would take place on the original CRC or later are ignored. However, if the frame that is triggered on has more Dwords than the Jams you specify, the remaining Dwords are passed through. The CRC and EOF of the original target trigger frame are always jammed according to the CRC and EOF settings on the SOF/CRC/EOF tab. This is the standard way to Jam a frame.

- Execute full Jam pattern

All header and payload Jams take place, even if they overwrite beyond the end of the target trigger frame. Use the control at the bottom of the Header/Payload tab to define how many Jams should take place.

The last defined Jam is the last Header/Payload Jam. The options for modifying the CRC and EOF on the SOF/CRC/EOF tab are unavailable.

If the target trigger frame is longer than the number of Jams defined, then the portion of the target trigger frame that extends after the last defined Jam is overwritten with Idles. If the target trigger frame is shorter, then the Jammer switches back to pass-through immediately after the last defined Jam.



**Note:** Be careful when using this option because you may overwrite a portion of important traffic (a frame or Flow Control Primitives).

### Replace Frame with Modified Frame

Each tab contains options relevant to different frame modifications.

#### Using the Global Tab

Use this tab (Figure 115) to define Jam parameters that apply globally to the frame.

#### Global Replace Jam Option

Use the Global Replacement Dword to set specific bits in a Dword to 1 or 0 while passing through the remaining bits. You can apply this global replacement to any Dword in the frame. Define one Global Replacement for each Test Case.


To edit these bits:

>> Enter hex values, or double-click on a byte field to open the Binary Editor.

Any bits left as Xs are passed through.

The difference between this Global Replacement option versus the Replace Dword option found on the Header/Payload tab is that the Global Replacement option allows masking down to the bit level, whereas the other option allows masking at the nibble level.

Figure 115: SAS Global Tab



This option is only available in the SAS/SATA Advanced Jammer configuration.

### **Global Bit Errors**

The Jammer software can introduce bit errors repeatedly in sequential or random fashion to predefined fields. These bit errors are introduced to the 32-bit form of the target Dwords (not the 40-bit form) so code violations are not created. The Global Bit Errors control allows you four options.

- Select **one bit for all fields** and **randomly**. This causes the Jammer to inject a single bit error in the group of all fields selected in the header or payload for a single Test Case. If the Jammer Test Suite is set to *loop*, then single bit errors are randomly injected into these fields, with one bit for each cycle of the Test Suite.
- Select **one bit for all fields** and **sequentially**. This also injects a single bit error in the group of all fields selected in the header or payload. If the Test Suite is set to loop forever, the bit error walks through all the selected fields.
- Select **one bit in each field** and **randomly** does the same thing as the first option; however, there will be one error for each Dword selected in the header or payload.
- Select **one bit in each field** and **sequentially** does the same thing as the second option; however, there will be one error for each Dword selected in the header or payload.



**Note:** The location of the bit errors are moved each time you run this entire Test Case, not each time you repeat the Jam within the Test Case.

---


### **Global Timer for Jam with D.C. Idle**

In an Advanced SAS/SATA Jammer configuration, the Jammer software allows you to set a global timer for Jamming with D.C. Idles. When using this option, DCI will continue until the timer expires regardless of the triggering item.

### Using the SOF/CRC/EOF Tab

Use the choices on this tab to modify the Start of Frame (SOF), Cyclic Redundancy Check (CRC), and End of Frame (EOF) Dwords of the original target frame (Figure 116).

**Figure 116: Serial Attached SCSI SOF/CRC/EOF Tab**



### SOF/EOF Options

You can pass through or replace the start and end of frame Dwords with another SOF, EOF, another standard Primitive, a Scrambled Idle Dword, or any four user-defined K/D characters. In addition to these options, you can send an error on any byte of the Dwords.

DCI options are available only in the Advanced SAS/SATA Jammer configurations. These allow you to replace a Dword with a DCI or to send DCI with the Global timer set in the Global tab.

Check Inject Error for any byte(s) on which you want to send errors. Then choose Disparity Error or Code Violation. If you choose Disparity Error, the Jammer inverts the running disparity at that byte. If that byte is a neutral 10b character, you might not see the disparity error until a later byte. The Code Violation option replaces the byte with a predefined 10-bit illegal character.

### ***CRC Options***

CRC options include:

- Not changing the CRC in the original target frame
- Recalculating the CRC to make it correct for the modified data
- Replace Dword with DCI
- Send DCI (with Global timer)
- Replacing with a user-specified data Dword or Primitive

With the addition of recalculating the CRC, you configure the CRC option in the same way as the SOF/EOF options.

Depending on the changes made to a frame, the old CRC might be invalid. If the CRC is passed through, an invalid frame might be created. The lowest layer of protocol error checking should recognize this type of error. If the frame is modified and the CRC is recalculated, a valid frame with modified data is created. If, for example, the modifications are made to SCSI commands embedded in the payload, the SCSI error checking routines should trap and handle the error.

Recalculating a CRC might not work if you corrupt the frame with illegal Primitives, errors, or Scrambled Idle Dwords.

### ***Using the Header/Payload Tab***

You can modify any and all words in the header and payload (Figure 117). Select either the **Replace Jam** or **All Jam Modes** radio button.

Similar to defining an Arm or Trigger Condition, there are two ways to specify your frame Jam Definition. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Highlight a template in the Template Library tree on the left side of the window.  
Tree View is structured similar to the display on the right side of the Arm and Trigger Condition windows. You can make selections from the tree; this creates the appropriate Replace Jams.
- 2 Click the double right arrow to display the Jam definition on the right side of the window.

When you use a template, the Jam definition is populated with Replace Jams of the specified data, while all other bits are passed through.


To manually edit the values, enter a value into the byte field. An **X** in a nibble passes the original value through.



**Note:** The more Dwords in a Jam Definition, the longer the time between Test Cases in the suite. Switching from one Test Case to the next is a software operation, so the time between cases will be on the order of hundreds of milliseconds.

---

Figure 117: SAS Header/Payload Tab



To manually define each nibble, enter a value into the byte field or double-click to display the Binary Editor. If you specify a bit as a 0 or 1, you must specify the values of the other three bits in that nibble as well. An X in a nibble passes the original value through. Choose any K/D character for an entire byte by using the drop-down controls. Click on the K or D to toggle this setting.

Use the **Number of Header + Payload Dwords** counter to define the number of Dwords to Jam. (Figure 118). Use the scroll bar to position the display to the desired Dword, if necessary.


Figure 118: Setting Header + Payload Size



You can also use the List View controls at the top to cut, copy, paste, add, insert, or delete Dwords.

Notice the special choice at the bottom left, **Current Trigger** (Figure 119). This is a copy of the frame condition you have specified for the Trigger. The name of the Trigger Condition (if any) is shown in parenthesis. Click the double right arrow to use this.


**Figure 119: Current Trigger Option**



To manually specify a frame Dword Jam, select the **All Jam Modes** radio button. Select a Jam Type from the drop-down menu (under the Type column), then specify any additional definition (if necessary) by clicking on the data field (under the Description column).

Selecting the **Replace Jam Mode** radio button opens a dialog that allows you to replace an entire frame either by using a template or manually entering values. The Replace Jam Mode dialog also contains a view of the frame contents, similar to those seen the Arm and Trigger Condition windows. These values correspond to the hex values defined in the center column.


**Figure 120: Replace Jam Mode**



Selecting the **All Jam Modes** radio button opens a dialog that provides the following choices are available for each Dword in a frame on the Header/Payload tab:


- **Replace 8b Jam Mode** - This function allows you to replace the Dword with any standard Primitive, a Scrambled Idle Dword, or a user-defined Dword (Figure 121).

**Figure 121: Replace Jam Dialog**



- **Replace 10b Jam** (Advanced Jammer Configurations only) - This function allows you to replace the Dword with any standard Primitive, a Scrambled Idle Dword, or a user-defined Dword.
- **Apply Global Replace Jam** - This function allows individual bits to be set to 1, set to 0 or passed through unchanged according to the Global Replacement Dword defined on the Global Tab.
- **Create Error Jam** - Check Inject Error for any byte(s) on which you want to send errors (Figure 122). Then choose Disparity Error or Code Violation. If you choose Disparity Error, the Jammer inverts the running disparity at that byte. If that byte is a neutral 10b character, you might not see the disparity error until a later byte. The Code Violation option replaces the byte with a predefined 10-bit illegal character.

**Figure 122: Create Error Dialog**



- **Invert Jam** - Invert defined bits and pass through the rest. Enter 1s at the appropriate bit locations.
- **Pass Through Jam** - Pass through the current Dword unchanged.
- **Replace Jam with CRC** - This word contains the current CRC value. CRC calculation is reset and started at the Dword after any SOF. Note that there should be only valid data Dwords between an SOF and its partner automatic CRC insertion or else the CRC value will be incorrect. Violations of this rule include using Primitives, Scrambled Idle Dwords, or code violations.



**Note:** If you place an SOF in Dword 2, and an automatic CRC in Dword 10, the CRC is calculated over Dwords 3 to 9.

- **Set Bits To 0s Jam-** Set defined bits to 0s and pass through the rest. Enter 0s at the appropriate bit locations.
- **Set Bits To 1s Jam -** Set defined bits to 1s and pass through the rest. Enter 1s at the appropriate bit locations.
- **Apply Global Bit Error Jam -** Apply the Global Bit Error function set on the Global tab. Enter 1s at the appropriate bit locations (Figure 123).

**Figure 123: Apply Global Bit Error Jam Bit Location Dialog**



### Replace Frame with Truncated Frame

This option truncates the target frame to a shorter length and sends Scrambled Idle Dwords on top of the remainder of the target frame (Figure 124).

>> Use the up and down arrow buttons or type the number of Dwords you want to truncate the frame to (including header and payload, not including SOF, CRC, and EOF).

You can pass through or replace the SOF Dword with another SOF, another standard Primitive, a Scrambled Idle Dword, or any four user-defined K/D characters. In addition to these options, you can send an error on any byte of the Dword.

DCI options are available only in the Advanced SAS/SATA Jammer configurations. These allow you to replace a Dword with a DCI or to send DCI with the Global timer set in the Global tab.

The CRC must be replaced or recalculated in one of the following ways:


- Recalculating the CRC to make it correct for the modified data
- Replacing with a user-specified data Dword or Primitive
- Replace Dword with DCI
- Send DCI (with Global timer)

Replacing the CRC is specified the same way as the SOF. You can also send an error on any byte.

You must select a replacement Dword for the EOF. This is specified in the same way as the SOF. You can also send an error on any byte.

Check **Inject Error** for any byte(s) on which you want to send errors. Then choose Disparity Error or Code Violation. If you choose Disparity Error, the Jammer inverts the running disparity at that byte. If that byte is a neutral 10b character, you might not see the disparity error until a later byte. The Code Violation option replaces the byte with a predefined 10-bit illegal character.


**Figure 124: SAS - Replace Frame with Truncated Frame**



**Replace Frame with Scrambled Idle Dwords**

This option replaces the target frame with Scrambled Idle Dwords. The following dialog is displayed (Figure 125).


**Figure 125: SAS - Replace Frame with Scrambled Idle Dwords.**




**Jamming a Primitive Sequence**

If the Trigger Event is a Primitive Sequence, click the **Jam** button on the Jammer Configuration window to open the Primitive Sequence Jam Definition window (Figure 126, Figure 127, Figure 128).


**Figure 126: Single Primitive Sequence Jam Definition Window**



**Figure 127: Triple Primitive Sequence Jam Definition Window**



**Figure 128: Redundant Primitive Sequence Jam Definition Window**



The number of Dwords shown in the Definition window corresponds to the type of Primitive Sequence you specified as the Trigger Condition (one Dword for a Single or Extended, four for a Triple, or seven for a Redundant Primitive Sequence).

Ideally, any Triple or Redundant Sequences that the Jammer triggers on should be three or six Dwords long, respectively. If the Dwords are shorter, then the Jammer does not use all of the Jams specified in this window. If the Dwords are longer, then any Dword over the ideal third or sixth Dword in the sequence is Jammed according to the fourth or seventh Dword Jam Definition, respectively.

For each Dword, you have three options:

- Pass through the Primitive
- Corrupt any byte(s) with an error
- Replace Dword with DCI
- Send DCI (with Global timer)

- Replace the Primitive with a new Dword

To pass through a Primitive, select the top option for that Dword.

To create an error, select Create Error for that Dword. Then check Inject Error for any byte(s) on which you want to send errors. Then choose Disparity Error or Code Violation. If you choose Disparity Error, the Jammer inverts the running disparity at that byte. If that byte is a neutral 10b character, you might not see the disparity error until a later byte. The Code Violation option replaces the byte with a predefined 10-bit illegal character.

DCI options are available only in the Advanced SAS/SATA Jammer configurations. These allow you to replace a Dword with a DCI or to send DCI with the Global timer set in the Global tab.

You can replace the Dword with any K/D characters, any standard Primitive, or a Scrambled Idle Dword, by selecting the bottom option and choosing from the drop-down list.

## Configuring SATA/STP Arm and Trigger Conditions

Arm and Trigger conditions recognize specific frames or Primitives.

For Frame conditions, SATA\_SOFTWARE is automatically specified. You can specify up to 31 additional Dwords after the SOF.

You can also define a wildcard specifying bits to be masked out of an arm word and passed through in the corresponding trigger word.

For Primitive Conditions, you can choose from groups of Single, Repeated, or Continued Primitive Sequences.

For a Single Primitive Sequence, you can specify any standard Single Primitive Sequence. You can also specify where you want the Jammer to look for the matching Dword: only inside frames, only outside frames, or anywhere.



**Note:** The Jammer does not look for any matching conditions during OOB initialization or speed negotiation.

---

For Repeated Primitive Sequences, you can choose either SATA\_PMACK or SATA\_PMNAK.

For Continued Primitive Sequences, you can choose any standard Continued Primitive Sequence.

The Arm and Trigger windows are identical (Figure 130 and Figure 131). In addition, you can select the domain triggered input as an Arm condition.

Depending on the Mode you select, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Jam event. If the Mode you select does not include an Arm condition, the Arm button remains disabled.


To set Arm and Trigger conditions:

- 1 Click the **Arm** or **Trigger** button in the Jammer Configuration window.


The window for the condition is displayed (Figure 129). If you are in hardware edit mode, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.

- Set the values as required to specify a unique Arm and Trigger sequence for the specific test. The following sections describe the available values.


**Figure 129: SATA/STP Frame Arm and Trigger Window Examples**




**Figure 130: SATA/STP Continued Primitives Arm Window Example**



**Figure 131: SATA/STP Single Primitive Trigger Window Example**



**Figure 132: SATA/STP Repeated Primitives Trigger Window Example**



## Setting Frame Conditions

You can specify frame conditions in three ways:

- Load a template from the Template Library tree
- Manually specify bits in the frame
- Select fields from the tree view in the right pane

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:


>> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 133 on page 147). In the hex view, partially defined hex characters appear as question marks: X001=?

When you use the tree view, values are automatically entered into the center column in the right window pane.

**Figure 133: Binary Editor Dialog**



### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Highlight the folder and click the double left arrow button.


Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Type selection, and on the main Xgig Maestro window.

## Setting Primitive Sequence Conditions

You can choose a Primitive Sequence from any of the categories on the left side of the window: Single, Repeated, or Continued. For Single Primitives, you can also choose where to match: anywhere, only outside of frames, or only inside of frames.

**Figure 134: SATA/STP Single Primitive Sequence Conditions Example**



You can check the “Use inverse of condition specified (i.e. NOT)” option; this means the first Dword encountered that does not match what you have specified creates a “condition met” event.

As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Type selection and on the main Xgig Maestro window.

## Configuring the SATA/STP Jam Definition

The **Jam Definition** window defines how to modify the event specified on the **Trigger Condition** window.

The Jam is always the same type (frame or Primitive Sequence) as the Trigger.

For any Jam Definition, you can specify an optional name at the top of the window. This name is also displayed on the Jammer Configuration window under the Type selection and on the main Xgig Maestro window.

You can save a Jam definition as a .j mj file by clicking the **Save** button in the **Jam** window. You can load a .j mj file by clicking the **Load** button in the **Jam** window.

## Jamming a Frame

If the Trigger Event is a frame, click the **Jam** button on the Jammer Configuration window to open the Frame Jam Definition window.

The content of the Jam Definition window corresponds to the type of frame Jam you choose on the Jammer Configuration window (modify frame, truncate frame, or replace frame with SATA\_SYNC Continued Primitive Sequence). The following paragraphs describe these choices.

### Replace Frame with Modified Frame

Each tab contains options relevant to different frame modifications.

#### Using the Global Tab

Use this tab (Figure 135) to define Jam parameters that apply globally to the frame.

#### Global Replace Jam Option

Use the Global Replacement Dword to set specific bits in a Dword to 1 or 0 while passing through the remaining bits. You can apply this global replacement to any Dword in the frame. Define one Global Replacement for each Test Case.


To edit these bits:

>> Enter hex values, or double-click on a byte field to open the Binary Editor.

Any bits left as Xs are passed through.

The difference between this Global Replacement option versus the Replace Dword option found on the Header/Payload tab is that the Global Replacement option allows masking down to the bit level, whereas the other option allows masking at the nibble level.

**Figure 135: SATA/STP Global Tab**



### **Global Bit Errors**

The Jammer software can introduce bit errors repeatedly in sequential or random fashion to predefined fields. These bit errors are introduced to the 32-bit form of the target Dwords (not the 40-bit form) so code violations are not created. The Global Bit Errors control allows you four options.

- Select **one bit for all fields** and **randomly**. This causes the Jammer to inject a single bit error in the group of all fields selected in the header or payload for a single Test Case. If the Jammer Test Suite is set to *loop*, then single bit errors are randomly injected into these fields, with one bit for each cycle of the Test Suite.
- Select **one bit for all fields** and **sequentially**. This also injects a single bit error in the group of all fields selected in the header or payload. If the Test Suite is set to loop forever, the bit error walks through all the selected fields.
- Select **one bit in each field** and **randomly** does the same thing as the first option; however, there will be one error for each Dword selected in the header or payload.
- Select **one bit in each field** and **sequentially** does the same thing as the second option; however, there will be one error for each Dword selected in the header or payload.



**Note:** The location of the bit errors are moved each time you run this entire Test Case, not each time you repeat the Jam within the Test Case.

---


### **Global Timer for Jam with D.C. Idle**

In an Advanced SAS/SATA Jammer configuration, the Jammer software allows you to set a global timer for Jamming with D.C. Idles. When using this option, DCI will continue until the timer expires regardless of the triggering item.

### Using the SOF/CRC/EOF Tab

Use the choices on this tab to modify the Start of Frame (SOF), Cyclic Redundancy Check (CRC), and End of Frame (EOF) Dwords of the original target frame (Figure 136).

Figure 136: SATA/STP SOF/CRC/EOF Tab



### SOF/EOF Options

You can pass through or replace the start and end of frame Dwords with another standard Primitive, Scrambled Primitive Data, or any four user-defined K/D characters. In addition to these options, you can send an error on any byte of the Dwords.

DCI options are available only in the Advanced SAS/SATA Jammer configurations. These allow you to replace a Dword with a DCI or to send DCI with the Global timer set in the Global tab.

Check Inject Error for any byte(s) on which you want to send errors. Then choose Disparity Error or Code Violation. If you choose Disparity Error, the Jammer inverts the running disparity at that byte. If that byte is a neutral 10b character, you might not see the disparity error until a later byte. The Code Violation option replaces the byte with a predefined 10-bit illegal character.

### ***CRC Options***

CRC options include:

- Not changing the CRC in the original target frame
- Replace Dword with DCI
- Send DCI (with Global timer)
- Recalculating the CRC to make it correct for the modified data
- Replacing with a user-specified data Dword, Primitive, or Scrambled Primitive Data

With the addition of recalculating the CRC, you configure the CRC option in the same way as the SOF/EOF options.

Depending on the changes made to a frame, the old CRC might be invalid. If the CRC is passed through, an invalid frame might be created. The lowest layer of protocol error checking should recognize this type of error. If the frame is modified and the CRC is recalculated, a valid frame with modified data is created.

### ***Using the Header/Payload Tab***

Similar to defining an Arm or Trigger Condition, there are two ways to specify your frame Jam Definition. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Highlight a template in the Template Library tree on the left side of the window.  
Tree View is structured similar to the display on the right side of the Arm and Trigger Condition windows. You can make selections from the tree; this creates the appropriate Replace Jams.
- 2 Click the double right arrow to display the Jam definition on the right side of the window.

When you use a template, the Jam definition is populated with Replace Jams of the specified data, while all other bits are passed through.


To manually edit the values, enter a value into the byte field. An **X** in a nibble passes the original value through.



**Note:** The more Dwords in a Jam Definition, the longer the time between Test Cases in the suite. Switching from one Test Case to the next is a software operation, so the time between cases will be on the order of hundreds of milliseconds.

---

**Figure 137: SATA/STP Header/Payload Tab**



To manually define each nibble, enter a value into the byte field or double-click to display the Binary Editor. If you specify a bit as a 0 or 1, you must specify the values of the other three bits in that nibble as well. An X in a nibble passes the original value through. Choose any K/D character for an entire byte by using the drop-down controls. Click on the K or D to toggle this setting.

Use the **Number of Header + Payload Dwords** counter to define the number of Dwords to Jam (Figure 138). Use the scroll bar to position the display to the desired Dword, if necessary.

**Figure 138: Setting Header + Payload Size**



You can also use the List View controls at the top to cut, copy, paste, add, insert, or delete Dwords.

Notice the special choice at the bottom left, **Current Trigger** (Figure 139). This is a copy of the frame condition you have specified for the Trigger. The name of the Trigger Condition (if any) is shown in parenthesis. Click the double right arrow to use this.


**Figure 139: Current Trigger Option**



To manually specify a frame Dword Jam, select the **All Jam Modes** radio button. Select a Jam Type from the drop-down menu (under the Type column), then specify any additional definition (if necessary) by clicking on the data field (under the Description column).

Selecting the **Replace Jam Mode** radio button opens a dialog that allows you to replace an entire frame either by using a template or manually entering values. The Replace Jam Mode dialog also contains a view of the frame contents, similar to those seen the Arm and Trigger Condition windows. These values correspond to the hex values defined in the center column.


**Figure 140: Replace 8b Jam Mode**



Selecting the **All Jam Modes** radio button opens a dialog that provides the following choices are available for each Dword in a frame on the Header/Payload tab:


- **Apply Global Replace Jam** - This function allows individual bits to be set to 1, set to 0 or passed through unchanged according to the Global Replacement Dword defined on the Global Tab.
- **Replace 8b Jam Mode** - This function allows you to replace the Dword with any standard Primitive, a Scrambled Idle Dword, or a user-defined Dword (Figure 141).

**Figure 141: Replace 8b Jam Dialog**



- **Replace 10b Jam** (Advanced Jammer Configurations only) - This function allows you to replace the Dword with any standard Primitive, a Scrambled Idle Dword, or a user-defined Dword (Figure 141).
- **Create Error Jam** - Check Inject Error for any byte(s) on which you want to send errors (Figure 142). Then choose Disparity Error or Code Violation. If you choose Disparity Error, the Jammer inverts the running disparity at that byte. If that byte is a neutral 10b character, you might not see the disparity error until a later byte. The Code Violation option replaces the byte with a predefined 10-bit illegal character.

**Figure 142: Create Error Dialog**



- **Invert Jam** - Invert defined bits and pass through the rest. Enter 1s at the appropriate bit locations.
- **Pass Through Jam** - Pass through the current Dword unchanged.
- **Replace 8b Jam** - You can replace the Dword with any standard Primitive, Scrambled Primitive Data, or a user-defined Dword (Figure 141).

To define each nibble, enter a value into the byte field or double-click to display the Binary Editor. If you specify a bit as a 0 or 1, you must specify the values of the other three bits in that nibble also. An **X** in a nibble passes the original value through. Choose any K/D character for an entire byte by using the drop-down controls. Click on the K or D to toggle this setting.

- **Replace Jam with CRC** - This word contains the current CRC value. CRC calculation is reset and started at the Dword after any SOF. Note that there should be only valid data Dwords between an SOF and its partner automatic CRC insertion or else the CRC value will be incorrect. Violations of this rule include using Primitives, Scrambled Primitive Data, or code violations.



**Note:** If you place an SOF in Dword 2, and an automatic CRC in Dword 10, the CRC is calculated over Dwords 3 to 9.

- **Set Bits To 0s Jam**- Set defined bits to 0s and pass through the rest. Enter 0s at the appropriate bit locations.
- **Set Bits To 1s Jam** - Set defined bits to 1s and pass through the rest. Enter 1s at the appropriate bit locations.
- **Apply Global Bit Error Jam** - Apply the Global Bit Error function set on the Global tab. Enter 1s at the appropriate bit locations (Figure 143).

**Figure 143: Apply Global Bit Error Jam Bit Location Dialog**



### Replace Frame with Truncated Frame

This option truncates the target frame to a shorter length and sends SATA\_WTRM on top of the remainder of the target frame (Figure 144).

>> Use the up and down arrow buttons or type the number of Dwords you want to truncate the frame to (including header and payload, not including SOF, CRC, and EOF).

You can pass through or replace the SOF Dword with another standard Primitive, Scrambled Primitive Data, or any four user-defined K/D characters. In addition to these options, you can send an error on any byte of the Dword.

DCI options are available only in the Advanced SAS/SATA Jammer configurations. These allow you to replace a Dword with a DCI or to send DCI with the Global timer set in the Global tab.

The CRC must be replaced or recalculated in one of the following ways:


- Recalculating the CRC to make it correct for the modified data
- Replacing with a user-specified data Dword or Primitive
- Relapse Dword with DCI
- Send DCI (with Global timer)

Replacing the CRC is specified the same way as the SOF. You can also send an error on any byte.

You must select a replacement Dword for the EOF. This is specified in the same way as the SOF. You can also send an error on any byte.

Check **Inject Error** for any byte(s) on which you want to send errors. Then choose Disparity Error or Code Violation. If you choose Disparity Error, the Jammer inverts the running disparity at that byte. If that byte is a neutral 10b character, you might not see the disparity error until a later byte. The Code Violation option replaces the byte with a predefined 10-bit illegal character.


**Figure 144: SATA/STP - Replace Frame with Truncated Frame**



**Replace with Scrambled Idle Dwords**

This option replaces the target frame with Scrambled Idle Dwords. The following dialog is displayed (Figure 145).


**Figure 145: SAS - Replace Frame with Scrambled Idle Dwords.**




## Jamming a Primitive Sequence


If the Trigger Event is a Primitive Sequence, click the **Jam** button on the Jammer Configuration window, to open the Primitive Sequence Jam Definition window (Figure 146, Figure 147, Figure 148). A dialog is displayed corresponding to your choice of Trigger Condition Primitive Sequence type.

**Figure 146: Single Primitive Sequence Jam Definition Window**



**Figure 147: Continued Primitive Sequence Jam Definition Window**



**Figure 148: Repeated Primitive Sequence Jam Definition Window**

### Jamming a Single Primitive Sequence

For the Jam, you have three options:

- Pass through the Primitive
- Corrupt any byte(s) with an error
- Replace the Primitive with a new Dword
- Replace Dword with DCI
- Send DCI (with Global timer)

To pass through the Primitive, select the top option.

To create an error, select Create Error. Then check Inject Error for any byte(s) on which you want to send errors. Then choose Disparity Error or Code Violation. If you choose Disparity Error, the Jammer inverts the running disparity at that byte. If that byte is a neutral 10b character, you might not see the disparity error until a later byte. The Code Violation option replaces the byte with a predefined 10-bit illegal character.

You can replace the Dword with any K/D characters, any standard Primitive, or Scrambled Primitive Data, by selecting the bottom option and choosing from the drop-down list.

DCI options are available only in the Advanced SAS/SATA Jammer configurations. These allow you to replace a Dword with a DCI or to send DCI with the Global timer set in the Global tab.

### Jamming a Continued or Repeated Primitive Sequence

Four options allow you to Jam the entire Primitive Sequence:

- Pass through entire sequence
- Create errors on every Dword of the sequence
- Replace every Dword of the sequence with a specific Dword
- Replace sequence with a Continued Primitive Sequence
- Send DCI (with Global timer)

Pass through and Create Errors work the same as Single Primitive Sequences.

You can replace every Dword of the sequence with another specific Dword by choosing **Replace every Dword of sequence with this Primitive...** You can replace the sequence with any K/D characters, any standard Primitives, or Scrambled Primitive Data by choosing from the drop-down menu. Choosing PMACK or PMNAK is equivalent to replacing with a Repeated Primitive Sequence.

You can replace the sequence with a standard Continued Primitive Sequence by choosing **Replace sequence with this Continued Primitive Sequence...** Choose from the drop-down menu.

DCI options are available only in the Advanced SAS/SATA Jammer configurations. These allow you to replace a Dword with a DCI or to send DCI with the Global timer set in the Global tab.

# ***Chapter 6***

## Creating Jammer Test Configurations for 10GigE

### **In this chapter:**

- [Defining Your Own Test Configurations for 10GigE](#)
- [Using the Jammer Configuration Window for 10GigE](#)
- [Configuring the Arm Condition for 10GigE](#)
- [Configuring the Trigger Condition for 10GigE](#)
- [Configuring the Jam Definition for 10GigE](#)

## Defining Your Own Test Configurations for 10GigE

Xgig Jammer lets you define your own test configurations and save them with or without hardware available.

You can create a configuration from scratch, or you can open and edit an existing configuration. Also, you can edit a configuration in edit only mode, which is independent of any hardware, or you can edit a configuration that is currently loaded to a Jammer device.


To edit a configuration in edit only mode:

- >> Double-click on a configuration file in the Configuration manager.
- or:
- >> Right-click on the configuration file in the Configuration manager and choose **Edit Jammer Configuration** from the context menu.

The edit only mode Jammer Configuration window opens (Figure 149).

This window allows you to set up your own Test Cases, name them, organize them, and save them to files so that you can use them again.

**Figure 149: Edit Only Jammer Configuration Window**




To start a configuration from scratch in edit only mode:

- >> Select **New Jammer Configuration** from the context menu or the File menu (Figure 150) on the Xgig Maestro menu bar. Then, select **10 Gigabit Ethernet Jammer** from the drop down menu.

or:

- >> Click the New Configuration icon at the top of the Configuration manager.

**Figure 150: Maestro File Menu**



To save your configuration in edit only mode:

- >> Click **Save** at the bottom of the Jammer Configuration window or open the File menu on the Jammer Configuration window and select **Save Configuration** or **Save Configuration As**.

Any changes you make have no effect on actual Jammer devices you control.

To edit a configuration that is loaded to a Jammer port:

- >> Click **Configuration...** in the device column.

or:

- >> Right-click in the Parameters Status table in the device column to open the context menu and select **Edit configuration**.

or:

- >> Click **Operation** in the device column to open the Operation dialog, then click **Config**.

The Xgig Jammer Configuration window in hardware edit mode is displayed (Figure 151).


This window allows you to set up your own Test Cases, name them, and save them to a file so that you can use them again.

Click **Apply** or **OK** and Jammer accepts the changes. They are immediately reflected in the Parameters Status table and affect the Jammer device the next time you run it.

To save your configuration edits:

- >> Open the File menu at the top of the Jammer Configuration window and select **Save Configuration As...** or **Save Configuration**.

**Figure 151: Xgig Jammer Configuration Window**



## Using the Jammer Configuration Window for 10GigE

The Jammer Configuration window title bar indicates how many ports it is configuring, the protocol, and the configuration file name, if any. If you are using hardware edit mode, the chassis name, chassis number, slot number, and port number are also listed. The elements of the Jammer Configuration window are described in the following sections.


## Using the Jammer Test Suite Tools for 10GigE

The Jammer Test Suite (left pane) lists the series of Xgig Jammer tests in the order in which you want them to execute. The suite includes one or more tests. The highlighted test appears as the Current Jammer Test (right pane). Each test in the suite executes in sequence with a test reset time of approximately 130 (200 max) milliseconds.

## Creating a Test Suite

When you create a 10GigE Jammer Test Suite, you use the toolbar in the Jammer Test Suite section of the Configuration window (Figure 152).

**Figure 152: 10GigE Jammer Test Suite Toolbar**



The following list describes the icons on the toolbar:

	Cut current test	Removes the highlighted test and holds its contents in the memory buffer.
	Copy current text	Copies the highlighted test to the memory buffer.
	Paste last test cut or copied	Inserts the current memory buffer contents before the currently highlighted test.
	Add new test to bottom of stack	Adds a new blank test to the bottom of the suite.
	Insert new test before current test	Inserts a new blank test above the currently highlighted test.
	Delete current test	Removes the highlighted test from the suite. If only one test is present, then the contents of this test are cleared.
	Move current test down the stack	Moves the highlighted test down one in the test order.
	Move current test up the stack	Moves the highlighted test up one in the test order.
	Toggle view	Toggles Test Suite between Card View and List View.
	Run test suite once or Repeat test suite	When you choose Repeat test suite, the tests run according the settings you define in the Jammer Current Test window.

To duplicate a test at another point in the Test Suite:

- 1 Highlight the test you want to duplicate.
- 2 Click **Copy**.
- 3 Highlight the test in the suite that is just after the point where you want the duplicate test inserted.
- 4 Click **Paste**.


The duplicate test is inserted.

Refer to “Configuring the Arm Condition for 10GigE”, “Configuring the Trigger Condition for 10GigE” and “Configuring the Jam Definition for 10GigE” for information about configuring each test.

## Using the Configuration File Menu

The File menu is the only menu on the menu bar (Figure 153).

**Figure 153: Configuration File Menu**



The choices are:

<b>Open Configuration</b>	Open an existing <code>.tsk</code> configuration file.
<b>Import to Selected Test</b>	Import a Test Case from a <code>.tst</code> file or an entire test suite, <code>.tsk</code> file, to the currently highlighted position. A Test Case is one line in the Jammer Test Suite.
<b>Export Selected Test</b>	Export and save the currently highlighted test to a <code>.tst</code> file.
<b>Save Configuration</b>	Save the entire Test Suite to the <code>.tsk</code> file you currently have loaded.
<b>Save Configuration As</b>	Save the entire Test Suite to a <code>.tsk</code> file with a name you assign to it.
<b>Close</b>	Close the Jammer Configuration Window.

The recently used 10GigE Jammer configuration files appear in the file menu and are loaded when selected.



**Note:** The `.tst` files are only for storing individual Test Cases and swapping them between configuration files. You cannot load `.tst` files directly into a Jammer device on the Xgig Maestro window.

## Using the Current Jammer Test Window for 10GigE

The graphics in this section of the window represent the hardware configuration for the selected test in the Jammer Test Suite (Figure 154).

**Figure 154: Current Jammer Test Window**

Current Jammer Test : 1st of 2 tests

Name : Create bit error on TCP frame sequence number

Mode : Arm on A, then Trigger + Jam on A or Rollback to Arm Reverse

Arm

Type : Frame OR  Trigger from Domain A

Name :  Define :

Trigger

Type : Frame

Name : Jam on any TCP frame Define :

Jam

Type : Insert Frame  Trigger Domain A upon Jam

Name : remove the frame Define :

Rollback to Arm if Trigger not found within 2147483647 Dwords

Repeat Arm -> Trigger -> Jam 7 times (including the first time)

00 : 05 : 00 ( hr : min : sec )

No pause


Repeat

### Mode


For 10GigE, Mode menus are available near the top of the Current Jammer Test window (Figure 155) and also near the top of each Test Case in the Jammer Test Suite window (Figure 156).

The input to path A (on top) is always port A and the input to path B (on the bottom) is always port B. The external trigger input and output that are available on path A always are linked to the domain shown on the Xgig Maestro window as “Domain of port A.” The trigger input and output on the bottom on path B are in the “Domain of port B.”

**Figure 155: Mode Drop-down Menu in Current Jammer Test - Right Pane**



**Figure 156: Mode Drop-down Menu in Test Suite - Left Pane**



## Reverse

You can reverse the direction of the jam by selecting the **Reverse** button.

## Arm and Trigger

To define Arm and Trigger conditions, select a respective Type from each drop-down menu. Then click the Arm or Trigger button to open the corresponding definition window.

You can use an external input as an Arm condition. Check Trigger from Domain A (or B) to enable this feature. You must put the corresponding Jammer port into a domain for this to work properly.

The Trigger event can be in the next Dword after the Arm event in the traffic stream.

## Jam

To define a Jam:

- 1 Select a Type from the drop-down menu, if available.
- 2 Click the Jam button to open the Jam Definition window.

The Jam Definition specifies the modifications to be made to the traffic matching the Trigger Condition.

In addition, the Jammer port can trigger out to the Domain it is in when a Jam takes place. Check Trigger Domain A (or B) upon Jam to enable this feature.



**Note:** If you use an external trigger input to define the Arm condition, then you cannot select the external trigger output for that path in that Test Case, and vice versa. For information regarding using the trigger input and output during a Test Case, refer to “Using Domains and External Triggering” on page 291. However, you can use an external trigger in on port A with an external trigger out on port B, and vice versa. Figure 157 shows an example.

**Figure 157: Trigger In and Trigger Out**

Current Jammer Test : 1st of 1 test

Name : Create bit error on TCP frame sequence number

Mode : Arm on A, then Trigger + Jam on B [Reverse]

**Diagram:**

- Top path: Data Input A → Arm → Trigger → Jam → Data Output A
- Bottom path: Data Input B → Arm → Trigger → Jam → Data Output B
- Feedback loop: Jam → Trigger (labeled "Trigger Domain B upon Jam")

**Configuration Fields:**

- Arm:** Type: Frame OR  Trigger from Domain A; Name: Any Ethernet; Define: Arm A...
- Trigger:** Type: Frame; Name: Jam on any TCP frame; Define: Trigger B...
- Jam:** Type: Insert Frame  Trigger Domain B upon Jam; Name: ISL frame; Define: Jam B...

**Repeat:** [Vertical arrow icon]

**Control Buttons:**

- Rollback
- Repeat: Repeat Arm -> Trigger -> Jam 7 times (including the first time)
- Timeout: 00 : 05 : 00 ( hr : min : sec )
- Pause: No pause


## Rollback

The Rollback option defines the time or Dword count parameter between the Arm and Trigger events. If the Trigger does not follow the Arm event in the allotted time or Dword count, the Jammer begins looking for the Arm event again. Click **Rollback** to display the dialog shown in Figure 158.



**Note:** This value is saved in terms of Dwords, not time, so keep this in mind if you save a Test Case using a device running at 3.0 Gbps and later open the configuration on a Jammer running at 1.5 Gbps.

**Figure 158: Rollback Condition Dialog**




## Timeout

The timeout option defines the period of time to wait for a specified test to complete before aborting and proceeding to the next test in the suite.

To set the timeout:

- 1 Click **Timeout** to display the dialog box in Figure 159.
- 2 Check **Enable Timeout**.
- 3 Enter the hours, minutes, and seconds you want to wait.


**Figure 159: Timeout Dialog**



- 4 Click **OK**.

## Repeat

Click **Repeat** to open the dialog shown in Figure 160. The Repeat Mode setting allows you to configure what is repeated when using an Arm condition. The first option means the Jammer will match the Arm condition once, then will repeat matching the Trigger condition as specified by the Repeat Count setting below. The second Repeat Mode option means that the Jammer must match the Arm condition each time before looking for a Trigger.

**Figure 160: Repeat Test Dialog**


## Pause

Click **Pause** to open the dialog shown in Figure 161. The Pause setting allows you to insert a pause before the beginning of a test case.

**Figure 161: Pause Test Dialog**

You can also configure options for each Test Case directly in the Test Suite, instead of clicking in the Current Jammer Test pane. Click on the area of the Test Case you want to modify to open the corresponding dialog (Figure 162).

Figure 162: Configuring Options Directly in the Test Suite



---

## Configuring the Arm Condition for 10GigE

The 10GigE Arm condition recognizes specific ordered sets, control characters, or frames.

In 10GigE, you can select from the following:

- **Frame** - Allows you to specify the 10GigE header and up to 114 bytes of payload
- **Ordered Set** - Provides you with predefined ordered sets, or allows you to define a four byte ordered set
- **Control Character** - Allows you to choose from pre-defined control characters

You can save an arm or trigger condition as a .jmt file by clicking the **Save** button in the **Arm** or **Trigger** window. You can load a .jmt file by clicking the **Load** button in the **Arm** or **Trigger** window.

Depending on the Mode you select, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Jam event. If the Mode you select does not include an Arm condition, the **Arm** button is disabled.

To set Arm conditions:

- 1 Select Frame, Ordered Set, or Control Character from the **Type** drop-down menu in the Arm section of the Current Jammer Test window.
- 2 Click on the **Arm** button to open the Arm window.

The window for the condition is displayed (Figure 163). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.


- 3 Set the values as required to specify the Arm condition as part of a unique Arm and Trigger sequence for the specific test.

The following sections describe the available values.

### Setting Frame Conditions for 10GigE Arm

You can specify frame conditions in two ways. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

**Figure 163: Gigabit Ethernet Arm Window for Frames**



To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:

- >> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 164). In the hex view, partially defined hex characters appear as question marks:

X001=?

**Figure 164: Binary Editor Dialog**



Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Highlight the folder and click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Setting Ordered Set Conditions for 10GigE Arm


You can choose from a predefined Ordered Set (LF or RF) or choose user-defined (Figure 165). All choices are four bytes. You can select either /Q/ or /Fsig/ for the first byte of a user-defined ordered set. You can enter hex values for the remaining three bytes.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 165: 10GigE Arm Window-Ordered Sets**




As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.

## Setting Control Character Conditions for 10GigE Arm

You can choose from any standard one byte Control Character (Figure 166). The field below the drop-down menu shows the hex value of the Control Character selected.

**Figure 166: 10GigE Arm Window Control Characters**



---

## Configuring the Trigger Condition for 10GigE

The 10GigE Trigger condition recognizes specific ordered sets, control characters, frames, SOP, and EOP.

In 10GigE, you can select a trigger from the following options:

- Frame - Allows you to specify the 10GigE header and up to 114 bytes of payload
- Ordered Set - Provides you with predefined ordered sets, or allows you to define a four byte ordered set
- Control Character - Allows you to choose from pre-defined control characters
- SOP - Allows you to trigger at the SOP
- EOP - Allows you to trigger at EOP

Depending on the Mode you select in the **Jammer Configuration** window, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Jam event. If the Mode you select does not include an Arm condition, the Arm button remains disabled.

To set Trigger conditions:

- 1 Open the Type drop-down in the Trigger Condition window, and select Frame, Ordered Set, Control Character, SOP, or EOP.


- 2 Click the **Trigger** button in the Xgig Jammer Configuration window.

The window for the condition is displayed (Figure 167). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.

- 3 Set the values as required to specify the Trigger condition as part of a unique Arm and Trigger sequence for the specific test.

The following sections describe the available values.

**Figure 167: 10GigE Trigger Window for Frames**



## Setting Frame Conditions for a 10GigE Trigger

You can specify frame conditions in two ways. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:


>> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 168). In the hex view, partially defined hex characters appear as question marks:

X001=?

**Figure 168: Binary Editor Dialog**




Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Decode Switches Menu

Some templates allow you to specify decode switches (Figure 169). When you load a template that has this option, the **Decode Switches Menu** appears in the upper left corner of the window. The decode switches provide detailed contextual options for decode; for example, further decode of response and data frames. The Decode Switches menu is context sensitive and will only show the decode options available for the specific template you are creating.

**Figure 169: Decode Switches Menu**



**Note:** Once the **Decode Switches** menu appears, it remains visible. However, if you load a template that has no decode options, the menu is greyed out and inactive.

The **Decode Switches** menu is intended to help you create a user-defined template. When editing a User Library template, Decode Switches are stored inside the template so they are still ON the next time you open this particular template.

Decode switches allow you to further decode Response and Data frames that can't be decoded without knowing what the associated command frame is. Below is a description of the switches available for Jammer's Trigger and Insert Frame conditions:

***FCoE Interpretations***


This menu is available for FCoE frames. Fibre Channel over Ethernet (FCoE) is the proposed mapping of Fibre Channel over selected full duplex IEEE 802.3 networks. The **Auto-Detect FCoE** setting automatically detects the version and is the default decode switch. The auto-detect mode works on a per-FCoE frame basis. It assumes that the FCoE frame reserved bits are set to zero and detects which FCoE specification is in use depending on where the zeroes are. If you end up with multiple errors and erroneous decoding of the FCoE frames, it is because the auto-detect mode assumptions do not work with your particular trace. This requires that select manually which FCoE specification to use. Available settings are:

- **Auto-Detect FCoE**  
Automatically detects the specification version by looking at the frame header.
- **T11 FCoE (Latest)**  
Selects the latest draft of the T11 standards committee specification as of this Xgig Analyzer release date.
- **Pre-T11 FCoE Draft**  
Selects the pre-T11 standards committee draft, 07-303v0.pdf.

### FC-SW Accept Interpretation

This menu item is available for FC-SW (Fibre Channel Switch Fabric Internal Link Service) Accept frames. It contains a list of the possible Switch Link Service Accept frame formats.

Figure 170: Decode Switch Options for FC-SW Accept Interpretation



### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Highlight the folder and click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Setting Ordered Set Conditions for a 10GigE Trigger


You can choose from a predefined Ordered Set (LF or RF) or choose user-defined (Figure 171). All choices are four bytes. You can select either /Q/ or /Fsig/ for the first byte of a user-defined ordered set. You can enter hex values for the remaining three bytes.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 171: 10GigE Trigger Window-Ordered Sets**




As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.

## Setting Control Character Conditions for a 10GigE Trigger

You can choose from any standard one byte Control Character (Figure 172). The field below the drop-down menu shows the hex value of the Control Character selected.


**Figure 172: 10GigE Trigger Window Control Characters**



## Setting SOP Trigger for 10GigE

The SOP Trigger has no options to set. When you set the test to trigger at the start of the packet (SOP), the following window appears, which states that for this type of jam test, the Jammer will trigger on an /S/ character, and the entire DWORD (32 bits) will be replaced with (/I/s or “0”s depending on the 64 bit alignment of the /S/ character.

**Figure 173: 10GigE Trigger SOP**




**Note:** When you select SOP as the trigger, the only jam type available is SOP. The jam window contain a message similar to the one above.

## Setting EOP Trigger for 10GigE

The EOP Trigger has no options to set. When you set the test to trigger at the end of the packet (EOP), the following window appears, which states that for this type of jam test, the Jammer will trigger on an /T/ character, and the entire DWORD (32 bits) will be replaced with (/I/s or “0”s depending on the 64 bit alignment of the /T/ character.

**Figure 174: 10GigE Trigger SOP**



**Note:** When you select EOP as the trigger, the only jam type available is EOP. The jam window contain a message similar to the one above.

## Configuring the Jam Definition for 10GigE

The **Jam Definition** window defines how to modify the event specified on the **Trigger Condition** window.

The type of Jam available depends on the type of Trigger selected. In the case of SOP and EOP, the Jam is always the same type as the trigger.

For any Jam Definition, you can specify an optional name at the top of the window. This name is also displayed on the Jammer Configuration window under Mode selection and on the main Xgig Maestro window.

You can save a Jam definition as a .jmj file by clicking the **Save** button in the **Jam** window. You can load a .jmj file by clicking the **Load** button in the **Jam** window.

### Jamming an Ordered Set for 10GigE

If the Trigger Event is an Ordered Set, click the **Jam** button on the Xgig Jammer Configuration window, to open the Ordered Set Jam Definition window (Figure 175).


The Ordered Set Jam Definition window allows you to modify any Ordered Set by replacing it with a different Ordered Set. You can choose from a predefined Ordered Set (LF or RF) or choose user-defined (Figure 175). All choices are four bytes. You can select either /Q/ or /Fsig/ for the first byte of a user-defined ordered set. Then, you can enter hex values for the remaining three bytes.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 175: 10GigE Ordered Set Jam Definition Window**




## Jamming a Control Character for 10GigE

If the Trigger Event is a Control Character, click the **Jam** button on the Xgig Jammer Configuration window, to open the Control Character Jam Definition window (Figure 176).

The Control Character Jam Definition window allows you to modify any Control Character by replacing it with a different Control Character.

**Figure 176: 10GigE Ordered Set Jam Definition Window**



## Jamming a Frame for 10GigE

To define a Jam for a frame:

- 1 Select a Jam from the **Jam Type** drop-down menu.
- 2 Click the **Jam** button to configure the jam.

This section explains the available Jam Types.

- [Replace Frame with Modified Frame](#)
- [Replace Frame with Truncated Frame](#)
- [Replace Frame with Idles](#)
- [Insert Frame](#)
- [Duplicate Frame](#)
- [Insert Dword](#)

### Replace Frame with Modified Frame


Each tab of the Modified Frame window contains options relevant to different frame modifications.

- [Global](#)
- [Delimiters/CRC](#)
- [Header/Payload](#)
- [Embedded Protocol\(s\)](#)

### ***Jam Behavior (All Tabs)***

The **Jam Behavior** pane is located at the bottom of each tab in the **Frame Jam Definition** window. The Jam behavior settings control the number of user-defined header/payload Jams performed relative to the target trigger frame.

**Figure 177: Jam Behavior Selection**



- **Jam until end of trigger frame**

Jams defined in the Header/Payload tab are performed until the end of the target trigger frame (or until an abnormal termination of the frame). All Jams defined that would take place on the original CRC or later are ignored. However, if the frame that is triggered on has more Dwords than the Jams you specify, the remaining Dwords are passed through. The CRC and EOF of the original target trigger frame are always jammed according to the CRC and EOF settings on the SOF/CRC/EOF tab. This is the standard way to Jam a frame.

---

- **Execute full Jam pattern**

All header and payload Jams are executed even if they overwrite beyond the end of the target trigger frame.

If the target trigger frame is longer than the number of Jams defined, then the portion of the target trigger frame that extends after the last defined Jam is overwritten with /I/. If the target trigger frame is shorter, then the Jammer switches back to pass-through immediately after the last defined Jam. Use the control on the Header/Payload tab at the bottom of the List View pane to define how many payload Jams should take place.

The Execute full Jam option is supported only when any template from the FCoE library is loaded into the Header/Payload edit area.

The following **Delimiter** options are supported:

- FCoE SOF modification
- FCoE EOF modification (always enabled)
- FCoE embedded CRC recalculate / replace
- GigE CRC recalculate/ replace

The GigE CRC is recalculated or replaced based on the user input and appended automatically at the end of the payload.




**Note:** For correct FCoE recalculation, any number of Header + payload words can be specified as long as the minimum embedded FCoE frame payload size is 2 Dwords.

---

**Non-FCoE Frames**

Non-FCoE frames can also be supported by using the **Replace Jam Editor** to change the ether type byte field in the payload area, but you must specify the payload size as a multiple of Dword.

**Figure 178: Replace Frame Editor**



**Important:** Currently, when Jamming with modified frame, the delimiter modification may not occur consistently when jamming from a protocol-specific frame to a non-protocol frame and vice-versa. However, the CRC recalculation always occurs.

— For Trigger FCoE -> Jam to Non-FCoE frame, FCoE delimiter modification is applied and overrides the specified field in the Header Payload area. FCoE CRC modification is not applied.

— For Trigger Non-FCoE frame -> Jam to FCoE frame, FCoE delimiter modification is not applied. However, valid FCoE delimiter value can be entered on the Header/Payload tab. FCoE CRC modification is applied.

## Using the Global Tab

Use this tab (Figure 179) to define Jam parameters that apply globally to the frame.

### Global Replace Jam Option


Use the Global Replace Jam Option word to set specific bits on an 8 bit level in a word to 1 or 0 while passing through the remaining bits. You can apply this replace jam option to any word in the frame. Define one Global Replace Jam Option for each Test Case.

To edit these bits:

>> Enter hex values, or double-click on a byte field to open the Binary Editor.

Any bits left as Xs are passed through.

Figure 179: 10GigE Global Tab



### Global 66b Jam Option

Use the Global 66b Jam Option word to set specific bits at the 64 bit level in a word to either 1 or 0 while passing through the remaining bits. You can apply this 66b jam option to any word in the frame. Define one Global 66b Jam Option for each Test Case.

To edit these bits:

>> Enter hex values, or double-click on a byte field to open the Binary Editor.

Any bits left as Xs are passed through.

### Global Bit Errors


The Jammer software can introduce bit errors repeatedly in sequential or random fashion to predefined fields. These bit errors are introduced to the 32-bit form of the target words (not the 40-bit form) so code violations are not created. The Global Bit Errors control allows you four options.

- Select **one bit for all fields** and **randomly**. This causes the Jammer to inject a single bit error in the group of all fields selected in the header or payload for a single Test Case. If the Jammer Test Suite is set to *loop*, then single bit errors are randomly injected into these fields, with one bit for each cycle of the Test Suite.
- Select **one bit for all fields** and **sequentially**. This also injects a single bit error in the group of all fields selected in the header or payload. If the Test Suite is set to loop forever, the bit error walks through all the selected fields.
- Select **one bit in each field** and **randomly** does the same thing as the first option; however, there will be one error for each word selected in the payload or header.
- Select **one bit in each field** and **sequentially** does the same thing as the second option; however, there will be one error for each word selected in the payload or header.

### Using the Delimiters/CRC Tab for Gigabit Ethernet

Use the choices on this tab to modify the FCoE Start of Frame (SOF), FCoE Embedded CRC Modification, FCoE End of Frame (EOF), and GigE Carrier Modification of the original frame (Figure 180).

Figure 180: 10GigE Delimiters/CRC Tab



### Modifying SOF/EOF

To modify these special characters in the target trigger frame:

- 1 Check the appropriate box to select replacement.
- 2 Open the drop-down menu and choose a standard 10GigE Ordered Set, or select User-defined.

If you choose User-defined, you can specify any value.

To edit the value enter a hex value into the byte field or double-click to display the Binary Editor.

### FCoE Embedded CRC/10GigE CRC Options


The CRC options include:

- Not changing the CRC in the original target frame
- Recalculating the CRC to make it correct for the modified data
- Replacing with a user-specified data word

### Using the Header/Payload Tab for 10GigE

You can modify any parameter or word on the 10GigE Header/Payload Tab (Figure 181).

Figure 181: 10GigE Header/Payload Tab



The 10GigE window always shows Jam definitions for the header and 4096 payload words (for the maximum supported 16 Kilobyte jumbo frames). If the frame that is Jammed has less than 4096 payload words, the extra Jam definitions do not take effect. The Jammer does not support 10GigE frames larger than 4096 payload words.

Notice the first line of the Jam Definition (Ether 0001) has only the first two bytes of the Destination Address header field. This is to visually orient the frame in the same manner as the Arm and Trigger Condition windows.

Similar to defining an Arm or Trigger Condition, there are two ways to specify your frame Jam Definition. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Highlight a template in the Template Library tree on the left side of the window.  
Tree View is structured similar to the display on the right side of the Arm and Trigger Condition windows. You can make selections from the tree; this creates the appropriate Replace Jams.
- 2 Click the double right arrow to display the Jam definition on the right side of the window.


Notice the special choice at the bottom left, "Current Trigger." This is a copy of the frame condition you have specified for the Trigger. Click the double right arrow to use this.

When you use a template, the Jam definition is populated with Replace Jams of the specified data, while all other bits are passed through.

To manually edit the values, enter a value into the byte field. An **X** in a nibble passes the original value through.

Selecting the **Replace 8b Jam Mode** radio button opens a dialog that allows you to replace an entire frame either by using a template or manually entering values. The Replace 8b Jam Mode dialog also contains a view of the frame contents, similar to those seen the Arm and Trigger Condition windows. These values correspond to the hex values defined in the center column.

**Figure 182: Replace 8b Jam Mode**



Selecting the **All Jam Modes** radio button opens a dialog that provides the following choices for each word in a frame on the Header/Payload tab:

**Replace 66 bit** - This function allows individual bits to be set to 1, set to 0 or passed through unchanged according to the **Global 66 Jam** option defined on the Global tab.

**Apply Global Replace Jam** - This function allows individual bits to be set to 1, set to 0 or passed through unchanged according to the Global Replace Jam option defined on the Global tab.

**Invert Jam** - Invert defined bits and pass through the rest. Enter 1s at the appropriate bit locations.

**Pass Through Jam** - Pass through the current word unchanged.

**Replace 8b Jam** - Replace nibbles with new values. Each drop-down represents a byte so you can replace a byte with a standard Ordered Set. If you choose User-defined, you can specify any K/D character. To edit these values, enter a value into the byte field or double-click to display the Binary Editor. If you specify a bit as a 0 or 1, you must specify the values of the other three bits in that nibble also. Any nibbles with an X are passed through.

**Set Bits To 0s Jam** - Set defined bits to 0s and pass through the rest. Enter 0s at the appropriate bit locations.

**Set Bits To 1s Jam** - Set defined bits to 1s and pass through the rest. Enter 1s at the appropriate bit locations.

**Apply Global Bit Error Jam** - Apply the Global Bit Error function set on the Global tab.


**Insert Code Violation Jam** - Introduce a predefined, fixed code violation to a byte in that word. Which byte is corrupted depends on the alignment orientation of the frame. The Jam Definition of the word before a Code Violation Jam must always be a Pass Through Jam. A Code Violation Jam cannot be placed in the first word of a frame (Ether 0001).

**Tree View** - Another way to manually edit or view your Jam Definition is to click the **Switch to** button at the lower right corner to toggle between List View and Tree View. The List View interface is described in the procedures in this chapter. Tree View is structured similar to the display on the right side of the Arm and Trigger Condition windows. You can make selections from the tree; this creates the appropriate Replace Jams.

### ***Using the Embedded Protocol(s) Tab for Gigabit Ethernet***

Figure 183 shows the Embedded Protocol(s) tab for Gigabit Ethernet. The available functions are described in this section.

**Figure 183: Gigabit Ethernet Embedded Protocol(s) Tab**



### **Recalculate Checksum**

Select the check boxes to choose recalculation of IP and TCP checksums.

#### **Recalculate IP checksum for valid IP embedded frames**

Checking this option replaces the IP checksum in the Jammed frame with a recalculated value. For the checksum to be inserted properly, the frame, after Jamming takes place, must have a Gigabit Ethernet header EtherType field value of 0x0800 and a valid IP header IHL field.

### Recalculate TCP checksum for valid TCP embedded frames

Checking this option replaces the TCP checksum in the Jammed frame with a recalculated value. For the checksum to be inserted properly, the frame, after Jamming takes place, must meet the same requirements as those listed for the IP checksum, and, in addition, have an accurate IP header Total Length field, an IP header IP Protocol field value of 0x06, and a valid TCP header Data Offset field.

Also, the Jumbo Frames setting (see “GigE Jumbo Frames” on page 25) must be correct for the TCP checksum insertion to work. Each setting shows the frame size limits as well as the corresponding latency.

The TCP checksum recalculation is not available when using the Repeat Jam feature.

### Replace Frame with Truncated Frame

This option truncates the target frame to a shorter length and sends Idles /I/ on top of the remainder of the target frame.

In the Truncate Frame Options window:

- 1 Choose the type of payload you want to truncate from the drop-down menu:
  - Gigabit Ethernet
  - IP
  - TCP
  - FCoE
- 2 Enter the number of bytes you want the payload to be truncated to (this does not include the CRC or other delimiters).

#### ***Gigabit Ethernet Payload***

For a Gigabit Ethernet payload, the **Number of Payload bytes** setting specifies how many bytes to leave after the Gigabit Ethernet header (the first 14 bytes of the frame). You can specify from 0 to 1500 bytes. If the target frame is shorter than the specified number of bytes, then no Jamming occurs. You also have the option to replace the IP checksum with a recalculated value, which also automatically updates the IP header Total Length field.

For any successful truncation, the Gigabit Ethernet CRC is always replaced with a recalculated value.

#### ***IP Payload***

For an IP payload, the **Number of Payload bytes** setting specifies how many bytes to leave after the IP header. You can specify from 0 to 1480 bytes. You also have the option to replace the IP checksum with a recalculated value, which also automatically updates the IP header Total Length field.

For the truncation or the IP checksum/IP header option to work properly, there are some requirements of the incoming target frame. The frame must have a Gigabit Ethernet header EtherType field value of 0x0800, a valid IP header IHL field, and a valid IP header Total Length field. If the Jammed frame is shorter than the specified number of bytes, then no truncation occurs, but the IP checksum can be recalculated if you select it.

For any successful truncation, the Gigabit Ethernet CRC is always replaced with a recalculated value.

### **TCP Payload**

For a TCP payload, the **Number of Payload bytes** setting specifies how many bytes to leave after the TCP header. You can specify from 0 to 1460 bytes. You also have the option to replace the IP checksum with a recalculated value, which also automatically updates the IP header Total Length field.

Each setting shows the frame size limits as well as the corresponding latency. In addition to these limits, the target frame must have an IP header IP Protocol field value of 0x06, a valid TCP header Data Offset field, and a valid IP header Total Length field. If the Jammed frame is shorter than the specified number of bytes, then no truncation occurs, but the IP checksum can be recalculated if you select it.

For any successful truncation, the Gigabit Ethernet CRC is automatically replaced with a recalculated value.

### **FCoE Payload**


For an FCoE payload, the **Payload Dwords** setting specifies how many Dwords (Dword = 4 bytes) to leave after the FCoE header. You can specify from 1 to 4096 Dwords. You also have to specify an EOF for the FCoE frame.

For any successful truncation, both the FCoE and the Gigabit Ethernet CRCs are always replaced with a recalculated value.


### **Replace Frame with Idles**

This option replaces the target frame with /I/ Ordered Sets in the 10GigE Jammer. There are no options to set for this Jam.

**Figure 184: 10GigE - Replace Frame with Idles**





**Figure 186: Binary Editor Dialog**

The frame size is indicated at the top of the window. You can adjust the frame size within the limits defined by the protocol and frame content.

The software automatically recalculates the applicable CRCs, and checksums each time you change the frame. If the CRC or checksum is incorrect, an entry is displayed in the frame contents next to the incorrect CRC or checksum showing the correct value of the CRC. To apply the correct recalculation of the CRC and checksum, click the **Recalculate CRC(s)/Checksum(s)** button at the bottom of the Jam Definition window.

### ***Decode Switches Menu***

Some templates allow you to specify decode switches. When you load a template that has this option, the **Decode Switches Menu** appears in the upper left corner of the window. The decode switches provide detailed contextual options for decode; for example, further decode of response and data frames. The Decode Switches menu is context sensitive and will only show the decode options available for the specific template you are creating.



**Note:** Once the **Decode Switches** menu appears, it remains visible. However, if you load a template that has no decode options, the menu is greyed out and inactive.

The **Decode Switches** menu is intended to help you create a user-defined template. When editing a User Library template, Decode Switches are stored inside the template so they are still ON the next time you open this particular template.

Decode switches allow you to further decode Response and Data frames that can't be decoded without knowing what the associated command frame is. Below is a description of the switches available for Jammer's Trigger and Insert Frame conditions:

### ***FCoE Interpretations***

This menu is available for FCoE frames. Fibre Channel over Ethernet (FCoE) is the proposed mapping of Fibre Channel over selected full duplex IEEE 802.3 networks. The **Auto-Detect FCoE** setting automatically detects the version and is the default decode switch. The auto-detect mode works on a per-FCoE frame basis. It assumes that the FCoE frame reserved bits are set to zero and detects which FCoE specification is in use depending on where the zeroes are. If you end up with multiple errors and erroneous decoding of the FCoE frames, it is because the auto-detect mode assumptions do not work with your particular trace. This requires that select manually which FCoE specification to use. Available settings are:

- **Auto-Detect FCoE**  
Automatically detects the specification version by looking at the frame header.

- **T11 FCoE (Latest)**  
Selects the latest draft of the T11 standards committee specification as of this Xgig Analyzer release date.
- **Pre-T11 FCoE Draft**  
Selects the pre-T11 standards committee draft, 07-303v0.pdf.

### ***FC-ELS Accept Interpretation***

This menu item is available for FC-ELS (Fibre Channel Extended Link Services) Accept frames. It contains a list of the possible Link Services Accept frame formats.

### ***Saving a Frame***

If you create a frame that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

- 1 Make sure the frame contents are displayed in the right pane.
- 2 Type a name for the frame, and click the double left arrow button.

The frame appears in the User Library.

### **Duplicate Frame**

You can duplicate the triggered frame and insert it after the frame. There are no options to set for this Jam.


**Figure 187: 10GigE - Duplicate Frame**



### **Insert Dword**

This option allows you to insert a 32-bit word to the triggered frame at a particular offset. The position of offset 0 begins after the preamble of a frame. The 32-bit data to be inserted is user programmable. Only data characters can be inserted. The GE CRC, FCoE CRC, IP checksum are automatically recalculated.

**Figure 188: 10GigE Insert Dword**



If the repeat jam option is used for an Insert Dword jam, the IPG between frames must be greater than minimum IPG. If the triggered frames are spaced by minimum IPG, the insertion process may be aborted before the specified number of repeat jams, and you will receive an error notice.

# ***Chapter 7***

## **Creating Jammer Test Configurations for 16G FC**

### **In this chapter:**

- [Defining Your Own Test Configurations for 16G FC](#)
- [Using the Jammer Configuration Window for 16G FC](#)
- [Configuring the Arm Condition for 16G FC](#)
- [Configuring the Trigger Condition for 16G FC](#)
- [Configuring the Jam Definition for 16G FC](#)

## Defining Your Own Test Configurations for 16G FC

Xgig Jammer lets you define your own test configurations and save them with or without hardware available.

You can create a configuration from scratch, or you can open and edit an existing configuration. Also, you can edit a configuration in edit only mode, which is independent of any hardware, or you can edit a configuration that is currently loaded to a Jammer device.

To edit a configuration in edit only mode:

>> Double-click on a configuration file in the Configuration manager.


or:

>> Right-click on the configuration file in the Configuration manager and choose **Edit Jammer Configuration** from the context menu.

The edit only mode Jammer Configuration window opens (Figure 189).

This window allows you to set up your own Test Cases, name them, organize them, and save them to files so that you can use them again.

**Figure 189: Edit Only Jammer Configuration Window**




To start a configuration from scratch in edit only mode:

>> Select **New Jammer Configuration** from the context menu or the File menu (Figure 190) on the Xgig Maestro menu bar. Then, select **16 Gig FC Jammer** from the drop down menu.

or:

>> Click the New Configuration icon at the top of the Configuration manager.

**Figure 190: Maestro File Menu**



To save your configuration in edit only mode:

>> Click **Save** at the bottom of the Jammer Configuration window or open the File menu on the Jammer Configuration window and select **Save Configuration** or **Save Configuration As**.

Any changes you make have no effect on actual Jammer devices you control.

To edit a configuration that is loaded to a Jammer port:

>> Click **Configuration...** in the device column.

or:

>> Right-click in the Parameters Status table in the device column to open the context menu and select **Edit configuration**.

or:

>> Click **Operation** in the device column to open the Operation dialog, then click **Config**.

The Xgig Jammer Configuration window in hardware edit mode is displayed (Figure 191).


This window allows you to set up your own Test Cases, name them, and save them to a file so that you can use them again.

Click **Apply** or **OK** and Jammer accepts the changes. They are immediately reflected in the Parameters Status table and affect the Jammer device the next time you run it.

To save your configuration edits:

>> Open the File menu at the top of the Jammer Configuration window and select **Save Configuration As...** or **Save Configuration**.

**Figure 191: Xgig Jammer Configuration Window**



## Using the Jammer Configuration Window for 16G FC

The Jammer Configuration window title bar indicates how many ports it is configuring, the protocol, and the configuration file name, if any. If you are using hardware edit mode, the chassis name, chassis number, slot number, and port number are also listed. The elements of the Jammer Configuration window are described in the following sections.


## Using the Jammer Test Suite Tools for 16G FC

The Jammer Test Suite (left pane) lists the series of Xgig Jammer tests in the order in which you want them to execute. The suite includes one or more tests. The highlighted test appears as the Current Jammer Test (right pane). Each test in the suite executes in sequence with a test reset time of approximately 130 (200 max) milliseconds.

## Creating a Test Suite

When you create a 16G FC Jammer Test Suite, you use the toolbar in the Jammer Test Suite section of the Configuration window (Figure 192).

**Figure 192: 16G FC Jammer Test Suite Toolbar**



The following list describes the icons on the toolbar:

	Cut current test	Removes the highlighted test and holds its contents in the memory buffer.
	Copy current text	Copies the highlighted test to the memory buffer.
	Paste last test cut or copied	Inserts the current memory buffer contents before the currently highlighted test.
	Add new test to bottom of stack	Adds a new blank test to the bottom of the suite.
	Insert new test before current test	Inserts a new blank test above the currently highlighted test.
	Delete current test	Removes the highlighted test from the suite. If only one test is present, then the contents of this test are cleared.
	Move current test down the stack	Moves the highlighted test down one in the test order.
	Move current test up the stack	Moves the highlighted test up one in the test order.
	Toggle view	Toggles Test Suite between Card View and List View.
	Run test suite once or Repeat test suite	When you choose Repeat test suite, the tests run according the settings you define in the Jammer Current Test window.

To duplicate a test at another point in the Test Suite:

- 1 Highlight the test you want to duplicate.
- 2 Click **Copy**.
- 3 Highlight the test in the suite that is just after the point where you want the duplicate test inserted.
- 4 Click **Paste**.


The duplicate test is inserted.

Refer to “Configuring the Arm Condition for 16G FC”, “Configuring the Trigger Condition for 16G FC” and “Configuring the Jam Definition for 16G FC” for information about configuring each test.

## Using the Configuration File Menu

The File menu is the only menu on the menu bar (Figure 193).

**Figure 193: Configuration File Menu**



The choices are:

<b>Open Configuration</b>	Open an existing <code>.tsk</code> configuration file.
<b>Import to Selected Test</b>	Import a Test Case from a <code>.tst</code> file or an entire test suite, <code>.tsk</code> file, to the currently highlighted position. A Test Case is one line in the Jammer Test Suite.
<b>Export Selected Test</b>	Export and save the currently highlighted test to a <code>.tst</code> file.
<b>Save Configuration</b>	Save the entire Test Suite to the <code>.tsk</code> file you currently have loaded.
<b>Save Configuration As</b>	Save the entire Test Suite to a <code>.tsk</code> file with a name you assign to it.
<b>Close</b>	Close the Jammer Configuration Window.

The recently used 16G FC Jammer configuration files appear in the file menu and are loaded when selected.



**Note:** The `.tst` files are only for storing individual Test Cases and swapping them between configuration files. You cannot load `.tst` files directly into a Jammer device on the Xgig Maestro window.

## Using the Current Jammer Test Window for 16G FC

The graphics in this section of the window represent the hardware configuration for the selected test in the Jammer Test Suite (Figure 194).

**Figure 194: Current Jammer Test Window**

Current Jammer Test : 1st of 1 test

Name : Test 2

Mode : Arm on A, then Trigger + Jam on A or Rollback to Arm Reverse

Diagram showing two paths (A and B) through Arm, Trigger, and Jam blocks. Path A (top) starts with Data Input A, goes through Arm, Trigger, and Jam, resulting in Data Output A. Path B (bottom) starts with Data Input B, goes through Arm, Trigger, and Jam, resulting in Data Output B. A Rollback block is shown between the paths, with arrows indicating a return from the Jam block of Path A to the Arm block of Path A.

**Arm**

Type : Frame OR  Trigger from Domain A

Name :  Define : Am A...

**Trigger**

Type : Frame

Name :  Define : Trigger A...

**Jam**

Type : Replace Frame with Modified Frame  Trigger Domain A upon Jam

Name :  Define : Jam A...

**Rollback** Rollback to Arm if Trigger not found within 2147483647 Dwords

**Repeat** Arm -> Trigger -> Jam once (Don't repeat the Test Case)

**Timeout** No timeout

**Pause** No pause


Once

### Mode


For 16G FC, Mode menus are available near the top of the Current Jammer Test window (Figure 195) and also near the top of each Test Case in the Jammer Test Suite window (Figure 196).

The input to path A (on top) is always port A and the input to path B (on the bottom) is always port B. The external trigger input and output that are available on path A always are linked to the domain shown on the Xgig Maestro window as “Domain of port A.” The trigger input and output on the bottom on path B are in the “Domain of port B.”

**Figure 195: Mode Drop-down Menu in Current Jammer Test - Right Pane**



**Figure 196: Mode Drop-down Menu in Test Suite - Left Pane**



## Reverse

You can reverse the direction of the jam by selecting the **Reverse** button.

## Arm and Trigger

To define Arm and Trigger conditions, select a respective Type from each drop-down menu. Then click the Arm or Trigger button to open the corresponding definition window.

You can use an external input as an Arm condition. Check Trigger from Domain A (or B) to enable this feature. You must put the corresponding Jammer port into a domain for this to work properly.

The Trigger event can be in the next Dword after the Arm event in the traffic stream.

## Jam

To define a Jam:

- 1 Select a Type from the drop-down menu, if available.
- 2 Click the Jam button to open the Jam Definition window.

The Jam Definition specifies the modifications to be made to the traffic matching the Trigger Condition.

In addition, the Jammer port can trigger out to the Domain it is in when a Jam takes place. Check Trigger Domain A (or B) upon Jam to enable this feature.



**Note:** If you use an external trigger input to define the Arm condition, then you cannot select the external trigger output for that path in that Test Case, and vice versa. For information regarding using the trigger input and output during a Test Case, refer to “Using Domains and External Triggering” on page 291. However, you can use an external trigger in on port A with an external trigger out on port B, and vice versa. Figure 197 shows an example.

**Figure 197: Trigger In and Trigger Out**

Current Jammer Test : 1st of 1 test

Name : Replace EOF with Idle

Mode : Arm on B, then Trigger + Jam on A [Reverse]

Diagram illustrating the flow of data and control:

- Data Input A → Arm → Trigger → Jam → Data Output A
- Data Input B → Jam → Trigger → Arm → Data Output B

Configuration fields:

- Arm:** Type: Frame OR  Trigger from Domain B. Name: [ ] Define: Am B...
- Trigger:** Type: Frame. Name: trigger on data frame Define: Trigger A...
- Jam:** Type: Replace Frame with Modified Frame  Trigger Domain A upon Jam. Name: replace EOF with Idle Define: Jam A...

Execution options:

- Rollback: [ ]
- Repeat: Arm -> Trigger -> Jam once (Don't repeat the Test Case)
- Timeout: No timeout
- Pause: No pause

Once


## Rollback

The Rollback option defines the time or Dword count parameter between the Arm and Trigger events. If the Trigger does not follow the Arm event in the allotted time or Dword count, the Jammer begins looking for the Arm event again. Click **Rollback** to display the dialog shown in Figure 198.



**Note:** This value is saved in terms of Dwords, not time, so keep this in mind if you save a Test Case using a device running at 3.0 Gbps and later open the configuration on a Jammer running at 1.5 Gbps.

**Figure 198: Rollback Condition Dialog**




## Timeout

The timeout option defines the period of time to wait for a specified test to complete before aborting and proceeding to the next test in the suite.

To set the timeout:

- 1 Click **Timeout** to display the dialog box in Figure 199.
- 2 Check **Enable Timeout**.
- 3 Enter the hours, minutes, and seconds you want to wait.


**Figure 199: Timeout Dialog**



- 4 Click **OK**.


## Repeat

Click **Repeat** to open the dialog shown in Figure 200. The Repeat Mode setting allows you to configure what is repeated when using an Arm condition. The first option means the Jammer will match the Arm condition once, then will repeat matching the Trigger condition as specified by the Repeat Count setting below. The second Repeat Mode option means that the Jammer must match the Arm condition each time before looking for a Trigger.

**Figure 200: Repeat Test Dialog**


## Pause

Click **Pause** to open the dialog shown in Figure 201. The Pause setting allows you to insert a pause before the beginning of a test case.

**Figure 201: Pause Test Dialog**

You can also configure options for each Test Case directly in the Test Suite, instead of clicking in the Current Jammer Test pane. Click on the area of the Test Case you want to modify to open the corresponding dialog (Figure 202).

Figure 202: Configuring Options Directly in the Test Suite



---

## Configuring the Arm Condition for 16G FC

The 16G FC Arm condition recognizes specific ordered sets, control characters, or frames.

In 16G FC, you can select from the following:

- **Frame** - Allows you to specify the 16G FC header and up to 114 bytes of payload
- **Ordered Set** - Provides you with predefined ordered sets, or allows you to define a four byte ordered set
- **Control Character** - Allows you to choose from pre-defined control characters
- **SOF** - Allows you to arm on the SOF
- **EOF** - Allows you to arm on the EOF

You can save an arm or trigger condition as a .jmt file by clicking the **Save** button in the **Arm** or **Trigger** window. You can load a .jmt file by clicking the **Load** button in the **Arm** or **Trigger** window.

Depending on the Mode you select, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Jam event. If the Mode you select does not include an Arm condition, the **Arm** button is disabled.

To set Arm conditions:


- 1 Select Frame, Ordered Set, Control Character, SOF, or EOF from the **Type** drop-down menu in the Arm section of the Current Jammer Test window.
- 2 Click on the **Arm** button to open the Arm window.  
The window for the condition is displayed (Figure 203). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.
- 3 Set the values as required to specify the Arm condition as part of a unique Arm and Trigger sequence for the specific test.

The following sections describe the available values.

### Setting Frame Conditions for 16G FC Arm

You can specify frame conditions in two ways (Figure 203). One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

**Figure 203: Gigabit Ethernet Arm Window for Frames**



To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:


- >> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 204). In the hex view, partially defined hex characters appear as question marks:

X001=?

**Figure 204: Binary Editor Dialog**



Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

- >> Highlight the folder and click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Setting Ordered Set Conditions for 16G FC Arm


You can choose from a predefined Ordered Set (LF or RF) or choose user-defined (Figure 205). All choices are four bytes. You can select either /Q/ or /Fsig/ for the first byte of a user-defined ordered set. You can enter hex values for the remaining three bytes.

To edit the values:

- >> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 205: 16G FC Arm Window-Ordered Sets**



As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.

### Setting Control Character Conditions for 16G FC Arm

You can choose from any standard one byte Control Character (Figure 206). The field below the drop-down menu shows the hex value of the Control Character selected.

**Figure 206: 16G FC Arm Window Control Characters**



### Setting SOF Conditions for 16G FC Arm


You can choose from a predefined Ordered Set representing the SOF or choose user-defined (Figure 207). All choices are four bytes. You can select either /Q/ or /Fsig/ for the first byte of a user-defined ordered set. You can enter hex values for the remaining three bytes.

To edit the values:

- >> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 207: 16G FC Arm Window-SOF**



As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.

## Setting EOF Conditions for 16G FC Arm


You can choose from a predefined Ordered Set representing the EOF or choose user-defined (Figure 208). All choices are four bytes. You can select either /Q/ or /Fsig/ for the first byte of a user-defined ordered set. You can enter hex values for the remaining three bytes.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 208: 16G FC Arm Window-EOF**



As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.

---

## Configuring the Trigger Condition for 16G FC

The 16G FC Trigger condition recognizes specific block type fields, ordered sets, control characters, frames, SOP, and EOP.

In 16G FC, you can select a trigger from the following options:

- Frame - Allows you to specify the 16G FC header and up to 114 bytes of payload
- Ordered Set - Provides you with predefined ordered sets, or allows you to define a four byte ordered set
- Control Character - Allows you to choose from pre-defined control characters
- SOF - Allows you to trigger at the SOF
- EOF - Allows you to trigger at EOF
- 66-bit Block Payload for Ordered Set

Depending on the Mode you select in the **Jammer Configuration** window, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Jam event. If the Mode you select does not include an Arm condition, the Arm button remains disabled.

To set Trigger conditions:


- 1 Open the Type drop-down in the Trigger Condition window, and select Frame, Ordered Set, Control Character, SOP, EOP, or 66-bit Block Payload for Ordered Set.
- 2 Click the **Trigger** button in the Xgig Jammer Configuration window.

The window for the condition is displayed (Figure 209). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.

- 3 Set the values as required to specify the Trigger condition as part of a unique Arm and Trigger sequence for the specific test.

The following sections describe the available values.

**Figure 209: 16G FC Trigger Window for Frames**



## Setting Frame Conditions for a 16G FC Trigger

You can specify frame conditions in two ways. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:


>> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 210). In the hex view, partially defined hex characters appear as question marks:

X001=?

**Figure 210: Binary Editor Dialog**



Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Decode Switches Menu

Some templates allow you to specify decode switches (Figure 211). When you load a template that has this option, the **Decode Switches Menu** appears in the upper left corner of the window. The decode switches provide detailed contextual options for decode; for example, further decode of response and data frames. The Decode Switches menu is context sensitive and will only show the decode options available for the specific template you are creating.



**Note:** Once the **Decode Switches** menu appears, it remains visible. However, if you load a template that has no decode options, the menu is greyed out and inactive.


The **Decode Switches** menu is intended to help you create a user-defined template. When editing a User Library template, Decode Switches are stored inside the template so they are still ON the next time you open this particular template.

Decode switches allow you to further decode Response and Data frames that can't be decoded without knowing what the associated command frame is. Below is a description of the switches available for Jammer's Trigger and Insert Frame conditions:

### FC-SW Accept Interpretation

This menu item is available for FC-SW (Fibre Channel Switch Fabric Internal Link Service) Accept frames. It contains a list of the possible Switch Link Service Accept frame formats.

Figure 211: Decode Switch Options for FC-SW Accept Interpretation



### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

- >> Highlight the folder and click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Setting Ordered Set Conditions for a 16G FC Trigger


You can choose from a predefined Ordered Set (LF or RF) or choose user-defined (Figure 212). All choices are four bytes. You can select either /Q/ or /Fsig/ for the first byte of a user-defined ordered set. You can enter hex values for the remaining three bytes.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 212: 16G FC Trigger Window-Ordered Sets**




As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.

## Setting Control Character Conditions for a 16G FC Trigger

You can choose from any standard one byte Control Character (Figure 213). The field below the drop-down menu shows the hex value of the Control Character selected.

**Figure 213: 16G FC Trigger Window Control Characters**



## Setting SOF Conditions for 16G FC Trigger


You can choose from a predefined Ordered Set representing the SOF or choose user-defined (Figure 214). All choices are four bytes. You can select either /Q/ or /Fsig/ for the first byte of a user-defined ordered set. You can enter hex values for the remaining three bytes.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 214: 16G FC Trigger Window-SOF**



As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.



**Note:** When you select SOF as the trigger, the only jam type available is SOF.

## Setting EOF Conditions for 16G FC Trigger

You can choose from a predefined Ordered Set representing the EOF or choose user-defined (Figure 215). All choices are four bytes. You can select either /Q/ or /Fsig/ for the first byte of a user-defined ordered set. You can enter hex values for the remaining three bytes.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 215: 16G FC Trigger Window-EOF**



As with frame conditions, you can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.




**Note:** When you select EOF as the trigger, the only jam type available is EOF. The jam window contain a message similar to the one above.

### Setting 66-bit Block Payload for Ordered Set Conditions for 16G FC Trigger


You can select to compare the block type field only within the block payload, to compare a ordered set within the block payload, or to compare both.

If you select to **Compare block type field only** (See Figure 216) or **Compare both** (See Figure 217), select a block type field from the **Block type field** drop-down menu. If you select **Compare an ordered set only** or **Compare both**, choose from a predefined Ordered Set or **User-Defined** from the **Ordered set** drop-down menu. You can select either /Q/ or /Fsig/ for part of a user-defined ordered set. You can enter hex values for the remainder of the ordered set by typing values into the fields, or you can double-click a value to bring up the Binary Editor.

**Figure 216: 66-bit Trigger: Compare Block Type Field Only**




**Figure 217: 66-bit Trigger: Compare Both**



If you select **Compare an ordered set only** (See Figure 218), you can choose to compare the ordered set only at the left 32-bit position within the block payload, only at the right 32-bit position within the block payload, or at either position within the block payload. If you selected **Compare both** above, then **Compare ordered set only at right 32-bit position within block payload** is automatically selected, and the other selections are grayed out.


**Figure 218: 66-bit Trigger: Compare An Ordered Set Only**



The trigger definition you create is shown in a pane at the bottom of the **16G FC 66bit Block Payload for Ordered Set Trigger Definition** window. The trigger definition will also be shown in the **16G FC 66bit Block Payload Jam Definition** window to assist you in defining your jam.

If you selected **Compare both** above, and you selected 0x55 as your **Block type field**, and you selected **Compare ordered set at either position within block payload**, all the values for the block payload are shown as “?” (See Figure 219). The values are represented this way to indicate that if the selected ordered set is encountered either in the right 32-bit position, or in the left 32-bit position, or in both positions, then the values will be compared, as 0x55 in the only block type field that will have an ordered set in both the left and right positions at all times.

**Figure 219: 66-bit Trigger: 0x55 Values Represented as Question Marks**



## Configuring the Jam Definition for 16G FC

The **Jam Definition** window defines how to modify the event specified on the **Trigger Condition** window.

The type of Jam available depends on the type of Trigger selected. In the case of SOF, EOF and 66-bit, the Jam is always the same type as the trigger.

For any Jam Definition, you can specify an optional name at the top of the window. This name is also displayed on the Jammer Configuration window under Mode selection and on the main Xgig Maestro window.

You can save a Jam definition as a `.j mj` file by clicking the **Save** button in the **Jam** window. You can load a `.j mj` file by clicking the **Load** button in the **Jam** window.

### Jamming an Ordered Set for 16G FC

If the Trigger Event is an Ordered Set, and you want to Jam with an Ordered Set, select Replace with Modified Ordered Set Jam from the drop-down menu, and click the **Jam** button on the Xgig Jammer Configuration window, to open the Ordered Set Jam Definition window (Figure 220).


The Ordered Set Jam Definition window allows you to modify any Ordered Set by replacing it with a different Ordered Set. You can choose from a predefined Ordered Set or choose user-defined (Figure 205). All choices are four bytes. You can select either `/Q/` or `/Fsig/` for the first byte of a user-defined ordered set. Then, you can enter hex values for the remaining three bytes.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 220: 16G FC Ordered Set Jam Definition Window**




## Jamming a Control Character for 16G FC

If the Trigger Event is a Control Character, click the **Jam** button on the Xgig Jammer Configuration window, to open the Control Character Jam Definition window (Figure 220).

The Control Character Jam Definition window allows you to modify any Control Character by replacing it with a different Control Character.

**Figure 221: 16G FC Control Character Jam Definition Window**



## Jamming the SOF for 16G FC

If the Trigger Event is an SOF, click the **Jam** button on the Xgig Jammer Configuration window, to open the SOF Jam Definition window (Figure 220).


The SOF Jam Definition window allows you to replace the SOF with idles, with a another pre-defined SOF, or with an Ordered Set. You can choose from a predefined Ordered Set or choose user-defined (Figure 205). All choices are four bytes. The first byte is defined as “FB”. You can modify the last three bytes by entering hex values.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 222: 16G FC SOF Jam Definition Window**



## Jamming the EOF for 16G FC

If the Trigger Event is an EOF, click the **Jam** button on the Xgig Jammer Configuration window, to open the EOF Jam Definition window (Figure 220).


The EOF Jam Definition window allows you to replace the EOF with idles, with a another pre-defined EOF, or with an Ordered Set. You can choose from a predefined Ordered Set or choose user-defined (Figure 205). All choices are four bytes. The last byte is defined as “FD”. You can change the first three bytes by entering hex values.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

As in frame conditions, an X indicates “don’t care” and a ? indicates a partially specified hex character.

**Figure 223: 16G FC EOF Jam Definition Window**




## Jamming the Periodic FEC for 16G FC

You can create a test case with Periodic FEC Jam by selecting **Periodic FEC Jam on A and B** from the **Mode** drop-down menu. This mode allows you to configure the number of consecutive bits to be corrupted or define a bit mask to configure which of the first 16 bits will be corrupted. It also allows you to count of the FEC block to be skipped before a FEC Jamming.

A test case with Periodic FEC Jam will not have Arm/Trigger definition. Periodic FEC Jam Type is the only Jam type available for the Jam type. When you click the **Jam** button, the **16G FC Periodic FEC** window appears. This window contains a check box for each port, **Enable Periodic FEC Jamming for Port A** and **Enable Periodic FEC Jamming for Port B**. In addition, you can select to invert a number (1-16) of consecutive bits at the beginning of the FEC Block. You can also skip a number of FEC Blocks between each Jam.

Since Periodic FEC Jamming runs forever, rollback, repeat mode, timeout, and pause settings are disabled for this mode.

Figure 224: 16G FC Periodic FEC Jam Window



## Jamming a Frame for 16G FC

To define a Jam for a frame:

- 1 Select a Jam from the **Jam Type** drop-down menu.
- 2 Click the **Jam** button to configure the Jam.

This section explains the available Jam Types.

- [Replace Frame with Modified Frame](#)
- [Insert Frame](#)
- [Replace Frame with Truncated Frame](#)
- [Replace Frame with Idles](#)
- [Duplicate Frame](#)
- [Insert Dword](#)

### Replace Frame with Modified Frame


Each tab of the Modified Frame window contains options relevant to different frame modifications.

- [Global](#)
- [Delimiters/CRC](#)
- [Header/Payload](#)
- [Embedded Protocol\(s\)](#)

### ***Jam Behavior (All Tabs)***

The **Jam Behavior** pane is located at the bottom of each tab in the **Frame Jam Definition** window. The Jam behavior settings control the number of user-defined header/payload Jams performed relative to the target trigger frame.

**Figure 225: Jam Behavior Selection**



- **Jam until end of trigger frame**

Jams defined in the Header/Payload tab are performed until the end of the target trigger frame (or until an abnormal termination of the frame). All Jams defined that would take place on the original CRC or later are ignored. However, if the frame that is triggered on has more Dwords than the Jams you specify, the remaining Dwords are passed through. The CRC and EOF of the original target trigger frame are always jammed according to the CRC and EOF settings on the SOF/CRC/EOF tab. This is the standard way to Jam a frame.

- **Execute full Jam pattern**

All header and payload Jams are executed even if they overwrite beyond the end of the target trigger frame.

If the target trigger frame is longer than the number of Jams defined, then the portion of the target trigger frame that extends after the last defined Jam is overwritten with /I/. If the target trigger frame is shorter, then the Jammer switches back to pass-through immediately after the last defined Jam. Use the control on the Header/Payload tab at the bottom of the List View pane to define how many payload Jams should take place.

The Execute full Jam option is supported only when any template from the FCoE library is loaded into the Header/Payload edit area.

The following **Delimiter** options are supported:

- SOF modification
- EOF modification (always enabled)
- CRC recalculate / replace / passthrough

## Using the Global Tab

Use this tab (Figure 226) to define Jam parameters that apply globally to the frame.

### Global Replace Jam Option


Use the Global Replace Jam Option word to set specific bits on an 8 bit level in a word to 1 or 0 while passing through the remaining bits. You can apply this replace jam option to any word in the frame. Define one Global Replace Jam Option for each Test Case.

To edit these bits:

>> Enter hex values, or double-click on a byte field to open the Binary Editor.

Any bits left as Xs are passed through.

**Figure 226: 16G FC Global Tab**



### Global 66b Jam Option

Use the Global 66b Jam Option word to set specific bits at the 64 bit level in a word to either 1 or 0 while passing through the remaining bits. You can apply this 66b jam option to any word in the frame. Define one Global 66b Jam Option for each Test Case.

To edit these bits:

>> Enter hex values, or double-click on a byte field to open the Binary Editor.

Any bits left as Xs are passed through.

### Global Bit Errors


The Jammer software can introduce bit errors repeatedly in sequential or random fashion to predefined fields. These bit errors are introduced to the 32-bit form of the target words (not the 40-bit form) so code violations are not created. The Global Bit Errors control allows you four options.

- Select **one bit for all fields** and **randomly**. This causes the Jammer to inject a single bit error in the group of all fields selected in the header or payload for a single Test Case. If the Jammer Test Suite is set to *loop*, then single bit errors are randomly injected into these fields, with one bit for each cycle of the Test Suite.
- Select **one bit for all fields** and **sequentially**. This also injects a single bit error in the group of all fields selected in the header or payload. If the Test Suite is set to loop forever, the bit error walks through all the selected fields.
- Select **one bit in each field** and **randomly** does the same thing as the first option; however, there will be one error for each word selected in the payload or header.
- Select **one bit in each field** and **sequentially** does the same thing as the second option; however, there will be one error for each word selected in the payload or header.

### Using the Delimiters/CRC Tab for Fibre Channel

Use the choices on this tab to modify the Start of Frame (SOF) Modification, CRC Modification, and End of Frame (EOF) Modification (Figure 227).

**Figure 227: 16G FC Delimiters/CRC Tab**



### Modifying SOF/EOF

To modify these special characters in the target trigger frame:

- 1 Check the appropriate box to select replacement.
- 2 Open the drop-down menu and choose a standard 16G FC Ordered Set, or select User-defined.

If you choose User-defined, you can specify any value for the last three bytes for SOF (The first byte is defined as “FB”) or the first three bytes for EOF (The last byte is defined as “FD”).

To edit the value enter a hex value into the byte field or double-click to display the Binary Editor.

### CRC Options


The CRC options include:

- Not changing the CRC in the original target frame
- Recalculating the CRC to make it correct for the modified data
- Replacing with a user-specified data word

### Using the Header/Payload Tab for 16G FC

You can modify any parameter or word on the 16G FC Header/Payload Tab (Figure 228). The maximum size for a payload is 2048 payload Dwords.

Figure 228: 16G FC Header/Payload Tab



Notice the first line of the Jam Definition (Ether 0001) has only the first two bytes of the Destination Address header field. This is to visually orient the frame in the same manner as the Arm and Trigger Condition windows.

Similar to defining an Arm or Trigger Condition, there are two ways to specify your frame Jam Definition. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Highlight a template in the Template Library tree on the left side of the window.  
Tree View is structured similar to the display on the right side of the Arm and Trigger Condition windows. You can make selections from the tree; this creates the appropriate Replace Jams.
- 2 Click the double right arrow to display the Jam definition on the right side of the window.


Notice the special choice at the bottom left, "Current Trigger." This is a copy of the frame condition you have specified for the Trigger. Click the double right arrow to use this.

When you use a template, the Jam definition is populated with Replace Jams of the specified data, while all other bits are passed through.

To manually edit the values, enter a value into the byte field. An **X** in a nibble passes the original value through.

Selecting the **Replace 8b Jam Mode** radio button opens a dialog that allows you to replace an entire frame either by using a template or manually entering values. The Replace 8b Jam Mode dialog also contains a view of the frame contents, similar to those seen the Arm and Trigger Condition windows. These values correspond to the hex values defined in the center column.

**Figure 229: Replace 8b Jam Mode**



Selecting the **All Jam Modes** radio button opens a dialog that provides the following choices for each word in a frame on the Header/Payload tab:

**Apply Global Replace Jam** - This function allows individual bits to be set to 1, set to 0 or passed through unchanged according to the Global Replace Jam option defined on the Global tab.

**Invert Jam** - Invert defined bits and pass through the rest. Enter 1s at the appropriate bit locations.

**Pass Through Jam** - Pass through the current word unchanged.

**Replace 8b Jam** - Replace nibbles with new values. Each drop-down represents a byte so you can replace a byte with a standard Ordered Set. If you choose User-defined, you can specify any K/D character. To edit these values, enter a value into the byte field or double-click to display the Binary Editor. If you specify a bit as a 0 or 1, you must specify the values of the other three bits in that nibble also. Any nibbles with an X are passed through.

**Set Bits To 0s Jam** - Set defined bits to 0s and pass through the rest. Enter 0s at the appropriate bit locations.

**Set Bits To 1s Jam** - Set defined bits to 1s and pass through the rest. Enter 1s at the appropriate bit locations.

**Apply Global Bit Error Jam** - Apply the Global Bit Error function set on the Global tab.


**Insert Code Violation Jam** - Introduce a predefined, fixed code violation to a byte in that word. Which byte is corrupted depends on the alignment orientation of the frame. The Jam Definition of the word before a Code Violation Jam must always be a Pass Through Jam. A Code Violation Jam cannot be placed in the first word of a frame (Ether 0001).

**Tree View** - Another way to manually edit or view your Jam Definition is to click the **Switch to** button at the lower right corner to toggle between List View and Tree View. The List View interface is described in the procedures in this chapter. Tree View is structured similar to the display on the right side of the Arm and Trigger Condition windows. You can make selections from the tree; this creates the appropriate Replace Jams.

### ***Using the Embedded Protocol(s) Tab for Fibre Channel***

Figure 230 shows the Embedded Protocol(s) tab for 16G FC. The available functions are described in this section.

**Figure 230: 16G FC Embedded Protocol(s) Tab**



#### **Recalculate LRC**

Select the check boxes to choose recalculation of the LRC.

#### **Replace LRC with this...**

Checking this option replaces the LRC with a user-defined DWORD.


#### **Disable LRC**

Checking this option disables the LRC and turns the FICON feature off.

### Insert Frame

This option allows you to insert a 16G FC frame after trigger. You can define the header and the payload using the Template Tree on the left pane, or you can manually define the frame.

**Figure 231: 16G FC Jam - Insert Frame Window**



To use a template, click a frame template from the User Library or the Viavi Library in the left pane, then click the double right arrows to apply the template. The frame header and payload information appears on the right side of the window.

Notice the special choice at the bottom left, “Current Trigger.” This is a copy of the frame condition you have specified for the Trigger. Click the double right arrow to use this.

To manually define a frame, type hexadecimal values directly into the center column of the window.

You can modify any parameter or word in the 16G FC header or payload. The maximum size for a header + payload is 540 Dwords. The minimum size is six Dwords.

### ***SOF Modification***

You can choose from a predefined Ordered Set representing the SOF or choose user-defined. All choices are four bytes. For a user-defined ordered set, the first byte is FB. You can enter hex values for the remaining three bytes.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

### ***CRC Modification***

You can choose to either recalculate the correct CRC to make it correct for the modified data or to replace the CRC with a user-specified DWORD.

To edit the values:

>> Enter a hex value.

### ***EOF Modification***

You can choose from a predefined Ordered Set representing the EOF or choose user-defined. All choices are four bytes. For a user-defined ordered set, the last byte is FD. You can enter hex values for the remaining three bytes.

To edit the values:

>> Enter a hex value, or double-click the byte field to open the Binary Editor.

### ***Decode Switches Menu***

Some templates allow you to specify decode switches. When you load a template that has this option, the **Decode Switches Menu** appears in the upper left corner of the window. The decode switches provide detailed contextual options for decode; for example, further decode of response and data frames. The Decode Switches menu is context sensitive and will only show the decode options available for the specific template you are creating.



**Note:** Once the **Decode Switches** menu appears, it remains visible. However, if you load a template that has no decode options, the menu is greyed out and inactive.

---

The **Decode Switches** menu is intended to help you create a user-defined template. When editing a User Library template, Decode Switches are stored inside the template so they are still ON the next time you open this particular template.

Decode switches allow you to further decode Response and Data frames that can't be decoded without knowing what the associated command frame is. Below is a description of the switches available for Jammer's Trigger and Insert Frame conditions:

### ***FCoE Interpretations***

This menu is available for FCoE frames. Fibre Channel over Ethernet (FCoE) is the proposed mapping of Fibre Channel over selected full duplex IEEE 802.3 networks. The **Auto-Detect FCoE** setting automatically detects the version and is the default decode switch. The auto-detect mode works on a per-FCoE frame basis. It assumes that the FCoE frame reserved bits are set to zero and detects which FCoE specification is in use depending on where the zeroes are. If you end up with multiple errors and erroneous decoding of the FCoE frames, it is because the auto-detect mode assumptions do not work with your particular trace. This requires that select manually which FCoE specification to use. Available settings are:

- **Auto-Detect FCoE**  
Automatically detects the specification version by looking at the frame header.
- **T11 FCoE (Latest)**  
Selects the latest draft of the T11 standards committee specification as of this Xgig Analyzer release date.
- **Pre-T11 FCoE Draft**  
Selects the pre-T11 standards committee draft, 07-303v0.pdf.

### ***FC-ELS Accept Interpretation***

This menu item is available for FC-ELS (Fibre Channel Extended Link Services) Accept frames. It contains a list of the possible Link Services Accept frame formats.

### ***Saving a Frame***

If you create a frame that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

- 1 Make sure the frame contents are displayed in the right pane.
- 2 Type a name for the frame, and click the double left arrow button.

The frame appears in the User Library.

### **Replace Frame with Truncated Frame**

This option truncates the target frame to a shorter length and sends Idles /I/ on top of the remainder of the target frame.

In the Truncate Frame Options window:

- 1 Enter the number of bytes you want the payload to be truncated to (this does not include the CRC or other delimiters).
- 2 Select an optional new EOF from the drop-down list, or choose user-defined, and define a four byte EOF.
- 3 Select LRC options. You can recalculate the LRC, replace the LRC with a user-defined FCoE Payload.

## Replace Frame with Idles

This option replaces the target frame with /I/ Ordered Sets in the 16G FC Jammer. There are no options to set for this Jam.


**Figure 232: 16G FC - Replace Frame with Idles**



## Duplicate Frame

You can duplicate the triggered frame and insert it after the frame. There are no options to set for this Jam.


**Figure 233: 16G FC - Duplicate Frame**



## Insert Dword

This option allows you to insert a 32-bit word to the triggered frame at a particular offset. The position of offset 0 begins after the preamble of a frame. The 32-bit data to be inserted is user programmable. Only data characters can be inserted. The GE CRC, FCoE CRC, IP checksum are automatically recalculated.

**Figure 234: 16G FC Insert Dword**




If the repeat jam option is used for an Insert Dword jam, the IPG between frames must be greater than minimum IPG. If the triggered frames are spaced by minimum IPG, the insertion process may be aborted before the specified number of repeat jams, and you will receive an error notice.

## Jamming a 66-bit Block Payload for 16G FC

If the trigger event is a 66-bit Block Payload for Ordered Set, click the **Jam** button on the Xgig Jammer Configuration window, to open the **66-bit Block Payload Jam Definition** window (See Figure 235).

**Figure 235: 66-bit Block Payload Jam Definition Window**




The **Trigger Definition** pane shows the trigger you defined in the **16G FC 66-bit Block Payload for Ordered Set Trigger Definition** window. The information in the trigger definition is what you are going to be replacing with the jam.

Use the **Jam** pane to define which bits you want to jam.


### Sync Bits

First, choose either to **Pass-through Sync Bits** or **Jam Sync Bits**. If you choose to **Jam Sync Bits** (See Figure 236), you can define all 66 bits of the jam using the binary editor provided. As in frame conditions, an X indicates “don’t care”. If you select **Pass-through Sync Bits** (See Figure 237), the pane expands to include details for the block type field.

**Figure 236: 66-bit Jam: Jam Sync Bits**



**Figure 237: 66-bit Jam: Pass Through Sync Bits**



## Block Type Field


The block type field defines what format of data you are using and which two quantities of data (one at the left 32-bit position and one at the right 32-bit position) are present in the 64-bit block payload you are jamming. The left and right quantities are represented in the panes at the bottom of the window.

### *Pass-through the Block Type*

The options you are presented with in the dialog depend on the trigger definition you have defined.


If you select **Pass-through Block Type Field**, and your trigger definition includes **Compare an Ordered Set Only**, then you can define the last 56 bits of the jam using the binary editor provided. As in frame conditions, an X indicates “don’t care”. No panes are shown at the bottom of the window (See Figure 238).

**Figure 238: 66-bit Jam: Compare an Ordered Set Only**



If you select **Pass-through Block Type Field**, and your trigger definition includes **Compare block type field only** or **Compare both**, then the contents of the panes at the bottom of the window depend on the block type field you selected in the trigger. The values from the trigger block type field are passed through to the jam block type field. Based on this block type field, the corresponding left and right jams are displayed (See Figure 239).


**Figure 239: 66-bit Jam: Jam Left/Right Panes Shown**



### Jam Block Type Field


If you select the **Jam Block Type Field**, the bottom panes will change depending on which block type field you select from the drop-down menu. If you select **User-Defined** from the drop-down menu, a binary editor will appear allowing you to define the 64-bit block payload you want to jam (See Figure 240).

**Figure 240: 66-bit Jam: Jam Block Type Field (User-Defined)**



Below the **Jam Block Type Field** option, a pane shows your jam. As you choose different block type fields, the jam in the pane changes (See Figure 241).

**Figure 241: 66-bit Jam: Jam Values Shown in Pane**



**Left and Right Jam Types**

The panes at the bottom of the window provide you with different ways to jam the data at the left 32-bit position and the data at the right 32-bit position in the 64-bit block payload. The pass-through choices are greyed out if your jam definition does not match your trigger definition because the condition is automatically false and, therefore, the values cannot be passed through.

**Jam Control Characters with**

The following choices are available for jamming control characters:

- **pass-through Control Characters**
- **Idle Primitive**
- a user-defined value

The user defined values include four seven-bit Ordered Sets for the left or right Idle jam for a total of 28 bits. These Ordered Sets are labeled either C0-C3 (right) or C4-C7 (left). Select a pre-defined Ordered Set from each drop-down menu, or select **User-Defined** to define your own Ordered Set. You can either type hex values directly into the 0x fields, or double-click an 0x field to open the Binary Editor and define each bit value.

**Jam Ordered Set with**

The following choices are available for jamming an Ordered Set:

- **pass-through Ordered Set**
- **this Ordered Set**  
Select a pre-defined Ordered Set from the drop-down menu.
- **this User-defined Sequence Ordered Set (use [Q])**

Type hex values into the fields at the bottom of the pane, or double-click a value to open the Binary Editor and type in the bit values. The first seven bits of this Ordered Set are not editable.

- **this User-defined Signal Ordered Set (use [Fsig])**

Type hex values into the fields at the bottom of the pane, or double-click a value to open the Binary Editor and type in the bit values. The first seven bits of this Ordered Set are not editable.

- **a user-defined value**

Type hex values into the fields, or double-click a value to open the Binary Editor and type in the bit values.

### ***Jam SOF with***

- **pass-through SOF**

- **this SOF**

Select an SOF from the drop-down menu.

- **a user-defined value**

Type hex values into the fields, or double-click a value to open the Binary Editor and type in the bit values.

### ***Jam EOF with***

- **pass-through EOF**

- **this EOF**

Select an EOF from the drop-down menu.

- **a user-defined value**

Type hex values into the fields, or double-click a value to open the Binary Editor and type in the bit values.

### ***Jam Data with***

- **pass-through value**

- **this value**

Type hex values into the fields, or double-click a value to open the Binary Editor and type in the bit values.

# ***Chapter 8***

## Creating Jammer Test Configurations for PCIe

**In this chapter:**

- [Defining Your Own Test Configurations for PCIe](#)
- [Using the Jammer Configuration Window for PCIe](#)
- [Configuring the Arm Condition for PCIe](#)
- [Configuring the Trigger Condition for PCIe](#)
- [Configuring the Jam Definition for PCIe](#)

## Defining Your Own Test Configurations for PCIe

Xgig Jammer lets you define your own test configurations and save them with or without hardware available for PCIe Generations 1, 2, and 3.

You can create a configuration from scratch, or you can open and edit an existing configuration. Also, you can edit a configuration in edit only mode, which is independent of any hardware, or you can edit a configuration that is currently loaded to a Jammer device.


To edit a configuration in edit only mode:

- >> Double-click on a configuration file in the Configuration manager.
- or:
- >> Right-click on the configuration file in the Configuration manager and choose **Edit Jammer Configuration** from the context menu.

The edit only mode Jammer Configuration window opens (Figure 242).

This window allows you to set up your own Test Cases, name them, organize them, and save them to files so that you can use them again.

**Figure 242: Edit Only Jammer Configuration Window**




To start a configuration from scratch in edit only mode:

- >> Select **New Jammer File** from the context menu or the File menu (Figure 243) on the Xgig Maestro menu bar. Then, select **Pcie Jammer Configuration...** from the drop down menu.

or:

- >> Click the New Configuration icon at the top of the Configuration manager.

**Figure 243: Maestro File Menu**



To save your configuration in edit only mode:

- >> Click **Save** at the bottom of the Jammer Configuration window or open the File menu on the Jammer Configuration window and select **Save Configuration** or **Save Configuration As**.

Any changes you make have no effect on actual Jammer devices you control.

To edit a configuration that is loaded to a Jammer port:

- >> Click **Configuration...** in the device column.

or:

- >> Right-click in the Parameters Status table in the device column to open the context menu and select **Edit configuration**.

or:

- >> Click **Operation** in the device column to open the Operation dialog, then click **Config**.

The Xgig Jammer Configuration window in hardware edit mode is displayed (Figure 244).


This window allows you to set up your own Test Cases, name them, and save them to a file so that you can use them again.

Click **Apply** or **OK** and Jammer accepts the changes. They are immediately reflected in the Parameters Status table and affect the Jammer device the next time you run it.

To save your configuration edits:

- >> Open the File menu at the top of the Jammer Configuration window and select **Save Configuration As...** or **Save Configuration**.

**Figure 244: Xgig Jammer Configuration Window**



## Using the Jammer Configuration Window for PCIe

The Jammer Configuration window title bar indicates how many ports it is configuring, the protocol, and the configuration file name, if any. If you are using hardware edit mode, the chassis name, chassis number, slot number, and port number are also listed. The elements of the Jammer Configuration window are described in the following sections.

## Using the Jammer Test Suite Tools for PCIe

The Jammer Test Suite (left pane) lists the series of Xgig Jammer tests in the order in which you want them to execute. The suite includes one or more tests. The highlighted test appears as the Current Jammer Test (right pane). Each test in the suite executes in sequence with a test reset time of approximately 130 (200 max) milliseconds.

### Creating a Test Suite

When you create a PCIe Jammer Test Suite, you use the toolbar in the Jammer Test Suite section of the Configuration window (Figure 245).

**Figure 245: PCIe Jammer Test Suite Toolbar**



The following list describes the icons on the toolbar:

	Cut current test	Removes the highlighted test and holds its contents in the memory buffer.
	Copy current text	Copies the highlighted test to the memory buffer.
	Paste last test cut or copied	Inserts the current memory buffer contents before the currently highlighted test.
	Add new test to bottom of stack	Adds a new blank test to the bottom of the suite.
	Insert new test before current test	Inserts a new blank test above the currently highlighted test.
	Delete current test	Removes the highlighted test from the suite. If only one test is present, then the contents of this test are cleared.
	Move current test down the stack	Moves the highlighted test down one in the test order.
	Move current test up the stack	Moves the highlighted test up one in the test order.
	Toggle view	Toggles Test Suite between Card View and List View.
	Run test suite once or Repeat test suite	When you choose Repeat test suite, the tests run according the settings you define in the Jammer Current Test window.

To duplicate a test at another point in the Test Suite:

- 1 Highlight the test you want to duplicate.
- 2 Click **Copy**.

- 3 Highlight the test in the suite that is just after the point where you want the duplicate test inserted.
- 4 Click **Paste**.


The duplicate test is inserted.

Refer to “Configuring the Arm Condition for PCIe”, “Configuring the Trigger Condition for PCIe” and “Configuring the Jam Definition for PCIe” for information about configuring each test.

## Using the Configuration File Menu

The File menu is the only menu on the menu bar (Figure 246).

**Figure 246: Configuration File Menu**



The choices are:

<b>Open Configuration</b>	Open an existing <code>.tsk</code> configuration file.
<b>Import to Selected Test</b>	Import a Test Case from a <code>.tst</code> file or an entire test suite, <code>.tsk</code> file, to the currently highlighted position. A Test Case is one line in the Jammer Test Suite.
<b>Export Selected Test</b>	Export and save the currently highlighted test to a <code>.tst</code> file.
<b>Save Configuration</b>	Save the entire Test Suite to the <code>.tsk</code> file you currently have loaded.
<b>Save Configuration As</b>	Save the entire Test Suite to a <code>.tsk</code> file with a name you assign to it.
<b>Close</b>	Close the Jammer Configuration Window.

Also, note that the recently used PCIe Jammer configuration files appear in the file menu and are loaded when selected.



**Note:** The `.tst` files are only for storing individual Test Cases and swapping them between configuration files. You cannot load `.tst` files directly into a Jammer device on the Xgig Maestro window.

## Using the Current Jammer Test Window for PCIe

The graphics in this section of the window represent the hardware configuration for the selected test in the Jammer Test Suite (Figure 247).

**Figure 247: Current Jammer Test Window**

Current Jammer Test : 1st of 1 test

Name : Test 2

Mode : Am on A, then Trigger + Jam on A

Data Input A → Arm → Trigger → Jam → Data Output A

Data Input B → Arm → Trigger → Jam → Data Output B

Arm

Type : TLP OR  Trigger from Domain A

Name : Define : Arm A...

Trigger

Type : TLP

Name : Define : Trigger A...

Jam

Type : Replace TLP with Modified TLP  Trigger Domain A upon Jam

Name : Define : Jam A...

Once

Rollback

Repeat Arm -> Trigger -> Jam once (Don't repeat the Test Case)

Timeout No timeout


Pause No pause

### Mode


For PCIe, Mode menus are available near the top of the Current Jammer Test window (Figure 248) and also near the top of each Test Case in the Jammer Test Suite window (Figure 249).

The input to path A (on top) is always port A and the input to path B (on the bottom) is always port B. The external trigger input and output that are available on path A always are linked to the domain shown on the Xgig Maestro window as “Domain of port A.” The trigger input and output on the bottom on path B are in the “Domain of port B.”

**Figure 248: Mode Drop-down Menu in Current Jammer Test - Right Pane**



**Figure 249: Mode Drop-down Menu in Test Suite - Left Pane**



### Arm and Trigger

To define Arm and Trigger conditions, select a respective Type from each drop-down menu. Then click the Arm or Trigger button to open the corresponding definition window.

You can use an external input as an Arm condition. Check Trigger from Domain A (or B) to enable this feature. You must put the corresponding Jammer port into a domain for this to work properly.

The Trigger event can be in the next Dword after the Arm event in the traffic stream.

### Jam

To define a Jam:

- 1 Select a Type from the drop-down menu, if available.
- 2 Click the Jam button to open the Jam Definition window.

The Jam Definition specifies the modifications to be made to the traffic matching the Trigger Condition.

In addition, the Jammer port can trigger out to the Domain it is in when a Jam takes place. Check Trigger Domain A (or B) upon Jam to enable this feature.



**Note:** If you use an external trigger input to define the Arm condition, then you cannot select the external trigger output for that path in that test case, and vice versa. For information regarding using the trigger input and output during a test case, refer to “Using Domains and External Triggering” on page 291.


## Rollback

The Rollback option **Rollback** parameter defines the time or word count parameter between the Arm and Trigger events. If the Trigger does not follow the Arm event in the allotted time or word count, the Xgig Jammer begins looking for the Arm event again. Click **Rollback** to display the dialog box shown in Figure 250.




**Note:** This value is saved in terms of words, not time, so keep this in mind if you save a Test Case using a device running at 2.5 GT/s and later open the configuration on a Jammer running at 5.0 GT/s.

**Figure 250: Rollback Condition Dialog**



## Repeat

Click the **Repeat** button to open one of the dialog boxes shown in Figure 251. The **Repeat** dialog box uses counters to provide an increased level of control over the Jam allowing you to skip over extraneous instances of the arm or trigger conditions and target the precise data you want to Jam. There are two unique **Repeat** dialog box for PCIe Jammer configuration modes; the “Trigger + Jam” or the “Arm then Trigger + Jam” modes. The Repeat Mode option means that the Jammer must match the specified condition each time before looking for a Trigger.

**Figure 251: PCIe Repeat Dialog Boxes**

A maximum of 32,767 occurrences of the Arm condition can be waited for.


A maximum of 32,767 occurrences of the Trigger condition can be ignored.

## Timeout

The timeout option defines the period of time to wait for a specified test to complete before aborting and proceeding to the next test in the suite.

To set the timeout:


- 1 Click **Timeout** to display the dialog box in Figure 252.
- 2 Check **Enable Timeout**.
- 3 Enter the hours, minutes, and seconds you want to wait.

**Figure 252: Timeout Dialog**


- 4 Click **OK**.

## Pause

Click **Pause** to open the dialog shown in Figure 253. The Pause setting allows you to insert a pause before the beginning of a test case.

**Figure 253: Pause Test Dialog**

You can also configure options for each Test Case directly in the Test Suite, instead of clicking in the Current Jammer Test pane. Click on the area of the Test Case you want to modify to open the corresponding dialog (Figure 254).

**Figure 254: Configuring Options Directly in the Test Suite**

---

## Configuring the Arm Condition for PCIe

The PCIe Arm condition recognizes specific TLPs (Transaction Layer Packets), DLLPs (Data Link Layer Packets), or ordered sets. You can select from the following:

- TLP - Allows you to specify a TLP to set the Arm Condition (see page 261)
- DLLP - Allows you to specify a DLLP to set the Arm Condition (see page 263)
- Ordered Set - Provides you with predefined ordered sets to set the Arm Condition (see page 265)

You can save an arm or trigger condition as a .jmt file by clicking the **Save** button in the **Arm** or **Trigger** window. You can load a .jmt file by clicking the **Load** button in the **Arm** or **Trigger** window.

Depending on the Mode you select, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Jam event. If the Mode you select does not include an Arm condition, the **Arm** button is disabled.

To set Arm conditions:

- 1 Select TLP, DLLP, or Ordered Set from the **Type** drop-down menu in the Arm section of the Current Jammer Test window.
- 2 Click on the **Arm** button to open the Arm window.

The window for the condition is displayed (Figure 255). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.


- 3 Set the values as required to specify the Arm condition as part of a unique Arm and Trigger sequence for the specific test.

The following sections describe the available values.

## Setting TLP Conditions for PCIe Arm

You can specify TLP conditions (Figure 255) by loading a template from the Template Library tree. You can manually specify bits in the TLP.

**Figure 255: PCIe Arm TLP Definition Window**



Selecting a TLP template from the Library list displays the first 32 Dwords of the TLP in the center portion of the window. Depending on the selected template, the first 3 or 4 Dwords of the displayed template are the TLP header.

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Arm Condition.

The condition is indicated on the right side of the window.

To manually specify a string in the TLP:

- >> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 256). In the hex view, partially defined hex characters appear as question marks.

**Figure 256: Binary Editor Dialog**

A way to manually edit the TLP Header is to make selections from the tree view in the right window pane. Selecting all or specific portions of the TLP Header from this tree view will highlight that selection in the Hex code displayed in the center portion of the window.

### **Saving a TLP Arm Definition**

If you create a TLP definition for Arm that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Highlight the folder and click the double left arrow button.


TLP conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first TLP encountered that does not match what you have specified creates a “condition met” event.

For each TLP condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Setting DLLP Conditions for PCIe Arm

You can specify DLLP conditions (Figure 257) by loading a template from the Template Library tree. You can manually specify bits in the DLLP.

**Figure 257: PCIe Arm DLLP Definition Window**



Selecting a DLLP template from the Library list displays the DLLP in the center portion of the window.

To use a template:

- 1 Select a DLLP template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Arm Condition.

The condition is indicated on the right side of the window.

To manually specify a string in the DLLP:

>> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 258). In the hex view, partially defined hex characters appear as question marks.

**Figure 258: Binary Editor Dialog**

A way to manually edit the DLLP is to make selections from the tree view in the right window pane. Selecting all or specific portions of the DLLP from this tree view will highlight that selection in the Hex code displayed in the center portion of the window.

### **Saving a DLLP Arm Definition**

If you create a DLLP definition for Arm that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Highlight the folder and click the double left arrow button.


DLLP conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first DLLP encountered that does not match what you have specified creates a “condition met” event.

For each DLLP condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Setting Ordered Set Conditions for PCIe Arm

You can choose from predefined Ordered Sets for PCIe Generations 1 and 2. You can select from EDB, EIOS, END, FTS, IDL, SDP, SKP, or STP from the Ordered sets in the Library. All Ordered Set choices are four bytes long and are not editable.

**Figure 259: PCIe Arm Ordered Set Definition Window**



The Lane selections near the top of the page allow you to monitor any or all of the lanes to identify the selected Ordered Set to meet the ARM condition using one or more lanes.

Specify the PCIe generation from the tree view in the right window pane. Select either Gen 1 or Gen 2.

You can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.

## Configuring the Trigger Condition for PCIe

The PCIe Trigger condition recognizes specific TLPs (Transaction Layer Packets), DLLPs (Data Link Layer Packets), or ordered sets. You can select from the following:

- TLP - Allows you to specify a TLP to set the Trigger Condition (see page 261)
- DLLP - Allows you to specify a DLLP to set the Trigger Condition (see page 263)
- Ordered Set - Provides you with predefined ordered sets to set the Trigger Condition (see page 265)

Depending on the Mode you select in the **Jammer Configuration** window, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Jam event. If the Mode you select does not include an Arm condition, the Arm button remains disabled.

To set Trigger conditions:

- 1 Open the Type drop-down in the Trigger Condition window, and select TLP, DLLP, or Ordered Set.
- 2 Click the **Trigger** button in the Xgig Jammer Configuration window.



The window for the condition is displayed. If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.


- 3 Set the values as required to specify the Trigger condition as part of a unique Arm and Trigger sequence for the specific test.

The following sections describe the available Trigger Type values.

## Setting TLP Conditions for a PCIe Trigger

You can specify TLP trigger conditions (Figure 260) by loading a template from the template Library tree. You can manually specify bits in the TLP.

**Figure 260: PCIe Trigger TLP Definition Window**



Selecting a TLP template from the Library list displays the first 32 Dwords of the TLP in the center portion of the window. Depending on the selected template, the first 3 or 4 Dwords of the displayed template are the TLP header.

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a string in the TLP:

- >> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 261). In the Hex view, partially defined hex characters appear as question marks.

**Figure 261: Binary Editor Dialog**

A way to manually edit the TLP Header is to make selections from the tree view in the right window pane. Selecting all or specific portions of the TLP Header from this tree view will highlight that selection in the Hex code displayed in the center portion of the window.

### **Saving a TLP Trigger Definition**

If you create a TLP trigger definition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Highlight the folder and click the double left arrow button.


TLP trigger conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first TLP encountered that does not match what you have specified creates a “condition met” event.

For each TLP trigger condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Setting DLLP Conditions for a PCIe Trigger

You can specify DLLP conditions (Figure 262) by loading a template from the Template Library tree. You can manually specify bits in the DLLP.

**Figure 262: PCIe Trigger DLLP Definition Window**



Selecting a DLLP template from the Library list displays the DLLP in the center portion of the window.

To use a template:

- 1 Select a DLLP trigger template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a string in the DLLP:

>> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 258). In the hex view, partially defined hex characters appear as question marks.

**Figure 263: Binary Editor Dialog**

A way to manually edit the DLLP is to make selections from the tree view in the right window pane. Selecting all or specific portions of the DLLP from this tree view will highlight that selection in the Hex code displayed in the center portion of the window.

### **Saving a DLLP Trigger Definition**

If you create a DLLP definition for Trigger that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Highlight the folder and click the double left arrow button.


DLLP conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first DLLP encountered that does not match what you have specified creates a “condition met” event.

For each DLLP condition, you can specify an optional name at the top of the window. This name is also shown on the Jammer Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Setting Ordered Set Conditions for a PCIe Trigger

You can choose from predefined Ordered Sets for PCIe Generation 1 and Generation 2. You can select from EDB, EIOS, END, FTS, IDL, SDP, SKP, or STP from the Ordered sets in the Library. All Ordered Set choices are four bytes long and are not editable.

**Figure 264: PCIe Arm Ordered Set Definition Window**



The Lane selections near the top of the page allow you to monitor any or all of the lanes to identify the selected Ordered Set to meet the Trigger condition using one or more lanes.

Specify the PCIe generation from the tree view in the right window pane. Select either Gen 1 or Gen 2.

You can specify an optional name at the top of the window. This name is also shown in the Jammer Configuration window under the Mode selection and on the main Xgig Maestro window.


## Configuring the Jam Definition for PCIe

The **Jam Definition** window defines how the specified event on the **Trigger Condition** window is modified. The type of Jam that is available depends on the type of Trigger selected.

- Where the Trigger type is TLP, the Jam is always Replace TLP with Modified TLP.
- Where the Trigger type is DLLP, the Jam is always Replace DLLP with Modified DLLP.
- Where the Trigger type is Ordered Set, the Jam is always PCIe Ordered Set Jam Type.

For any Jam definition, you can specify an optional name at the top of the window. This name is also displayed on the Jammer Configuration window under Mode selection and on the main Xgig Maestro window.

Access the Jam definition windows using the Jam button in the Jam area



You can save a Jam definition as a .jmj file by clicking the **Save** button in the **Jam** window. You can load a .jmj file by clicking the **Load** button in the **Jam** window.

## Jamming a TLP for PCIe

With **TLP** as the Trigger Type, the Jam Type is **Replace TLP with Modified TLP**. When you select the **Jam** button, the following Jam Definition window is displayed (Figure 265). This window allows you to define the modified TLP that is used.


There are three tabs: the Header/Payload tab defines the modified TLP;  
the Gen1/2 tab sets the SOP and LCRC modification settings for PCIe Generation 1 and 2;  
the Gen 3 tab sets the STP and LCRC modification settings for PCIe Generation 3.

### Header/Payload Tab


Any parameter in the PCIe header can be modified (Figure 265). Select either the **Replace Jam** or **All Jam Modes** radio button to define the Jam frame.

The Header/Payload tab allows you to select a modified TLP packet from the Library on the left of the window. When the selection is made and you click the “double right arrow” button, the Dwords representing the full PCIe frame are displayed in the Index/Hex columns in the center of the window.

The first 309 Dwords in the Frames Header and Payload are editable. The maximum value of 309 is allowed to be entered. You can set the number of Dwords by changing the value shown below the Index/Hex columns.



**Figure 265: PCIe Jamming TLP Header/Payload Tab Definitions**



Depending on the selected TLP, the header portion is either the first 3 or 4 Dwords. At the right side of the window, the header portions of the TLP are shown. Selecting a specific header portion highlights corresponding the Hex value.

In the Hex view, an X represents a nibble that can be any value (a “don’t care”). Partially defined hex characters appear as question marks.


To modify the Hex value of a highlighted string, double-click the string to display the Binary Editor (Figure 266).

**Figure 266: Binary Editor Dialog**



Select the **All Jam Modes** radio button to open the All Jam Modes screen (see Figure 267). This screen provides access to set the Jam modes. Use the drop down arrow (circled in red) to open the list of available Jam modes.

**Figure 267: All Jam Modes for PCIe TLP**



The header portion (index numbers 00000000 through 00000006) has six available Jam options.




**Note:** Once any option (other than Pass Through Jam and Create Error Jam) is selected for a Dword, only that Jam option plus the Pass Through Jam and Create Error Jam options are available for any of the other Dwords in the header portion.

The payload portion (index numbers 00000007 and above) allows only two Jam choices: Pass Through Jam and Replace Jam




**Note:** If any Dword in the header portion is set to Invert Jam, Set Bit to 0's Jam, or Set Bits to 1's Jam, then only the Pass Through Jam option is available in the payload portion.


- **Pass Through Jam** - Pass through the current word unchanged.
- **Create Error Jam (Gen1/2 Only)** - Check Inject Error for any byte(s) on which you want to send Disparity Errors. This inverts the running disparity at that byte. Selecting the **Description** column displays the following dialog box to make changes:




- Replace Jam** - This function allows you to replace each nibble with a new value. Selecting the **Description** column displays the following dialog box to make changes:




- Invert Jam** - Invert defined bits and pass through the rest. Enter 1s at the appropriate bit locations. Selecting the **Description** column displays the following dialog box to make changes:



- Set Bits To 0's Jam** - Set defined bits to 0's and pass through the rest. Enter 0's at the appropriate bit locations. Selecting the **Description** column displays the following dialog box to make changes:




- Set Bits To 1's Jam** - Set defined bits to 1's and pass through the rest. Enter 1's at the appropriate bit locations. Selecting the **Description** column displays the following dialog box to make changes:



### Gen 1/2 Tab


Selecting the Gen 1/2 tab allows you to define whether you want to pass through or change the TLP’s SOP (Start Of Packet) and LCRC (Link Cyclical Redundancy Check) values.

**Figure 268: PCIe Jamming TLP Gen1/2 Definition Window**



**SOP Modification:** Select either the **Pass through SOP** or **Replace SOP with this...** options. You can replace the SOP with User-Defined Bytes. Byte 0 is fixed and cannot be changed. You can modify Byte 1 and Byte 2 of the SOP. Enter values directly into the byte text boxes.


**Figure 269: SOP Modification Bytes**



Enter values directly into the byte text boxes. The upper 4 bits of Byte 1 are Reserved bits.

As shown in Figure 269, the 12-bit packet sequence number is the lower 4 bits of Byte 1 and the 8 bits of Byte 2. You can also change this number by selecting the **Packet Sequence Number** button to display the Packet Sequence Number dialog box. Enter a value for the packet sequence number into the dialog box and select **OK** to modify the 12-bit value.

**Figure 270: Packet Sequence Number Dialog Box**




**LCRC Modification:** Select either the **Pass through CRC unchanged** or **Recalculate correct CRC** options.

**Gen 3 Tab**


Selecting the Gen 3 tab allows you to define whether you want to pass through or change the TLP’s STP (Start Of Packet) and LCRC (Link Cyclical Redundancy Check) values.

**Figure 271: PCIe Jamming TLP Gen 3 Definition Window**



**STP Modification:** Select either the **Pass through STP** or **Replace STP with this...** options. You can replace the STP with a User-Defined Dword. Double-click the text boxes to enter bit values into the text boxes.

**Figure 272: STP Modification Bytes**



**LCRC Modification:** Select either the **Pass through CRC unchanged** or **Recalculate correct CRC** options.

## Jamming a DLLP for PCIe


With **DLLP** as the Trigger Type, the Jam Type will be **Replace DLLP with Modified DLLP**. When you select the Jam button, the following Jam Definition window is displayed (Figure 273). This window allows you to define the modified DLLP that is used.

There are three tabs: the Header/Payload tab defines the DLLP, the Gen 1/2 tab sets the CRC modification settings, and the Gen 3 tab sets the CRC modification settings.

### Header/Payload Tab

The Header/Payload tab allows you to select a modified DLLP packet from the Library on the left of the window. When the selection is made and you click the “double right arrow” button, the DLLP’s Dword is displayed in the Index/Hex columns in the center of the window.

**Figure 273: PCIe Jamming DLLP Header/Payload Tab Definitions**



The header portions of the selected DLLP are shown. Selecting a specific header portion highlights corresponding the Hex value.

In the Hex view, an X represents a nibble that can be any value (a “don’t care”). Partially defined hex characters appear as question marks.


To modify the Hex value of a highlighted string, double-click the string to display the Binary Editor (Figure 274).

**Figure 274: Binary Editor Dialog**




Select the **All Jam Modes** radio button to open the All Jam Modes screen (see Figure 275). This screen provides access to set the Jam modes using the drop down arrow (circled in red).

**Figure 275: All Jam Modes for PCIe DLLP**




All Jam Modes for DLLP has the following available Jam options.

- **Pass Through Jam** - Pass through the current word unchanged.
- **Replace Jam** - This function allows you to replace each nibble with a new value. Selecting the **Description** column displays the following dialog box to make changes:




- **Create Error Jam (Gen1/2 Only)** - Check Inject Error for any byte(s) on which you want to send Disparity Errors. This inverts the running disparity at that byte. Selecting the **Description** column displays the following dialog box to make changes:



### Gen 1/2 Tab

Selecting the Gen1/2 tab allows you to define whether you want to pass through, recalculate, or replace the DLLP’s CRC value with a User-Defined Word. If you select that you want to replace the CRC value with a User-Defined Word, you set the word’s 2 bytes using the with the buttons at the right which display a drop-down list to select from. You can also inject disparity error on either Byte 0 or Byte 1 by selecting one or both of the **Inject Error** check boxes.


**Figure 276: PCIe Jamming DLLP Gen 1/2 CRC Definitions**



### Gen 3 Tab

Selecting the Gen3 tab allows you to define whether you want to pass through, recalculate, or replace the DLLP's CRC value with a User-Defined Word. If you select that you want to replace the CRC value with a User-Defined Word, you set the word's 2 bytes using the buttons at the right which display a drop-down list to select from.

**Figure 277: PCIe Jamming DLLP Gen 3 CRC Definitions**




## Jamming an Ordered Set for PCIe

If the Trigger Event is an Ordered Set, and you want to Jam with an Ordered Set, select Replace with Modified Ordered Set Jam from the drop-down menu, and click the **Jam** button on the Xgig Jammer Configuration window, to open the Ordered Set Jam Definition window (Figure 278).

With **Ordered Set** as the Trigger Type, the Jam Type will be **PCIe Ordered Set Jam Type**. When you select the Jam button, the following Jam Definition window is displayed (Figure 278). This window allows you to select the modified Ordered Set that is used.

The OS tab allows you to select a modified Ordered Set from the Library on the left of the window. The ordered sets that are available from the library are based on the ordered set that was selected in the Trigger definition. When the ordered set selection is made and you click the “double right arrow” button, the ordered set information (Index, Type, and Description) are displayed on the right side of the window.

**Figure 278: PCIe Jamming Ordered Set Definitions**





# ***Chapter 9***

## **Xgig Jammer Application Notes**


### **In this chapter:**

- [Setting Up the Xgig Jammer and Xgig Analyzer to Capture a Jam](#)
- [Testing Strategies for the Xgig Jammer](#)
- [Replace Frame with Modified Traffic - Fibre Channel](#)
- [Using Domains and External Triggering](#)
- [How to Setup a Single Port Xgig Jammer](#)

## Setting Up the Xgig Jammer and Xgig Analyzer to Capture a Jam

Typically, when setting up a Jammer test, it is customary to have a traffic source, a device under test (DUT), a Jammer and an Analyzer. You can set up the Analyzer to capture the traffic (including the Jam) and the response to the Jam. [Figure 279](#) illustrates the setup.

**Figure 279: Xgig Jammer and Analyzer Setup**



In this setup, ports 1 and 2 are part of a duplex Jammer configured in crossover. The sequence of events is described as follows:

- 1 The source traffic goes into port 1, which is Path A in the Jammer configuration.
- 2 An Arm-Trigger-Jam sequence creates a Jam and the traffic goes out port 2 and then into port 3 of the Analyzer.
- 3 The Analyzer captures the incoming traffic including the Jam.
- 4 The traffic goes to the DUT, which responds.
- 5 The response goes in port 4 of the Analyzer and is also captured.
- 6 The reply goes all the way back to the traffic source by going through ports 4, 3, 2 and 1.

To see the Jam in the capture, you must stop the Analyzer when the Jam data is in the Analyzer's buffer. You can accomplish this in two ways:

- Configure the Analyzer to trigger on traffic such as the Jam itself or around the Jam.
- Setup the Jammer to trigger the Analyzer.

To setup the Jammer to trigger the Analyzer, the Jammer port that generates the trigger and the Analyzer ports that receive the trigger must be in the same Domain. To set this up:

- 1 Using Xgig TraceControl (Analyzer), create an Analyzer Domain using ports 3 and 4.
- 2 Setup port 3 to stop capturing on a trigger, but do not specify a template for the Trigger Condition.
- 3 Set the clock rate on the Analyzer.
- 4 Using Xgig Maestro (Jammer), go to **Port > Port Selection and Domain Setup** on the menu bar.
- 5 Select and Use ports 1 and 2 as a duplex Jammer.
- 6 Select port 1, right-click, and select **Add to Domain...**, then select the Domain in which the Analyzers are.

Now ports 1, 3 and 4 are in the same Domain and will receive each other's triggers.

**Figure 280: Ports Selected for the Same Domain**



- 7 Use a Jammer configuration that triggers on Path A and triggers Domain A.
- 8 Start the Analyzer and Jammer.
- 9 Each time the Jammer Jams, the Analyzer is triggered and stopped.
- 10 View and save the capture.
- 11 Restart the Analyzer for the next Jam.

---

## Testing Strategies for the Xgig Jammer

The Xgig Jammer is designed to verify the operation of a Fibre Channel, Gigabit Ethernet, SAS, or SATA/STP based system by introducing errors in a controlled and repeatable way. The Fibre Channel, Gigabit Ethernet, SAS, or SATA/STP devices under test are assumed to be functional and operating properly with or without the Xgig Jammer system inserted in the link.

The goal of Xgig Jammer testing is to modify the traffic moving between the devices, creating errors, which should be recognized and handled correctly by the network. The range of tests that can be created is unlimited. A Fibre Channel test can include:

- Replace an Open (OPN) sent by a host with an Idle. Does the host recognize that the OPN was never received?
- Modify a frame and leave the CRC unchanged. Does the receiving device recognize a bad frame?
- Modify a SCSI command within a frame and correct the CRC. Does the SCSI error checking software recognize a bad command?

The Xgig Jammer can be used both with black-box and white-box test strategies. For black box testing, the Xgig Jammer can be configured to cause a wide range of potential error conditions. The operating environment should trap, handle, and then report the actions the system took for each of these errors. If an error is not trapped or handled correctly, the Xgig Jammer can be configured to redo the specific test. The details of the traffic to and from the offending device are captured by the Xgig Analyzer for examination.

Using the Xgig Jammer for a white-box test strategy requires a two-stage process. Analyze the error checking software in the device and determine the expected response to specific classes of errors. Exercise all the error checking routines by creating the errors with the Xgig Jammer and then verify that the system responds correctly.

---

## Replace Frame with Modified Traffic - Fibre Channel

The Fibre Channel Jammer frame function “Replace w/ Modified Traffic” allows a large number of ways to alter a target frame. These alterations come in four basic types:

- Simple frame modification
- Frame truncation and/or modification
- Replacement of a frame with multiple frames
- Replacement of a frame with Ordered Sets.

Each of these types is described in this application note. All of the following cases assume you are using the Jam behavior option set to “Jam until end of trigger frame.”

### Simple Frame Modification

The “Replace w/ Modified Traffic” feature always allows you to modify any word of the target frame. The “SOF/CRC/EOF” tab allows you to edit the SOF, CRC, and EOF. The “Header” tab allows you to define Jamming for the first 6 words of the frame. The “Payload” tab allows you to define Jamming for the rest of the frame, for however many words you decide, up to the maximum legal frame length (528 payload words).

During operation, when the Jammer finds the target frame, it steps through each word performing each requested change, until it reaches the target frame's CRC. At this point, even if you have defined extra words in the “Payload” tab, the Jammer ignores these extra instructions and instead follows your instructions for the CRC word and EOF. On the other hand, if you do not specify as many words in the “Payload” tab as are in the target frame, then the Jammer passes through the remaining payload words until the CRC of the target frame.

An example of a simple modification would be leaving the structure of the target frame intact but changing its data. To do this you would leave the SOF as an SOF, modify the data with other data, keep the position of the CRC, and leave the EOF as an EOF.

### Frame Truncation and/or Modification

You can also truncate and modify a frame at the same time. In order to accomplish this, define as many data word modifications as the desired length of the new frame, then select an “Automatic CRC” to be inserted after the data words, followed by an EOF. Fill the rest of the “Payload” tab with “Idles” or some other Ordered Sets. To be safe, define the full amount of 528 words, in case the target frame is very large.

Regardless of how many payload words you specify, or how long the target frame is, when the Jammer reaches the target frame's CRC and EOF, it looks for specific instructions regarding them (on the “SOF/CRC/EOF” tab). Do not forget to replace both the CRC and EOF with the desired Ordered Sets.

This form of truncation does not work correctly if the target frame is shorter than the new frame you have defined. The Jammer would modify the target frame up to the point of its CRC, and then jump to the CRC and EOF instructions, which are defined as other Ordered Sets. The resulting frame fragment would have an SOF, some data words, and then whatever Ordered Sets you defined for the CRC and EOF words.

Another Frame Jamming feature “Replace Frame w/ Truncated Frame” is a simple way to access a subset of this functionality. The feature asks for only two simple inputs from the user:

- The number of words the new frame should have
- A new EOF

The Jammer passes through the original frame (without modifying) until it reaches the specified length, and then sends a good CRC and the user-specified EOF, followed by “Idles” to replace the rest of the target frame. The feature automatically deals safely with the case where the target frame is shorter than the new specified length. In this case, the frame is simply passed through with no changes, but the new EOF is used.

## Replacement of Frame with Multiple Frames

Perhaps the most advanced use of the “Replace w/ Modified Traffic” feature is to replace the target frame with more than one frame. This is probably only wise if you know the target frame is large, because the replacement traffic you specify must fit in the space from the SOF to the EOF of the target frame.

To create multiple frames, repeat patterns of SOF, 6 or more data words, an automatic CRC and an EOF, throughout the Jam definition. Make sure to define some number of Ordered Sets, for example, “Idles” between each frame. Remember to specify what to do with the target frame’s SOF, CRC, and EOF (on the “SOF/CRC/EOF” tab). Either use them as part of your smaller frames or replace them with other Ordered Sets. As noted previously, the CRC and EOF functionality take precedence over payload words.

The LRC options you set on the “Global” tab take place for all frames you create or alter. The LRC is the eighth payload word, that is, 14 words after any SOF. Frames shorter than 14 data words are not affected. Any Ordered Set between an SOF and the LRC word cancels the word count, so that the global LRC option is ignored for that “frame” and the Jammer defers to what was specified in the “Payload” tab.

## Replacement of Frame with Ordered Sets

Choose Ordered Sets to replace the SOF, CRC, and EOF of the target frame (“SOF/CRC/EOF” tab), as well as all entries in the “Header” and “Payload” tabs. Make sure to specify enough payload words to cover the largest possible expected target frame (defining all 528 payload words is the safest method).

Note that the Frame Jamming feature “Replace Frame w/ Idles” is a simple way to access a subset of this functionality. This feature replaces the target frame with only “Idles.” It automatically adjusts for any size of target frame.

## Using Domains and External Triggering

This is a complex example of using domains and external triggering.

For this example, you want to have an Xgig duplex Jammer Arm on a TTL input, then Trigger on a frame and Jam it, and trigger an Xgig Analyzer in the same Sync Group. You want the Jam to occur on port A.


- 1 Set the Jammer Test Case mode to Arm B Followed by Trigger A Jams A.
- 2 For the Arm B, check Trigger from Domain B.
- 3 Set up the desired Trigger condition and Jam definition for the frame.
- 4 Check Trigger Domain A.
- 5 In the Port Selection and Domain Setup window, put port B in the same Domain as the TTL input connector.
- 6 Add port A to the domain of the Xgig Analyzer ports you are using to capture.

When the TTL input connector triggers, it will trigger the domain containing port B and will Arm the Jammer. When the Jammer finds its Trigger condition, it will Jam and then trigger the domain that contains the Analyzer ports.

## How to Setup a Single Port Xgig Jammer

When you lock two Jammer ports separately as simplex Jammers, they always have a data path without crossover. To use a Jammer port with an Analyzer on the same blade, the connections would be made as in Figure 281.

**Figure 281: Single Port Jammer Setup**



The connection at port 1 requires that the transmit path and receive path go to different locations, so the cables must be separate. Therefore this sort of setup is probably not possible with copper connections.

When using a single port Jammer setup, the GUI refers only to path A and port A because the device has only one port. This is still true if you use port 2 as a single port Jammer.

Remember that you could use the Jammer on port 2 as part of another completely different testing setup (however, it must still share the same protocol and clock rate settings).



**Note:** If you load a duplex Jammer configuration file (one that utilizes path B) to a single port simplex Jammer, you receive a warning that the configuration will be “flattened.” This means that any path B settings get transferred to path A. If the duplex port configuration uses both a trigger from domain (input) and trigger domain (output), then only the trigger domain (output) is used after flattening (and therefore you should review such configurations before use).

## ***PART TWO:*** Using Xgig Delay Emulator



# ***Chapter 10***

## Introducing Xgig Delay Emulator

### **In this chapter:**

- Xgig Delay Emulator Overview
- Features
- Cabling

## Xgig Delay Emulator Overview

The Xgig Delay Emulator includes hardware (Xgig Multi-function Blade) and software that performs real-time delay modification for the 10GigE protocol. You can use the Delay Emulator with Xgig Analyzers to capture and display the network traffic associated with the delay modification.

The Xgig Delay Emulator should be used as a digital retiming device. The Xgig Delay Emulator blade re-times the data and re-transmits it with a new clock transparent to the data link (it passes every bit of data.) The Xgig Delay Emulator blade functions in any 10GigE architecture. It does not log onto a loop, switch, or fabric; it only passes data between two devices. The Xgig Delay Emulator blade can pass 10GigE traffic, or it can recognize an event or event sequence and modify the traffic. The events must be 10GigE frames. A specific frame or series of frames can be modified in two ways: inserting a variety of delays or reordering a frame.

## Features

Xgig Delay Emulator has the following features:

## Operation

The Xgig Delay Emulator system (hardware and software), allows you to perform the following operations:

- Emulate network scenarios such as distance, switch processing delay, jitter, and multipath routing.
- Simulate network congestion.

You can use simulated congestion to help characterize effects on QoS and bandwidth throttle.

## Capabilities

The Xgig Delay Emulator has the following capabilities:

- Operates with 10GigE protocol
- Supports the 10.3125 Gbps line rate.
- Supports frames from 64 bytes to 9k jumbo frames.
- Operates in digital re-timing mode at all times.
- Contains standard editing features such as copy, cut, paste, add, insert, and delete to edit the test suite. An option lets you run the test suite forever in a repeating loop.
- Provides the appropriate MAC (media access control) layer when you load the application.

### Triggering Capabilities

The Xgig Delay Emulator module provides the following Triggering capabilities:

- You have two levels of triggering:
  - Arm (first level)
  - Trigger (second level)
- You can set an Arm condition as a specific DWord within a frame.
- You can set an Trigger condition as a specific DWord within a frame.

### Delay Capabilities

- The Xgig Delay Emulator can perform the following types of Delays on the contents of frames:
  - Fixed delay
  - Jitter delay
  - Ramp down delay
  - Ramp up delay
  - Random delay
  - Random Jitter delay
- The minimum delay through the system is approximately 30 microseconds.
- The maximum programmable delay is approximately 1.3 seconds.
- A test supports up to eight queues.
- You can define **Frame Drop** mode and rate.

### Reorder Capabilities

The Xgig Delay Emulator can perform the following types of frame reorder:

- Consecutive reorder
- Trigger reorder


## New Features for Xgig Delay Emulator

There are no new features for the Xgig Jammer 8.1 release.

## Cabling


Test Setups containing Delay Emulator require special cabling if you want to use them to test data in both directions. Because Delay Emulator uses only the odd port of a port pair, data flows only from the Rx connector of Port one to the Tx connector of port two. The flow of data in the opposite direction, from the Rx connector of port two to the Tx connector of port one is not possible because port two is not used. Therefore, if you want to perform delay emulation on traffic flowing in both directions between two devices, you must use a second blade running Delay Emulator. See the example below.

**Figure 282: Delay Emulator Test Setup**



The following diagram shows the cabling for the Delay Emulator in the example above.

**Figure 283: Delay Emulator Cabling Diagram**



One cable connects the Load Tester to the Delay Emulator. The cable for the Tx Rx connection comes out of port 2 of the Load Tester then splits. The Rx cable plugs into the Tx connector of port 2 of the second Delay Emulator. The Tx cable plugs into the Rx connector of port 1 of the first Delay Emulator.

Another cable connects the Delay Emulator to Analyzer. The cable for the Tx Rx connection comes out of port 2 of the Analyzer then splits. The Rx cable plugs into the Tx connector of port 2 of the first Delay Emulator. The Tx cable plugs into the Rx port of port 1 of the second Delay Emulator.

A third cable connects the Load Tester to the Analyzer through port 1 of both blades.

# ***Chapter 11***

## Using the Delay Emulator Tab


### **In this chapter:**

- Using the Configuration Manager in Delay Emulator
- Using the Parameters Status Table in Delay Emulator
- Using the Parameters Status Context Menu in Delay Emulator
- Using the Ports Manager in Delay Emulator
- Using the Real Time Tab
- Using the Log Manager in Delay Emulator
- Customizing the Appearance of the Maestro/Delay Emulator Main Window
- Performing Configuration Tasks in Delay Emulator
- Running the Test Suite on a Delay Emulator Device

After you have discovered and locked the Delay Emulator ports that you want to use and have set up your capturing and monitoring applications, such as Xgig Analyzer, you are ready to run the Xgig Delay Emulator application. This chapter provides an overview of the Delay Emulator tab, on the Xgig Maestro main window, and its functions; it also includes steps to run predefined tests supplied with the Xgig Delay Emulator application or tests you have defined and saved.

You should have launched Xgig Maestro and locked at least one device as described in the *Xgig Maestro Introduction Guide*. The Xgig Maestro window is displayed with the Delay Emulator tab on the right. This tab is where you operate the Delay Emulators you have locked.

**Figure 284: Xgig Delay Emulator Tab on Xgig Maestro Window**




## Using the Configuration Manager in Delay Emulator

The Configuration manager (Figure 285) is associated with the device function tab. This window also displays the configuration files specific to the function tab displayed. The **Sample Configurations** folder includes configurations that are provided with the application. The **User Configurations** folder is where the configurations you create are saved. The **Most Recently Used** folder allows you easy access to those configuration files most recently used. The Configuration Manager also includes a list of all the drives on your system allowing you to locate any configuration files on your system quickly.

The Configuration manager has the following features:


- The Configuration manager provides a list of test configurations organized into folders and lists all the drives on your system allowing you to easily browse to locate all of your configuration files on your system

**Figure 285: File Location in Delay Emulator Configuration Manager**



- List of configuration files in a folder

**Figure 286: Configuration Files and Description Pane**



- Description pane
  - When you select a configuration file in the list, a description of the file is displayed in the description pane below. It also displays the name of the file, the path where the file is located, the size of the file, the date and time when the file was created, the date and time the file was modified, whether the file is read-only and the Map path where the file is located on your system.
  - When you click the Show/Hide button below the Description pane, you display or hide this pane.
- Drag and drop files
 

You can drag any configuration from the Configuration manager list onto a device column to load it.
- Tool bar that lets you create, load, copy, cut, and paste configuration files. See “[Configuration Manager Tool Bar in Delay Emulator](#)” on page 303 for more information on this tool bar.
- Context menu
 

Select a configuration file name, and right-click to display a menu where you can choose to create and edit configuration files, and additional operations. See “[Configuration Manager Context Menu in Delay Emulator](#)” on page 304 for more information about these menus.
- Browse to map folders of files stored in locations other than the default Sample and User Configuration folders.

## Configuration Manager Tool Bar in Delay Emulator

The Configuration manager tool bar (Figure 287) allows you to perform the following functions:

**New Configuration**  allows you to open the Configuration window and create a new Delay Emulator configuration from scratch.

**New Folder**  allows you to create a new folder.

**Load**  allows you to load a configuration file into a port or ports. This icon is only active when a port has been locked and is selected in the Port Manager. See “[Loading Delay Emulator Configuration Files](#)” for details.

**Map**  allows you to select a folder that you want to be listed in the Configuration Manager for the selected function tab.

**Unmap**  allows you to unmap a folder that has been mapped.

**Cut**  allows you to cut a file from its current location. This is not the same as deleting a file.

**Copy**  allows you to copy a file.

**Paste**  allows you to paste a file you have cut or copied.

**Delete**  allows you to delete a file or folder.

**Path**  allows you to go up one level in the folder tree. This field next to this icon displays the current folder name.

**Refresh**  allows you to refresh the Configuration Files and Description pane.

**Show/Hide**  allows you to show or hide the details for the selected file. These details appear in the lower section of the Configuration Manager pane.


**View**  allows you to view the files in the Configuration Manager as a list including only the file name or to view the details of the files in the list.

**Figure 287: Configuration Manager Tool Bar in Delay Emulator**



## Configuration Manager Context Menu in Delay Emulator

**Figure 288: Configuration Manager Context Menu in Delay Emulator**




Right-click in the list to choose the following actions from the context-sensitive menu:

- **Up**  
Displays the contents one folder level up from the current display.
- **New Delay Emulator Configuration**  
Allows you to open either a new Delay-Mode configuration or a Re-order Mode configuration.
- **New Folder**  
Opens the Configuration manager dialog where you can enter the name of a new folder you want to add.
- **Edit Delay Emulator Configuration**  
Opens the file highlighted in the list, the same as double-clicking on the file name.
- **Load Delay Emulator Configuration into Selected Port(s)**  
Loads the file highlighted in the list into the port(s) selected in the Ports Manager. See “Using the Ports Manager in Delay Emulator.”
- **Cut**  
Removes a selected file or folder from the list.
- **Copy**  
Copies a selected file or folder to a clipboard making it available to paste in another location.

- **Paste**  
Pastes a file or folder you cut or copied to the location you choose.
- **Rename**  
Opens a dialog with the current file or folder name displayed in an entry field that you can modify. It also shows the protocol, path, and current file or folder name.
- **Delete**  
Opens a dialog where you can confirm whether you want to delete the highlighted file (configuration) or folder from the list.
- **Must Confirm Delete**  
Sets this choice as a preference that opens a dialog to confirm that you want to delete a file or folder from the list. When you select it, a check mark is displayed next to it. It is selected by default.
- **Map Folder**  
Opens the Map Folder dialog box that lets you map a folder to a name of your choice.

**Figure 289: Map Folder dialog box**



Enter a name of your choice in the Mapped Folder Name field, and use the **Browse** button to select the folder on your system or network you want to map to this name.

- **Edit Mapping Path**  
Allows you to edit the mapping path.
- **Unmap Folder**  
Removes a highlighted mapped folder from the Configuration manager.
- **Explore**  
Opens a Windows Explorer window showing the directory where the current configuration files are located.
- **Open Command Prompt**  
Opens a Windows Command Prompt window showing the directory where the current configuration files are located.
- **Refresh**  
Refreshes the Configuration Manager window.

- **View**

Has two choices:

- List

Displays the list of files or folders in the path you choose.

- Details

Displays the list of files or folders with the size and modification date.

## Using the Parameters Status Table in Delay Emulator

The Parameters Status pane contains two tabs, **All Ports** and **Delay/Reorder Frame**. The **All Ports** tab shows all devices that have been locked. The **Delay/Reorder Frame** tab shows the devices locked according to their mode. Each Delay Emulator device is displayed by a column on the Delay Emulator tab (Figure 290). At the top of each column is the chassis name and the chassis number, the slot number, and port number(s) in parenthesis.

The locked ports can be divided in a sorted manner in the **Delay/Reorder Frame** tab or displayed unsorted in the **All Ports** tab.

To configure how to display the ports in the Parameters Status Table, click on the Views button and do the following:

Select or unselect **Configuration** to display or hide the Configurations tab and Parameters tab where you manage Delay Emulator configuration files and select the Parameters to display, respectively.

Select or unselect **Port Selection** to display or hide the Port Selection table.

Click **Ports** to display the options for displaying the ports in the Parameters Status Table.

**Tile Horizontally** - Select this option to display the Delay pane before the Reorder Frame pane. This allows you to drag and drop a port from one mode to the other.

**Tile Vertically** - Select this option to display the Delay pane beside the Reorder Frame pane. This allows you to drag and drop a port from one mode to the other.

**Tabs** - Select this option to display the Delay pane and Reorder Frame pane as tabs.

Each Delay Emulator port is displayed by a column on the Parameters Status table (Figure 290). At the top of each column is the protocol, the chassis name, and in parenthesis the chassis number, the slot number and port number(s).

**Figure 290: Delay Emulator Parameters Status table**

Delay / Reorder Frame		All Ports
Delay		Reorder Frame
<b>10 GE PLATSAS1 (1.4.1)</b>		
State		Stopped
Link State		No Signal
Configuration...		( Not configured from a file )
Start / Stop		Start
Pause / Resume		Pause
Skip		Skip
Operation		Operation
Status		
Time Since Test Started		00 : 00 : 00
Configuration Repeat Count		N/A
Test Timeout Mode		N/A
Test Timeout		N/A
Log		No log available
Settings		
Config Type		Delay
Protocol Settings		10 Gigabit Ethernet
Clock rate settings		10.3125 Gbps
Current test		
Index		N/A
Name		N/A
Test Mode		N/A

The first column on the tab is the legend for each row in the device columns and contains the following categories for Delay and for Reorder Frame:

- State
- Link State
- Configuration
- Status
- Settings

## Parameters Category Descriptions

### **State**

This row shows the state of the Delay Emulator: Disconnected, Connecting, Starting, Running, Stopping, Skipping, Pausing, Paused, Stopped

### **Link State**

Indicating the state of the signal, whether it is present, no signal is present, or the signal has been lost.

### **Configuration**

Displays the name of the configuration file, if any, loaded into the port.

### **Start/Stop**

Click this button to Start or Stop a test. The green arrow icon indicates you can click the button to Start the test. The red box indicates you can click the button to stop the test.

### **Pause/Resume**

Click this button to pause or resume a test suite that is running.

### **Skip**

Click this button to skip a test that is running and move to the next test in the suite.

### **Operation**

Opens the Operation dialog box

### **Status Category**

This category gives the status of the test suite that you have loaded into the Delay Emulator.

#### ***Time Since Test Started***

Indicates the time elapsed since the current test started.

#### ***Configuration Repeat Count***

Indicated how many times the test suite has been repeated.

#### ***Test Timeout Mode***

Indicates whether the timeout option is set.

#### ***Test Timeout***

Indicates the time value for the timeout option.

***Log***

Indicates if a log from the last operation is available for viewing.

**Settings Category**

This category indicates the current physical setup of the Delay Emulator device. You can change most of the settings in this category by using the Parameters Status context menu for each device you have locked.

***Config Type***

Indicates whether the configuration is delay-mode or reorder-mode.

***Protocol***

Indicates the current protocol setting for the Delay Emulator.

***Clock Rate***

Indicates the Delay Emulator clock rate.

**Current Test Category**

This category shows the condition of the test currently loaded in the Delay Emulator device.

***Index***

Indicates the number of the test within the queue that is being executed.

***Name***

Indicates the name of the test currently loaded in the Delay Emulator device.

***Test Mode***

Indicates whether the test mode is Arm, Trigger or Trigger


## Using the Parameters Status Context Menu in Delay Emulator

Right-click on the Parameters Status table to display the context menus shown in Figure 291. Each protocol has a unique context menu. The available operations are displayed for the column in which you click. This menu provides controls for configuration files, setting the data path, logging test activity, removing a Delay Emulator from the Parameters Status table, and the appearance of the status table.

Refer to the following pages for more information about the how to use the context menu choices:

- “Using the Parameters Status Table in Delay Emulator” on page 307 for information about the parameter settings you make from these menus.
- “Running the Test Suite on a Delay Emulator Device” on page 331 for information about running the Delay Emulator.
- “Using the Log Manager in Delay Emulator” on page 320 for choosing log preferences.
- “Performing Configuration Tasks in Delay Emulator” on page 329 for information about using the Load configuration file, Save configuration file, Reset configuration, and Edit configuration selections from these menus.

**Figure 291: Delay Emulator Parameters Status table Context Menus**



## Log

This setting allows you to view the log, open the options menu for the log, or save the current log.

## Change Port to Delay/Reorder Mode

This setting changes the configuration applied to the selected ports to the other mode. If the current configuration is a delay-mode configuration, this setting changes the configuration to reorder-mode and visa versa. The current configuration remains as a saved file. A new blank configuration is applied to the ports containing zero tests.

This option allows you to immediately create a blank configuration and begin editing it while it is loaded into to the hardware.

## Using the Ports Manager in Delay Emulator

The Ports manager displays details about the ports you have locked. It shows the protocol, chassis name (with chassis number, slot number, and port numbers), and other port specific information. You can sort the rows from first to last or last to first by clicking the column heading. For more information about Xgig slot positions and numbering, refer to the Xgig Family Hardware Guide included with the product CD.



**Note:** If you are disconnected due to a network problem, you can reconnect to the ports by using the Port Selection and Domain Setup window.

**Figure 292: Delay Emulator Ports Manager**



The following icons are displayed on the menu bar:



### Select All Ports

Selects all ports in the Ports Manager.



### Unselect All Ports

Unselect all ports in the Ports Manager.



### Load Configuration to Selected Ports

Load the selected configuration file to all selected ports in the Ports Manager.



### Start Selected Ports

Start BERT operation on the selected ports in the Ports Manager.



### Stop Selected Ports

Stop BERT operation on the selected ports in the Ports Manager.



### Show Properties of Selected Ports

Display the Port Properties dialog box, with information on the selected function, protocol, and clock rate (speed). It also shows the chassis name, IP address, slot and port(s).



### Disconnect Selected Ports

Disconnect the selected ports in the Ports Manager.




### Disconnect All Ports

Disconnect all ports in the Ports Manager.

## Actions Button

The **Actions** button contains menus for **Toggle Display**. See [Figure 293](#).

**Figure 293: Actions Button Options**



### Toggle Display

This option toggles between a horizontal and vertical view of the ports.

## Ports Manager Columns

The Ports Manager includes the following columns:

### Select

Indicates whether you want to select a port pair

### Show

Indicates whether you want to show this port pair in the Ports Manager.

### Operation

**Operation** is a button you press to display the Operation bar for the device you are using. Refer to [“Running the Test Suite on a Delay Emulator Device”](#) on page 331 for additional information.

### State

This column displays the state of the device under test.


### Address

This column displays the chassis name and the chassis number, the slot number, and port number(s) in parenthesis.

## Using the Ports Manager Context Menu

You can right-click in the Ports Manager to open the context menu (Figure 294).

**Figure 294: Ports Manager Context Menu**



The menu contains the following choices:

### **Text Size**

Refer to “Changing Text Size” on page 327 for information.


### **Columns**

This choice opens a Customize table dialog (Figure 295) where you can choose which columns you want to display.

Click the check box next to this item to display this item in the Ports Manager.

The grayed out items are defaults; you cannot clear these items.

**Figure 295: Delay Emulator Ports Manager Context Menu Parameters Selection**



---

## Using the Real Time Tab

To access the real time latency graph, click the **Real Time** tab at the bottom of the Delay Emulator main window.

### Delay-Mode

The Real Time window contains a table showing parameters for each device running. The parameters include:

- Port ID  
This includes the chassis number, the slot number, and the port number
- Current Test Index  
Indicates the position of the current test within the test suite
- Test Name  
Indicates the name of the current test
- Time Started  
Indicates when the current test started
- Time Out  
Indicates the timeout value if applicable
- Configuration Repeat Count  
Indicates how many times the configuration has been repeated.

The following parameters are present for each queue when you expand the configuration table”


- Operation Status  
Indicates the state of the port, started, triggered stopped, etc.
- Operation Mode  
Indicates the type of delay
- Frame Drop  
Indicates how many will be dropped. You can change this value by clicking the arrow at the right of the field and sliding the slider to the desired value.

When a test is running, the device’s ports appear in table in the upper half of the window. If multiple test are running, each device appears in the table. To expand the an entry in the table to view the queues for that test, click the plus sign on the left. This opens the delay control.

## Delay Graph

To access the delay graph, click the button in the **Delay** field. This graph allows you to view the delay change in real time. The graph has a control at the top of the window that allows you to set the latency value in nanoseconds. You can either type a value in the field or click the up/down buttons to change the value in increments of one. If the delay type is “Fixed Delay”, you can change the delay value while a test is running. If you would like to pause the graph, click the Pause button in the top left corner of the window. To resume, click the Play button. To undock the graph, click the green undock button. You can close this window and reopen it at any time while the test is running.

**Figure 296: Delay Graph**



## Reorder-Mode

The Real Time window contains a table showing parameters for each device running. The parameters include:

- Port ID  
This includes the chassis number, the slot number, and the port number
- Current Test Index  
Indicates the position of the current test within the test suite
- Test Name  
Indicates the name of the current test
- Time Started  
Indicates when the current test started
- Time Out  
Indicates the timeout value if applicable
- Configuration Repeat Count  
Indicates how many times the configuration has been repeated.
- Frames Reordered  
Indicates the number of frames that have been reordered
- Operation Status  
Indicates the state of the port, started, triggered stopped, etc.
- Operation Mode  
Indicates the type of delay

When a test is running, the device's ports for the device appear in a table in the lower half of the window. If multiple test are running, each device appears in the table.

## Using the Log Manager in Delay Emulator

To access the Log Manager, click the **Log** tab at the bottom of the Delay Emulator main window.

The purpose of logging is to automatically create a log that reports which delay or reorder tests have occurred and which ones might have reached the timeout limit while not finding a trigger. You can view a log with any text editor.

The Filter icons next to the **Type** and **Address** column labels allow you to choose how you want to display device types, by protocol or All, and device addresses, by single address or All devices.

If the **All Devices** tab at the top of the Xgig Maestro main window is selected, then the **Log Source** menu  2 active log sources ▾ shows all log sources as active by default. You can choose to disable BERT logging, Delay Emulator logging, Generator logging, Target Emulator logging, or all four by clicking the **Log Sources** menu and un-checking the selections. If the **BERT-Bit error rate testing**, **Jammer**, **Target Emulator**, or **Generator** tabs in the main window are selected, then the Log Manager displays only the log entries for that tab, respectively.

The following icons are displayed on the Log Manager menu bar:



### Display Entry Contents

Lets you save the selected log to a file in the device Logs folder (for example: C:\Program Files\Viavi\Xgig Maestro\Delay Emulator\Logs) or anywhere you want to save it on the network. Refer to the note on page 323 for information about installation on 64-bit operating systems.



### Save All Entries As

Lets you save all the logs in the Log Manager to a file.



### Save selected entries as

Lets you save the selected logs to a file.



### Select All

Selects all the logs in the Log Manager.



### Options

Opens the Log Manager Options dialog where you can enter your preferences for the information you want displayed in the Log Manager (Figure 297).



### Clear Filtering

Removes filtering by Type and Address and displays all the devices you have locked.



### Clear Selected Entries

Deletes the log entry you have highlighted.



### Clear All Entries


Deletes all the log entries in the Log Manager.

## Setting Log Options

To have log files automatically named and saved to a specific location:

- 1 Click the Log Manager Options icon to open the drop-down menu (Figure 297), and select **Delay Emulator logging options**.

**Figure 297: Log Manager Options Menu**




Or:

Open the Parameters context menu and select **Options**.

Either of these commands opens the Delay Emulator Log Options dialog (Figure 298). This dialog allows you to set up how you want the log files to be automatically named and the default location where you want them saved. You can also change the filename and folder when you save the log.

**Figure 298: Delay Emulator Log Options Dialog**



- 2 Select a log filename template from the following choices:

- Delay EmulatorLog\_[port]
- Delay EmulatorLog\_[port]\_[date]\_[time]
- Delay EmulatorLog\_[date]\_[time]
- Delay EmulatorLog\_[date]\_[time]\_[port]

Or, you can type in your own template. Any [port], [date], and [time] in the template is replaced by the corresponding value. Port is displayed as:

```
protocol, chassis name (chassis number in the cascade, blade
number in the chassis, port number on the blade)
```

- 3 Enter the path to the folder where you want to save the log file.

You can browse to where you want to save the log file by clicking .

- 4 Click **OK**.

You have set up the log filename template and default folder to save the log.



**Note:** These settings apply to all Delay Emulator logs. Log options are the same for all Delay Emulator ports.

## Viewing a Log

The Delay Emulator log shows the status of each Test Case during the entire length of the test run

To display a log:

>> Click the Log Manager tab at the bottom of the Xgig Maestro main window to view the log in a tabulated format (Figure 299).

Or:

>> Click the **Log** button on the Operation bar (with the appropriate Delay Emulator device selected in the Parameters Status table; a green check mark indicates the device is selected).

Or you can:

>> Open the Parameters context menu and select **Log > View**.


These two latter commands open a window that allows you to quickly view the Xgig Delay Emulator log. (Figure 300). In the case of these two methods, each time you run a Delay Emulator, a new Delay Emulator log is created for the device, and the previous log is discarded. Click **Print** at the bottom of the Delay Emulator log to print a hard copy of the log.

On the other hand, the Log Manager continues to list the logs and display them depending on the Log Manager options you have selected. See “Setting Log Options” on page 321.

You can save a log to a .txt file or an HTML file. Refer to “Saving a Log” on page 323.

**Figure 299: Log Manager**

DelayEmulator logging active			
DateTime	Type	Address	Contents
2/23/2010 4:58:07 PM	Delay Emulator	API Trace	GetTriggerStateNameString(167643824, 1, tsArm, "") Return: ecSuccess Spent:00:00:00
2/23/2010 4:58:07 PM	Delay Emulator	API Trace	GetConfigurationModifiedState(119419448, False) Return: ecSuccess Spent:00:00:00
2/23/2010 4:58:07 PM	Delay Emulator	API Trace	GetConfigurationModifiedState(119419448, False) Return: ecSuccess Spent:00:00:00
2/23/2010 4:58:07 PM	Delay Emulator	API Trace	GetTriggerStateNameString(167643824, 1, tsTrigger, "") Return: ecSuccess Spent:00:00:00
2/23/2010 4:58:07 PM	Delay Emulator	API Trace	GetConfigurationModifiedState(119419448, False) Return: ecSuccess Spent:00:00:00
2/23/2010 4:58:07 PM	Delay Emulator	API Trace	GetConfigurationModifiedState(119419448, False) Return: ecSuccess Spent:00:00:00

**Figure 300: Example of a Delay Emulator Log Display**

## Saving a Log

You can save a log from the Log Manager tab or the Parameters context menu.

To save a log from the Log Manager tab as an HTML file or text file:

- 1 Highlight the log you want to save.
- 2 Click the **Save Selected Entries As...** button.

The Save Log Manager Contents As window is displayed that lets you name and save the log as an HTML file to the Saved Logs folder or to a location you prefer.

To save a log to a .txt file using the Parameters context menu:

- >> Open the Parameters context menu (Figure 301) and select **Log > Save As**.

This command opens a File dialog where you can save the log with a file name you assign to it. The default location is:

C:\Program Files\Viavi\Xgig Maestro\Delay Emulator\Logs



**Note:** This software application can be loaded on 32-bit or 64-bit Windows operating systems. The path used above is for a 32-bit operating system.

If you are using a 64-bit operating system, the path would be:

C:\Program Files(x86)\Viavi\Xgig Maestro\Delay Emulator\Logs

**Figure 301: Log Menu**

## Customizing the Appearance of the Maestro/Delay Emulator Main Window

You can move and rearrange the individual device tabs on your monitor screen as you prefer. You can also select the information you want to display in the Parameters Status table. In addition, you can select the size of displayed text.

### Using the Window Menu

The **Window** menu allows you to arrange the window display:

#### **Layout**

Layout offers choices for rearranging the Maestro device tab windows. The Ports manager and Log Manager windows are not affected by this menu selection.

#### ***Internal Tabs***

Allows you to restore the Maestro main window to its default format.

#### ***Internal MDI***

Internal multiple document interface (MDI) lets you isolate each device tab as a separate window that you can activate by clicking anywhere on the window.

#### **Show Hidden Windows**

Restores any windows you have closed while using the Internal Tabs or Internal MDI display arrangement.

#### **Arrange Icons**

Arranges the icons for minimized windows at the bottom of the screen. If an open document window is at the bottom of the screen, some or all of the icons will be underneath this document window and will not be visible.

#### **Cascade**

Arranges all open windows in a cascade style from the top, left corner of the window.

#### **1 All Devices**

Brings the All Devices tab to the front as the active window. This window displays ports from all active devices (BERT, Delay Emulator, Generator, and Target Emulator).

#### **2 BERT - Bit error rate testing**

Brings the BERT device tab to the front as the active window

### **3 BERT - Latency measurement**

Brings the BERT Latency measurement device tab to the front as the active window

### **4 Jammer**

Brings the Delay Emulator device tab to the front as the active window

### **5 Generator**

Brings the Generator device tab to the front as the active window

### **6 Target Emulator**

Brings the Target Emulator device tab to the front as the active window

### **7 Delay Emulator**

Brings the Delay Emulator device tab to the front as the active window.

### **Tile Horizontally**

After selecting **Layout > Internal MDI**, this command opens and aligns the BERT, BERT Latency measurement, Delay Emulator, Generator, and Target Emulator device windows horizontally one over the other.

### **Tile Vertically**

After selecting **Layout > Internal MDI**, this command opens and aligns the BERT, BERT Latency measurement, Delay Emulator, and Generator, and Target Emulator device windows vertically one next to the other. You can view the individual device windows by dragging the sides out to resize them.

### **Minimize All Windows**

After selecting **Layout > Internal MDI**, this command minimizes all the open windows. You can restore each window, individually, by using the standard window controls on the header or select **Internal Tabs** to restore the Maestro main window to its default format.

## Customizing the Parameters Status table in Delay Emulator

You can change the appearance of the Parameters Status table by:

- Removing columns
- Resizing columns
- Changing the text size
- Displaying and hiding status table parameters

### Removing columns

If you have a number of devices locked, you can remove a column that you do not need to view without unlocking the port or affecting the operation.

To remove a column:


- 1 Right-click on the specific column you want and open the Parameters context menu.
- 2 Select **Hide Delay Emulator** (Figure 302).

Or:

In the Ports Manager, clear the **Show** check box next to the device you want to remove.

The column is removed, but the device is still locked (“in use”) and displayed in the Ports Manager.

**Figure 302: Removing a Device Column**



To replace the device column on the Parameters Status table:

- >> Click the **Show** check box for the device in the Ports Manager.

## Resizing columns

You can resize any of the columns by placing the mouse at the right edge at the top of a column, next to the chassis name. A resizing cursor appears. Hold down the mouse button, and drag the mouse to resize the column.

## Changing Text Size

You can choose the text size you want the Parameters Status table or the Ports Manager to display.




**Note:** You cannot change the text size in the Log Manager.

To change text size:


- 1 Open the context menu by clicking the right mouse button while the cursor is on the Parameters Status table or the Ports Manager.
- 2 Select **Text size** (Figure 303).  
You have five choices from which to select.  
Smallest is the default size.
- 3 Select the text size you want.  
A bullet is displayed next to the current selection.

**Figure 303: Text Size Menu**

Context menu over Ports manager



Context menu over device parameters status table



## Displaying and Hiding Parameters in Delay Emulator

You can hide specific parameters on the Parameters Status table to simplify the status tables and show only the information in which you are interested.


To display or hide parameters on the Parameters Status table:

- 1 Click the Parameters tab at the top of the Configuration manager pane to switch to the Parameters manager (Figure 304).

You can expand the categories by clicking the plus signs on the left.

The default displays most of the parameters.

**Figure 304: Delay Emulator Parameters Manager**



- 2 Click check box to set or clear the check mark next to the parameters.

Checked parameters are displayed.

## Performing Configuration Tasks in Delay Emulator

This section describes how to handle configuration files from the Delay Emulator main window.

### Loading Delay Emulator Configuration Files

You can load a configuration file on a Delay Emulator using one of the following methods:

#### From the Configuration Manger:

- >> Drag the configuration file from the list in the Configuration Manager onto the Parameters Status table (column for the device) and release the mouse button.

You can drag configuration files from anywhere, including the list of configuration files in the Configuration Manager on the Xgig Maestro window, the system desktop, or Windows Explorer.

#### From the Parameters Context Menu

- 1 Right-click on the device column to open the Parameters context menu and select **Load configuration file**.

An Open File dialog is displayed.

- 2 Navigate to the Delay Emulator `.decfg` file that you want to use and click **Open**.

The file is loaded and its name and parameters are displayed in the device column of the Parameters Status table.

#### From the Ports Manager:

- 1 Check the **Select** check box(es) in the Ports Manager for the port(s) you want to use.
- 2 Click the configuration file you want to load from the Configuration Manager.

- 3 Click the **Load Configuration to Selected Ports** button . This button is located in the Ports Manager and in the Configuration Manager. Both have the same function.

You can use the above methods to navigate to a mapped folder and load a configuration file.

### Saving a Delay Emulator Configuration File

To save a Delay Emulator configuration file you created or edited:

- 1 Right-click on the device column in the Parameters Status table to open the Parameters context menu, and select **Save configuration file**.

A Windows Save dialog is displayed.

- 2 Navigate to where you want to save the configuration file and assign a name to it.

Xgig Delay Emulator configuration files are saved with a `.decfg` extension.


## Resetting a Delay Emulator Configuration

To clear the configuration from a device:

- 1 Right-click on the device column in the Parameters Status table to open the Parameters context menu, and select **Reset configuration**.

A warning dialog may be displayed asking you to confirm the configuration reset.

**Figure 305: Reset Configuration Warning Dialog**



- 2 Click **Yes** to clear the configuration from the device.

## Editing a Delay Emulator Configuration

To create a configuration file for a device, you can start from a blank default configuration or edit the configuration after you have loaded a configuration file to the device.

You can open the Configuration window using one of the following methods:

- 1 Right-click on the device column in the Parameters Status table to open the Parameters context menu.
- 2 Select **Edit configuration**.

Or:

- >> Click the **Configuration** button on the Parameters Status table


This opens the Configuration window for the device that is currently selected. Refer to or [“Using the Jammer Configuration Window”](#) on page 116 for more information.

## Running the Test Suite on a Delay Emulator Device

After you have configured a Delay Emulator device, you can start the operation. Three methods are available:

>> Click the **Start** button on the Parameters Status table.

**Figure 306: Parameters Status table Start Button**



Or you can:

>> Right-click on the device column to open the Parameters context menu where the **Start**, **Pause**, **Skip**, and **Stop** commands are available.

Or:

1 On the Ports manager, select the device.

2 Click the **Start** button  .


Or:

1 On the Ports manager, in the Operation column, click the **Operation** button for the device.

The Operation dialog is displayed (Figure 307).

2 Click **Start**.

**Figure 307: Delay Emulator Tab Operation Bar**



Clicking any of the Operation buttons (including **Config**) takes effect on the Delay Emulator device that is currently selected in the Parameters Status table.

**Start** runs the Test Suite from the beginning if you click it while the Delay Emulator is stopped. The Start button label becomes a Stop label while the Test Suite is running.

**Pause** causes the Delay Emulator to pause and not run the next Test Case in the Test Suite when the current Test Case is completed. When you click **Pause**, the State of the Delay Emulator is “Pausing” while the current Test Case is still running. When the current Test Case completes (or is skipped), the Delay Emulator is in the “Paused” state waiting for user intervention.

**Skip** causes the Delay Emulator to abort the current Test Case and move on to the next one. If the Delay Emulator is “Paused,” you can click **Skip** to jump through your Test Suite without running any Test Cases until you get to the Test Case you want to run and resume testing. If you skip past the last Test Case in the Test Suite and the Test Suite is not set to loop forever, then the Delay Emulator goes to the Stopped state as if the Test Suite completed.

To let a test run to the end and then skip to another test:

- 1 Click **Pause**.  
Wait for the current test to finish.
- 2 Click **Skip** to step through the tests.
- 3 Observe the progress field on the Parameters Status table to track tests in the queue.
- 4 Click **Start**.

**Stop** causes the Delay Emulator to abort running the entire Test Suite and go to the Stopped state.

**Log** indicates a log is available for viewing. Click **Log** to view the latest test log.

# ***Chapter 12***

## **Creating Delay Emulator Test Configurations for Delay Mode**

### **In this chapter:**

- [Defining Your Own Test Configurations for Delay Mode](#)
- [Using the Delay-Mode Configuration Window](#)
- [Configuring the Classify Condition in Delay-Mode](#)
- [Configuring the Arm Condition in Delay-Mode](#)
- [Configuring the Trigger Condition in Delay-Mode](#)

## Defining Your Own Test Configurations for Delay Mode

Xgig Delay Emulator lets you define your own test configurations and save them with or without hardware available.

You can create a configuration from scratch, or you can open and edit an existing configuration. Also, you can edit a configuration in edit only mode, which is independent of any hardware, or you can edit a configuration that is currently loaded to a Delay Emulator device.


To edit a configuration in edit only mode:

- >> Double-click a configuration file in the Configuration manager.
- or:
- >> Right-click the configuration file in the Configuration manager, and choose **Edit Delay Emulator Configuration** from the context menu.

The edit only mode Delay Emulator Configuration window opens (Figure 308).

This window allows you to set up your own Test Cases, name them, organize them, and save them to files so that you can use them again.

**Figure 308: Edit Only Delay Emulator Configuration Window**




To start a configuration from scratch in edit only mode:

- >> Select **New Delay Emulator Configuration** from the context menu or the File menu (Figure 309) on the Xgig Maestro menu bar. Then, select **Delay-Mode or Reorder-Mode Delay Emulator Configuration** from the drop down menu.

or:

>> Click the New Configuration icon at the top of the Configuration manager.

**Figure 309: Maestro File Menu**



To save your configuration in edit only mode:

>> Click **Save** at the bottom of the Delay Emulator Configuration window, or open the File menu on the Delay Emulator Configuration window and select **Save Delay Emulator Configuration** or **Save Delay Emulator Configuration As**.

Any changes you make have no effect on actual Delay Emulator devices you control.

To edit a configuration that is loaded to a Delay Emulator port:

>> Click **Configuration...** in the device column.

or:

>> Right-click in the Parameters Status table in the device column to open the context menu and select **Edit configuration**.

or:

>> Click **Operation** in the device column to open the Operation dialog, then click **Config**.


The Xgig Delay Emulator Configuration window in hardware edit mode is displayed (Figure 310). This window allows you to set up your own Test Cases, name them, and save them to a file so that you can use them again.

Click **Apply** or **OK** and Delay Emulator accepts the changes. They are immediately reflected in the Parameters Status table and affect the Delay Emulator device the next time you run it.

To save your configuration edits:

>> Open the File menu at the top of the Delay Emulator Configuration window and select **Save Delay Emulator Configuration** or **Save Delay Emulator Configuration As**.

**Figure 310: Xgig Delay Emulator Configuration Window**



## Using the Delay-Mode Configuration Window

The Delay Emulator Configuration window title bar indicates how many ports it is configuring, the protocol, and the configuration file name, if any. If you are using hardware edit mode, the chassis name, chassis number, slot number, and port number are also listed. The elements of the Delay Emulator Configuration window are described in the following sections.

## Using the Delay Emulator Test Suite Tools

The Delay Emulator Test Suite (left pane) lists the series of Xgig Delay Emulator tests in the order in which you want them to execute. The number of tests in a test suite has no limit. Each test can contain between one and eight queues. The highlighted test appears as the Current Delay Emulator Test (right pane). Each test in the suite executes in sequence.

### Creating a Test Suite

When you create a Delay Emulator Test Suite, you use the toolbar in the Delay Emulator Test Suite section of the Configuration window (Figure 311).

**Figure 311: 10GigE Delay Emulator Test Suite Toolbar**



The following list describes the icons on the toolbar:

	Cut current test	Removes the highlighted test and holds its contents in the memory buffer.
	Copy current text	Copies the highlighted test to the memory buffer.
	Paste last test cut or copied	Inserts the current memory buffer contents before the currently highlighted test.
	Add new test to bottom of stack	Adds a new blank test to the bottom of the suite.
	Insert new test before current test	Inserts a new blank test above the currently highlighted test.
	Delete current test	Removes the highlighted test from the suite. If only one test is present, then the contents of this test are cleared.
	Move current test down the stack	Moves the highlighted test down one in the test order.
	Move current test up the stack	Moves the highlighted test up one in the test order.
	Run test suite once or Repeat test suite	When you choose Repeat test suite, the tests run according the settings you define in the Delay Emulator Current Test window. You can also type a number in this field to indicate you want the test suite to repeat a certain number of times.

To duplicate a test at another point in the Test Suite:


- 1 Highlight the test you want to duplicate.
- 2 Click **Copy**.
- 3 Highlight the test in the suite that is just after the point where you want the duplicate test inserted.
- 4 Click **Paste**.

The duplicate test is inserted.

## Using the Configuration File Menu

The File menu is the only menu on the menu bar (Figure 312).

**Figure 312: Configuration File Menu**



The choices are:


- New Configuration**                      Creates a new delay or reorder .decfg configuration file.
- Open Configuration**                    Open an existing .decfg configuration file.
- Save Configuration**                    Save the entire Test Suite to the .decfg file you currently have loaded.
- Save Configuration As**                Save the entire Test Suite to a .decfg file with a name you assign to it.
- Recent Configuration**                Open a recently opened .decfg configuration file.
- Close**                                    Close the Delay Emulator Configuration Window.

The recently used Delay Emulator configuration files appear in the file menu and are loaded when selected.

### Using the Current Delay Emulator Test Window: Delay-Mode

The graphics in this section of the window represent the hardware configuration for the selected test in the Delay Emulator Test Suite (Figure 313).

**Figure 313: Current Delay Emulator Test Window**



## Single Tab

The **Single** tab shows the contents for a single test within the test suite. A test is comprised of queues, which are delays. A test can have up to eight queues. Each queue has its own settings. To populate a test, you must create queues. Use the toolbar to create and control queues within a test. The toolbar on the **Single** tab contains the same functions for queues as the left pane has for tests.


### Create a Queue

To create a queue within a test, click the **Add Queue**  button. The queue appears below the toolbar. The following sections illustrate the process of defining the parameters for a queue.

### Mode

The Mode menu is available near the top of the Current Delay Emulator Test window (Figure 314) and also near the top of each queue in the Delay Emulator **Single** tab (Figure 310).

**Figure 314: Mode Drop-down Menu in Current Delay Emulator Test**



### Classify

The Classify menu are available in the left pane of the Current Delay Emulator Test window and also in each queue in the Delay Emulator **Single** tab. To define Classify condition, click the Classify button in the queue or in the left pane to open the corresponding definition window.

### Arm and Trigger

The Arm and Trigger menus are available in the left pane of the Current Delay Emulator Test window and also in each queue in the Delay Emulator **Single** tab. To define Arm and Trigger conditions, click the Arm or Trigger **Frame** button in the queue. Now, click the Arm or Trigger button in the queue or in the left pane to open the corresponding definition window.

### Delay

The Delay menu allows you to select what type of delay you want. Click the Delay button to access the Delay dialog. All delays are in addition to the smallest delay of 30ms and are rounded up or down to the nearest 6ns increment.

Select the type of delay you want from the drop-down menu.

#### Fixed Delay

Emulates a fixed delay for each buffer segment

For Fixed Delay, type the delay value in nanoseconds.

### ***Jitter Delay***

Emulates inter-packet gap variations for each buffer segment

For Jitter Delay, type the min. and max. values as well as the step size in nanoseconds.

### ***Ramp Down Delay***

Emulates delays that decrease with each buffer segment

For Ramp Down Delay, type the min. and max. values as well as the step size in nanoseconds.

### ***Ramp Up Delay***

Emulates delays that increase with each buffer segment

For Ramp Up Delay, type the min. and max. values as well as the step size in nanoseconds.

### ***Random Delay***

Emulates random inter-packet gap variations for each buffer segment

For random delay, type the min. and max. delay values in nanoseconds.

### ***Random Jitter Delay***


Emulate random inter-packet gap variations for each buffer segment

For Random Jitter Delay, type the mean value in nanoseconds and the percentage of change in value to define your range. For example. If your mean is 1000ns, and your percentage is 5, then your delay values will range from 950 to 1050ns

### ***Drop Mode***

You can define frame drop mode and rate in a delay queue. You can also choose **Frame Drop Mode** or **Byte Drop Mode** from the **Type** drop-down menu of the **Drop** dialog. The Drop mode defines whether the drop rate will be based on number of frames or number of bytes in frames. **Byte Drop Mode** is only available for the first queue. The frame drop rate defines the ration to drop, and it has precision to 0.01%.

**Figure 315: Drop Mode**




### ***Timeout***

The timeout option defines the period of time to wait for a specified test to complete before aborting and proceeding to the next test in the suite.

To set the timeout:

- 1 Click **Timeout** to display the dialog box in Figure 316.
- 2 Check **Enable Timeout**.
- 3 Select either **By Time** or **By Frame**.
- 4 For **By Time**, enter the hours, minutes, and seconds you want to wait.
- 5 For **By Frame**, enter the number of frames you want to wait for.

**Figure 316: Timeout Dialog**




- 6 Click **OK**.

### Summary Tab

The Summary tab provides a graphical representation of all the queues in a test. The flow of information goes from the classify condition to the Arm and/or Trigger condition. If the Classify condition for a queue is not met, the Classify condition for the next queue is compared. If none of the Classify conditions in the test are met, the process defaults to the bypass delay.

The bypass delay is a fixed delay set at 30 microseconds, which is the smallest delay possible.

**Figure 317: Summary Tab**



## Configuring the Classify Condition in Delay-Mode

The Classify condition of a queue is compared first. If it is met, the queue process begins. The queue process consists of either Arm and Trigger or just Trigger. If the Classify condition is not met, the Classify condition of the next queue is compared. The Classify condition recognizes specific DWords within frames.



**Note:** If none of the Classify conditions in the queue are met, the software uses the default bypass delay, which acts as a catch all for traffic that doesn't go through the queues. This flow is represented on the Summary tab of the **Delay Emulator Configuration** window.


Depending on the Mode you select in the **Delay Emulator Configuration** window, the appropriate graphic diagram shows the Classify condition, the Trigger and optional Arm conditions, and the Delay. If the Mode you select does not include an Arm condition, the Arm button remains disabled.

To set Classify conditions:

- 1 Click the **Classify** button in the Xgig Delay Emulator Configuration window.  
The window for the condition is displayed (Figure 318). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.
- 2 Set the values as required to specify the Classify condition as part of a unique Classify, Arm and Trigger sequence for the specific test.

The following sections describe the available values.

**Figure 318: Classify Window for Delay**



## Setting Frame Conditions for Classify in Delay-Mode

You can specify frame conditions in two ways. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:


>> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 319). In the hex view, partially defined hex characters appear as question marks:

X001=?

**Figure 319: Binary Editor Dialog**




Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Decode Switches Menu

Some templates allow you to specify decode switches. When you load a template that has this option, the **Decode Switches Menu** appears in the upper left corner of the window. The decode switches provide detailed contextual options for decode; for example, further decode of response and data frames. The Decode Switches menu is context sensitive and will only show the decode options available for the specific template you are creating.

**Figure 320: Decode Switches Menu**




 **Note:** Once the **Decode Switches** menu appears, it remains visible. However, if you load a template that has no decode options, the menu is greyed out and inactive.

The **Decode Switches** menu is intended to help you create a user-defined template. When editing a User Library template, Decode Switches are stored inside the template so they are still ON the next time you open this particular template.

Decode switches allow you to further decode Response and Data frames that can't be decoded without knowing what the associated command frame is. Below is a description of the switches available under the **FC-SW Accept Interpretation**

**Figure 321: Decode Switch Options for FC-SW Accept Interpretation**



### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

- >> Highlight the folder and click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Delay Emulator Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Configuring the Arm Condition in Delay-Mode

The Arm condition recognizes specific DWords within frames.

Depending on the Mode you select, the appropriate graphic diagram shows the Classify condition, the Trigger and optional Arm conditions, and the Delay. If the Mode you select does not include an Arm condition, the **Arm** button is disabled.

To set Arm conditions:

- 1 Click on the **Arm** button to open the Arm window.

The window for the condition is displayed (Figure 322). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.


- 2 Set the values as required to specify the Arm condition as part of a unique Arm and Trigger sequence for the specific test.

The following sections describe the available values.

### Setting Frame Conditions for Arm in Delay-Mode

You can specify frame conditions in two ways. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

**Figure 322: Arm Window for Delay**



To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.


To manually specify a frame:

- >> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 323). In the hex view, partially defined hex characters appear as question marks:

X001=?

**Figure 323: Binary Editor Dialog**

Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

>> Highlight the folder and click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Delay Emulator Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Configuring the Trigger Condition in Delay-Mode

The Trigger condition recognizes specific DWords within frames.

Depending on the Mode you select in the **Delay Emulator Configuration** window, the appropriate graphic diagram shows the Classify condition, the Trigger and optional Arm conditions, and the Delay. If the Mode you select does not include an Arm condition, the Arm button remains disabled.

To set Trigger conditions:


- 1 Click the **Trigger** button in the Xgig Delay Emulator Configuration window.

The window for the condition is displayed (Figure 324). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.

- 2 Set the values as required to specify the Trigger condition as part of a unique Arm and Trigger sequence for the specific test. The default setting for the Trigger condition is to trigger on any frame.

The following sections describe the available values.

**Figure 324: 10GigE Trigger Window for Frames**



## Setting Frame Conditions for a Trigger in Delay-Mode

You can specify frame conditions in two ways. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:


>> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 325). In the hex view, partially defined hex characters appear as question marks:

X001=?


**Figure 325: Binary Editor Dialog**



Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Decode Switches Menu

Some templates allow you to specify decode switches. When you load a template that has this option, the **Decode Switches Menu** appears in the upper left corner of the window. The decode switches provide detailed contextual options for decode; for example, further decode of response and data frames. The Decode Switches menu is context sensitive and will only show the decode options available for the specific template you are creating.


**Figure 326: Decode Switches Menu**

**Note:** Once the **Decode Switches** menu appears, it remains visible. However, if you load a template that has no decode options, the menu is grayed out and inactive.

The **Decode Switches** menu is intended to help you create a user-defined template. When editing a User Library template, Decode Switches are stored inside the template so they are still ON the next time you open this particular template.

Decode switches allow you to further decode Response and Data frames that can't be decoded without knowing what the associated command frame is. Below is a description of the switches available under the **FC-SW Accept Interpretation**

**Figure 327: Decode Switch Options for FC-SW Accept Interpretation**



**Saving a Frame Condition**

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

- >> Highlight the folder and click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Delay Emulator Configuration window under the Mode selection, and on the main Xgig Maestro window.

# ***Chapter 13***

## Creating Delay Emulator Test Configurations for Reorder Mode

### **In this chapter:**

- [Defining Your Own Test Configurations for Reorder Mode](#)
- [Using the Reorder-Mode Configuration Window](#)
- [Configuring the Arm Condition in Reorder-Mode](#)
- [Configuring the Trigger Condition in Reorder-Mode](#)
- [Configuring the Reorder Condition](#)

## Defining Your Own Test Configurations for Reorder Mode

Xgig Delay Emulator lets you define your own test configurations and save them with or without hardware available.

You can create a configuration from scratch, or you can open and edit an existing configuration. Also, you can edit a configuration in edit only mode, which is independent of any hardware, or you can edit a configuration that is currently loaded to a Delay Emulator device.

To edit a configuration in edit only mode:

>> Double-click a configuration file in the Configuration manager.


or:

>> Right-click the configuration file in the Configuration manager, and choose **Edit Delay Emulator Configuration** from the context menu.

The edit only mode Delay Emulator Configuration window opens (Figure 328).

This window allows you to set up your own Test Cases, name them, organize them, and save them to files so that you can use them again.

**Figure 328: Edit Only Delay Emulator Configuration Window**




To start a configuration from scratch in edit only mode:

- >> Select **New Delay Emulator Configuration** from the context menu or the File menu (Figure 329) on the Xgig Maestro menu bar. Then, select **Delay-Mode or Reorder-Mode Delay Emulator Configuration** from the drop down menu.

or:

- >> Click the New Configuration icon at the top of the Configuration manager.

**Figure 329: Maestro File Menu**



To save your configuration in edit only mode:

- >> Click **Save** at the bottom of the Delay Emulator Configuration window, or open the File menu on the Delay Emulator Configuration window and select **Save Delay Emulator Configuration** or **Save Delay Emulator Configuration As**.

Any changes you make have no effect on actual Delay Emulator devices you control.

To edit a configuration that is loaded to a Delay Emulator port:

- >> Click **Configuration...** in the device column.

or:

- >> Right-click in the Parameters Status table in the device column to open the context menu and select **Edit configuration**.

or:

- >> Click **Operation** in the device column to open the Operation dialog, then click **Config**.


The Xgig Delay Emulator Configuration window in hardware edit mode is displayed (Figure 330). This window allows you to set up your own Test Cases, name them, and save them to a file so that you can use them again.

Click **Apply** or **OK** and Delay Emulator accepts the changes. They are immediately reflected in the Parameters Status table and affect the Delay Emulator device the next time you run it.

To save your configuration edits:

- >> Open the File menu at the top of the Delay Emulator Configuration window and select **Save Delay Emulator Configuration** or **Save Delay Emulator Configuration As**.

Figure 330: Xgig Delay Emulator Configuration Window



## Using the Reorder-Mode Configuration Window

The Delay Emulator Configuration window title bar indicates how many ports it is configuring, the protocol, and the configuration file name, if any. If you are using hardware edit mode, the chassis name, chassis number, slot number, and port number are also listed. The elements of the Delay Emulator Configuration window are described in the following sections.

## Using the Delay Emulator Test Suite Tools in Reorder-Mode

The Delay Emulator Test Suite (left pane) lists the series of Xgig Delay Emulator tests in the order in which you want them to execute. The number of test in the test suite has no limit. Each test can contain between two and eight frames to be reordered. The highlighted test appears as the Current Delay Emulator Test (right pane). Each test in the suite executes in sequence.

### Creating a Test Suite

When you create a Delay Emulator Test Suite, you use the toolbar in the Delay Emulator Test Suite section of the Configuration window (Figure 331).

**Figure 331: 10GigE Delay Emulator Test Suite Toolbar**



The following list describes the icons on the toolbar:

	Cut current test	Removes the highlighted test and holds its contents in the memory buffer.
	Copy current text	Copies the highlighted test to the memory buffer.
	Paste last test cut or copied	Inserts the current memory buffer contents before the currently highlighted test.
	Add new test to bottom of stack	Adds a new blank test to the bottom of the suite.
	Insert new test before current test	Inserts a new blank test above the currently highlighted test.
	Delete current test	Removes the highlighted test from the suite. If only one test is present, then the contents of this test are cleared.
	Move current test down the stack	Moves the highlighted test down one in the test order.
	Move current test up the stack	Moves the highlighted test up one in the test order.
	Run test suite once or Repeat test suite	When you choose Repeat test suite, the tests run according the settings you define in the Delay Emulator Current Test window. You can also type a number in this field to indicate that you want the test suite to repeat a certain number of times.

To duplicate a test at another point in the Test Suite:


- 1 Highlight the test you want to duplicate.
- 2 Click **Copy**.
- 3 Highlight the test in the suite that is just after the point where you want the duplicate test inserted.
- 4 Click **Paste**.

The duplicate test is inserted.

### Using the Configuration File Menu

The File menu is the only menu on the menu bar (Figure 332).

**Figure 332: Configuration File Menu**



The choices are:


<b>New Configuration</b>	Creates a new delay or reorder <code>.decfg</code> configuration file.
<b>Open Configuration</b>	Open an existing <code>.decfg</code> configuration file.
<b>Save Configuration</b>	Save the entire Test Suite to the <code>.decfg</code> file you currently have loaded.
<b>Save Configuration As</b>	Save the entire Test Suite to a <code>.decfg</code> file with a name you assign to it.
<b>Recent Configuration</b>	Open a recently opened <code>.decfg</code> configuration file.
<b>Close</b>	Close the Delay Emulator Configuration Window.

The recently used Delay Emulator configuration files appear in the file menu and are loaded when selected.

## Using the Current Delay Emulator Test Window: Reorder-Mode

The graphics in this section of the window represent the hardware configuration for the selected test in the Delay Emulator Test Suite (Figure 333).


**Figure 333: Current Delay Emulator Test Window**



### Mode

The Mode menu is available near the top of the Current Delay Emulator Test window (Figure 334).

**Figure 334: Mode Drop-down Menu in Current Delay Emulator Test - Right Pane**



### Arm and Trigger

The Arm and Trigger buttons are located in the right pane of the Current Delay Emulator Test window. To define Arm and Trigger conditions, click the Arm or Trigger button.

## Reorder

The Reorder button is located in the right pane of the Current Delay Emulator Test window. To define the Reorder condition, click the Reorder button.


## Timeout

The timeout option defines the period of time to wait for a specified test to complete before aborting and proceeding to the next test in the suite.

To set the timeout:

- 1 Click **Timeout** to display the dialog box in Figure 335.
- 2 Check **Enable Timeout**.
- 3 Enter the hours, minutes, and seconds you want to wait.

**Figure 335: Timeout Dialog**



- 4 Click **OK**.

## Configuring the Arm Condition in Reorder-Mode

The Arm condition recognizes specific DWords within frames.

Depending on the Mode you select, the appropriate graphic diagram shows the Trigger and optional Arm conditions. If the Mode you select does not include an Arm condition, the **Arm** button is disabled.

To set Arm conditions:

- 1 Click on the **Arm** button to open the Arm window.

The window for the condition is displayed (Figure 336). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.


- 2 Set the values as required to specify the Arm condition as part of a unique Arm and Trigger sequence for the specific test.

The following sections describe the available values.

## Setting Frame Conditions for Arm for Reorder

You can specify frame conditions in two ways. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

**Figure 336: Arm Window for Frames**



To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:


- >> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 337). In the hex view, partially defined hex characters appear as question marks:

X001=?

**Figure 337: Binary Editor Dialog**



Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

- >> Highlight the folder and click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Delay Emulator Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Configuring the Trigger Condition in Reorder-Mode

The Trigger condition recognizes DWords within frames.

Depending on the Mode you select in the **Delay Emulator Configuration** window, the appropriate graphic diagram shows the Trigger and optional Arm conditions, along with the Delay. If the Mode you select does not include an Arm condition, the Arm button remains disabled.

To set Trigger conditions:


- 1 Click the **Trigger** button in the Xgig Delay Emulator Configuration window.

The window for the condition is displayed (Figure 338). If you are in hardware edit mode, the protocol, chassis name, chassis number, slot number, and port numbers are displayed in the title bar.

- 2 Set the values as required to specify the Trigger condition as part of a unique Arm and Trigger sequence for the specific test.

The following sections describe the available values.

**Figure 338: Trigger Window for Frames**



## Setting Frame Conditions for a Trigger in Reorder-Mode

You can specify frame conditions in two ways. One way is to load a template from the Template Library tree, and the other way is to manually specify bits in the frame.

To use a template:

- 1 Select a template from the Template Library tree on the left.
- 2 Click the double right arrow button to set the Trigger Condition.

The condition is indicated on the right side of the window.

To manually specify a frame:


>> Type hexadecimal values directly into the center column of the window.

An X represents a nibble that can be any value (a “don’t care”).

To set individual bits in any field, double-click on the hex entry to open the Binary Editor (Figure 339). In the hex view, partially defined hex characters appear as question marks:

X001=?

**Figure 339: Binary Editor Dialog**




Another way to manually edit the frame condition is to make selections from the tree view in the right window pane.

### Decode Switches Menu

Some templates allow you to specify decode switches. When you load a template that has this option, the **Decode Switches Menu** appears in the upper left corner of the window. The decode switches provide detailed contextual options for decode; for example, further decode of response and data frames. The Decode Switches menu is context sensitive and will only show the decode options available for the specific template you are creating.

**Figure 340: Decode Switches Menu**




**Note:** Once the **Decode Switches** menu appears, it remains visible. However, if you load a template that has no decode options, the menu is greyed out and inactive.

The **Decode Switches** menu is intended to help you create a user-defined template. When editing a User Library template, Decode Switches are stored inside the template so they are still ON the next time you open this particular template.

Decode switches allow you to further decode Response and Data frames that can't be decoded without knowing what the associated command frame is. Below is a description of the switches avaFC-SW Accept Interpretation

**Figure 341: Decode Switch Options for FC-SW Accept Interpretation**



### Saving a Frame Condition

If you create a frame condition that you want to save and make easily available for future use, you can save it into the “User Library” folder in the Template Library tree. To do this:

- >> Highlight the folder and click the double left arrow button.

Frame conditions have the option of “Use inverse of condition specified (i.e., NOT).” When you check this option, it means that the first frame encountered that does not match what you have specified creates a “condition met” event.

For each frame condition, you can specify an optional name at the top of the window. This name is also shown on the Delay Emulator Configuration window under the Mode selection, and on the main Xgig Maestro window.

## Configuring the Reorder Condition

The Reorder definition tells the software the way you want to reorder frames, how many frames to reorder, and in which order to place them.

Depending on the Mode you select, the appropriate graphic diagram shows the Trigger and optional Arm conditions. If the Mode you select does not include an Arm condition, the **Arm** button is disabled.

To define the Reorder:

- 1 Click the **Reorder** button to open the Reorder window.

The Reorder window is displayed (Figure 336).

- 2 Select the type of reorder you want.

- Consecutive Reorder

For a consecutive reorder, every frame including the trigger frame is reordered.

- Trigger Reorder

For a trigger reorder, all frames of the type specified in the trigger are reordered beginning with the frame including the trigger frame.

- 3 Select the number of frames you want to reorder, between two and eight.
- 4 Drag the frames to reorder them.
- 5 Click OK.

## ***PART THREE:*** Appendices



# Appendix A

## Fibre Channel Ordered Sets - Partial List

Fibre Channel defines certain combinations of characters called Ordered Sets. The table in this appendix shows a partial list. The following abbreviations are used in the table:

SOF                      Start-of-frame delimiter

EOF                      End-of-frame delimiter

ALPA, D, S, Type    Arbitrated Loop Physical Address, Destination, Source, Mark Type. These are limited to 127 specific hex values.

Name	Function	Beginning RD	Ordered Set	8 Bit Hex
SOFc1	SOF Connect Class 1	Negative	K28.5 D21.5 D23.0 D23.0	K28.5 B5 17 17
SOFi1	SOF Initiate Class 1	Negative	K28.5 D21.5 D23.2 D23.2	K28.5 B5 57 57
SOFn1	SOF Normal Class 1	Negative	K28.5 D21.5 D23.1 D23.1	K28.5 B5 37 37
SOFi2	SOF Initiate Class 2	Negative	K28.5 D21.5 D21.2 D21.2	K28.5 B5 55 55
SOFn2	SOF Normal Class 2	Negative	K28.5 D21.5 D21.1 D21.1	K28.5 B5 35 35
SOFi3	SOF Initiate Class 3	Negative	K28.5 D21.5 D22.2 D22.2	K28.5 B5 56 56
SOFn3	SOF Normal Class 3	Negative	K28.5 D21.5 D22.1 D22.1	K28.5 B5 36 36
SOFf	SOF Fabric	Negative	K28.5 D21.5 D24.2 D24.2	K28.5 B5 58 58
SOFc4	SOF Activate Class 4	Negative	K28.5 D21.5 D25.0 D25.0	K28.5 B5 19 19
SOFi4	SOF Initiate Class 4	Negative	K28.5 D21.5 D25.2 D25.2	K28.5 B5 59 59
SOFn4	SOF Normal Class 4	Negative	K28.5 D21.5 D25.1 D25.1	K28.5 B5 39 39

Name	Function	Beginning RD	Ordered Set	8 Bit Hex
EOft	EOF Terminate	Negative Positive	K28.5 D21.4 D21.3 D21.3 K28.5 D21.5 D21.3 D21.3	K28.5 95 75 75 K28.5 B5 75 75
EOFdt	EOF Disconnect-Terminate	Negative Positive	K28.5 D21.4 D21.4 D21.4 K28.5 D21.5 D21.4 D21.4	K28.5 95 95 95 K28.5 B5 95 95
EOFa	EOF Abort	Negative Positive	K28.5 D21.4 D21.7 D21.7 K28.5 D21.5 D21.7 D21.7	K28.5 95 F5 F5 K28.5 B5 F5 F5
EOFn	EOF Normal	Negative Positive	K28.5 D21.4 D21.6 D21.6 K28.5 D21.5 D21.6 D21.6	K28.5 95 D5 D5 K28.5 B5 D5 D5
EOFdti	EOF Disconnect-Terminate-Invalid	Negative Positive	K28.5 D10.4 D21.4 D21.4 K28.5 D10.5 D21.4 D21.4	K28.5 8A 95 95 K28.5 AA 95 95
EOFni	EOF Normal-Invalid	Negative Positive	K28.5 D10.4 D21.6 D21.6 K28.5 D10.5 D21.6 D21.6	K28.5 8A D5 D5 K28.5 AA D5 D5
EOFrt	EOF Remove-Terminate Class 4	Negative Positive	K28.5 D21.4 D25.4 D25.4 K28.5 D21.5 D25.4 D25.4	K28.5 95 99 99 K28.5 B5 99 99
EOFrti	EOF Remove-Terminate Invalid Class 4	Negative Positive	K28.5 D10.4 D25.4 D25.4 K28.5 D10.5 D25.4 D25.4	K28.5 8A 99 99 K28.5 AA 99 99
IDLE	Idle	Negative	K28.5 D21.4 D21.5 D21.5	K28.5 95 B5 B5
R_RDY	Receiver_Ready	Negative	K28.5 D21.4 D10.2 D10.2	K28.5 95 4A 4A5
VC_RDY	Virtual Circuit Ready	Negative	K28.5 D21.7 VC.ID VC.ID	K28.5 F5 xx xx
BB_SCs	Buffer-to-buffer State Change (SOF)	Negative	K28.5 D21.4 D22.4 D22.4	K28.5 95 96 96
BB_SCr	Buffer-to-buffer State Change (R_RDY)	Negative	K28.5 D21.4 D22.6 D22.6	K28.5 95 D6 D6
SYNx	Clock Synchronization Word x	Negative	K28.5 D31.3 CS_x CS_x	K28.5 7F xx xx
SYNy	Clock Synchronization Word y	Negative	K28.5 D31.3 CS_y CS_y	K28.5 7F xx xx
SYNz	Clock Synchronization Word z	Negative	K28.5 D31.3 CS_z CS_z	K28.5 7F xx xx
OLS	Offline	Negative	K28.5 D21.1 D10.4 D21.2	K28.5 35 8A 55
NOS	Not_Operational	Negative	K28.5 D21.2 D31.5 D5.2	K28.5 55 BF 45
LR	Link_Reset	Negative	K28.5 D9.2 D31.5 D9.2	K28.5 49 BF 49
LRR	Link_Reset_Response	Negative	K28.5 D21.1 D31.5 D9.2	K28.5 55 BF 49
OPNyx	Open Loop Port	Negative	K28.5 D17.4 ALPD ALPS	K28.5 91 xx xx
OPNfr	Open Loop Port	Negative	K28.5 D17.4 D31.7 D31.7	K28.5 91 FF FF
CLS	Close Loop Port	Negative	K28.5 D5.4 D21.5 D21.5	K28.5 85 B5 B5
MRK	Mark	Negative	K28.5 D31.2 type ALPS	K28.5 5F xx xx
LIP	Loop Initialization, Acquire PA	Negative	K28.5 D21.0 D23.7 D23.7	K28.5 15 F7 F7
LIP	Loop Initialization, Rcvr Fail	Negative	K28.5 D21.0 D24.7 D23.7	K28.5 15 F8 F7
LIP	Loop Initialization, Reinitialize	Negative	K28.5 D21.0 D23.7 ALPS	K28.5 15 F7 xx
LIP	Loop Initialization, Fail at PS	Negative	K28.5 D21.0 D24.7 ALPS	K28.5 15 F8 xx
LIP	Loop Initialization, Reset PD	Negative	K28.5 D21.0 ALPD ALPS	K28.5 15 xx xx
LPEyx	Loop Port Enable, enable PD	Negative	K28.5 D5.0 ALPD ALPS	K28.5 05 xx xx
LPEfx	Loop Port Enable, enable all	Negative	K28.5 D5.0 D31.7 ALPS	K28.5 05 FF xx
LPByx	Loop Port Bypass, bypass PD	Negative	K28.5 D9.0 ALPD ALPS	K28.5 09 xx xx
ARBx	Arbitrate For Loop	Negative	K28.5 D20.4 ALPS ALPS	K28.5 94 xx xx
ARB(F0)	Arbitrate For Loop, fairness	Negative	K28.5 D20.4 D16.7 D16.7	K28.5 94 F0 F0

# ***Appendix B***

## **8-Bit/10-Bit Mapping**

This appendix contains tables sorted by values for 8-bit/10-bit mapping.

The following table lists:

## Legal 8-Bit/10-Bit Characters Sorted by 10-Bit Value

10B Dec	8B Dec	ASCII+	HEX	Previous Disparity	Data Byte Name	10 B	Comment
85	87	W	57	RD +	D23.2	00 0101 0101	
86	215	x	D7	RD +	D23.6	00 0101 0110	
87	247	÷	F7	RD +	K23.7	00 0101 0111	
89	55	7	37	RD +	D23.1	00 0101 1001	
90	183	.	B7	RD +	D23.5	00 0101 1010	
91	23	ETB	17	RD +	D23.0	00 0101 1011	
92	119	w	77	RD +	D23.3	00 0101 1100	
93	151	—	97	RD +	D23.4	00 0101 1101	
94	247	÷	F7	RD +	D23.7	00 0101 1110	
101	72	H	48	RD +	D8.2	00 0110 0101	
102	200	È	C8	RD +	D8.6	00 0110 0110	
105	40	(	28	RD +	D8.1	00 0110 1001	
106	168	ˆ	A8	RD +	D8.5	00 0110 1010	
107	8	BS	08	RD +	D8.0	00 0110 1011	
108	104	h	68	RD +	D8.3	00 0110 1100	
109	136	ˆ	88	RD +	D8.4	00 0110 1101	
110	232	è	E8	RD +	D8.7	00 0110 1110	
113	231	ç	E7	RD +	D7.7	00 0111 0001	
114	135	‡	87	RD +	D7.4	00 0111 0010	
115	103	g	67	RD +	D7.3	00 0111 0011	
116	7	BEL	07	RD +	D7.0	00 0111 0100	
117	71	G	47	RD +	D7.2	00 0111 0101	
118	199	Ç	C7	RD +	D7.6	00 0111 0110	
121	39	'	27	RD +	D7.1	00 0111 1001	
122	167	§	A7	RD +	D7.5	00 0111 1010	
149	91	[	5B	RD +	D27.2	00 1001 0101	
150	219	Û	DB	RD +	D27.6	00 1001 0110	
151	251	û	FB	RD +	K27.7	00 1001 0111	
153	59	;	3B	RD +	D27.1	00 1001 1001	
154	187	»	BB	RD +	D27.5	00 1001 1010	
155	27	ESC	1B	RD +	D27.0	00 1001 1011	
156	123	{	7B	RD +	D27.3	00 1001 1100	
157	155	›	9B	RD +	D27.4	00 1001 1101	
158	251	Û	FB	RD +	D27.7	00 1001 1110	
165	68	D	44	RD +	D4.2	00 1010 0101	
166	196	Ä	C4	RD +	D4.6	00 1010 0110	
169	36	\$	24	RD +	D4.1	00 1010 1001	
170	164	¤	A4	RD +	D4.5	00 1010 1010	
171	4	EOT	04	RD +	D4.0	00 1010 1011	
172	100	d	64	RD +	D4.3	00 1010 1100	
173	132	ˆ	84	RD +	D4.4	00 1010 1101	
174	228	ä	E4	RD +	D4.7	00 1010 1110	
177	244	ô	F4	RD +	D20.7	00 1011 0001	
178	148	"	94	RD +	D20.4	00 1011 0010	
179	116	t	74	RD +	D20.3	00 1011 0011	
180	20	DC4	14	RD +	D20.0	00 1011 0100	
181	84	T	54	RD+/-	D20.2	00 1011 0101	
182	212	Ô	D4	RD+/-	D20.6	00 1011 0110	
183	244	ô	F4	RD--	D20.7	00 1011 0111	
185	52	4	34	RD+/-	D20.1	00 1011 1001	
186	180	'	B4	RD+/-	D20.5	00 1011 1010	
187	20	DC4	14	RD--	D20.0	00 1011 1011	
188	116	t	74	RD--	D20.3	00 1011 1100	
189	148	"	94	RD--	D20.4	00 1011 1101	
197	88	X	58	RD +	D24.2	00 1100 0101	
198	216	Ø	D8	RD +	D24.6	00 1100 0110	
201	56	8	38	RD +	D24.1	00 1100 1001	
202	184	.	B8	RD +	D24.5	00 1100 1010	

203	24	CAN	18	RD +	D24.0	00 1100 1011	
204	120	x	78	RD +	D24.3	00 1100 1100	
205	152	ˆ	98	RD +	D24.4	00 1100 1101	
206	248	ø	F8	RD +	D24.7	00 1100 1110	
209	236	ï	EC	RD +	D12.7	00 1101 0001	
210	140	œ	8C	RD +	D12.4	00 1101 0010	
211	108	l	6C	RD +	D12.3	00 1101 0011	
212	12	FF	0C	RD +	D12.0	00 1101 0100	
213	76	L	4C	RD+/-	D12.2	00 1101 0101	
214	204	ì	CC	RD+/-	D12.6	00 1101 0110	
217	44	,	2C	RD+/-	D12.1	00 1101 1001	
218	172	ˆ	AC	RD+/-	D12.5	00 1101 1010	
219	12	FF	0C	RD--	D12.0	00 1101 1011	
220	108	l	6C	RD--	D12.3	00 1101 1100	
221	140	œ	8C	RD--	D12.4	00 1101 1101	
222	236	ï	EC	RD--	D12.7	00 1101 1110	
225	252	Û	FC	RD +	D28.7	00 1110 0001	
226	156	œ	9C	RD +	D28.4	00 1110 0010	
227	124		7C	RD +	D28.3	00 1110 0011	
228	28	FS	1C	RD +	D28.0	00 1110 0100	
229	92	\	5C	RD+/-	D28.2	00 1110 0101	
230	220	Û	DC	RD+/-	D28.6	00 1110 0110	
233	60	<	3C	RD+/-	D28.1	00 1110 1001	
234	188	¼	BC	RD+/-	D28.5	00 1110 1010	
235	28	FS	1C	RD--	D28.0	00 1110 1011	
236	124		7C	RD--	D28.3	00 1110 1100	
237	156	œ	9C	RD--	D28.4	00 1110 1101	
238	252	Û	FC	RD--	D28.7	00 1110 1110	
242	156	œ	9C	RD --	K28.4	00 1111 0010	Reserved*
243	124		7C	RD --	K28.3	00 1111 0011	Reserved*
244	28	FS	1C	RD --	K28.0	00 1111 0100	Reserved*
245	92	\	5C	RD --	K28.2	00 1111 0101	Reserved*
246	220	Û	DC	RD --	K28.6	00 1111 0110	Reserved*
248	252	Û	FC	RD --	K28.7	00 1111 1000	Test
249	60	<	3C	RD --	K28.1	00 1111 1001	Reserved*
250	188	¼	BC	RD --	K28.5	00 1111 1010	Sync
277	93	]	5D	RD +	D29.2	01 0001 0101	
278	221	ÿ	DD	RD +	D29.6	01 0001 0110	
279	253	ÿ	FD	RD +	K29.7	01 0001 0111	
281	61	=	3D	RD +	D29.1	01 0001 1001	
282	189	½	BD	RD +	D29.5	01 0001 1010	
283	29	GS	1D	RD +	D29.0	01 0001 1011	
284	125	}	7D	RD +	D29.3	01 0001 1100	
285	157	_	9D	RD +	D29.4	01 0001 1101	
286	253	ÿ	FD	RD +	D29.7	01 0001 1110	
293	66	B	42	RD +	D2.2	01 0010 0101	
294	194	Ä	C2	RD +	D2.6	01 0010 0110	
297	34	"	22	RD +	D2.1	01 0010 1001	
298	162	¢	A2	RD +	D2.5	01 0010 1010	
299	2	STX	02	RD +	D2.0	01 0010 1011	
300	98	b	62	RD +	D2.3	01 0010 1100	
301	130	,	82	RD +	D2.4	01 0010 1101	
302	226	â	E2	RD +	D2.7	01 0010 1110	
305	242	ò	F2	RD +	D18.7	01 0011 0001	
306	146	'	92	RD +	D18.4	01 0011 0010	
307	114	r	72	RD +	D18.3	01 0011 0011	
308	18	DC2	12	RD +	D18.0	01 0011 0100	
309	82	R	52	RD+/-	D18.2	01 0011 0101	
310	210	Ò	D2	RD+/-	D18.6	01 0011 0110	
311	242	ò	F2	RD--	D18.7	01 0011 0111	
313	50	2	32	RD+/-	D18.1	01 0011 1001	
314	178	²	B2	RD+/-	D18.5	01 0011 1010	
315	18	DC2	12	RD--	D18.0	01 0011 1011	
316	114	r	72	RD--	D18.3	01 0011 1100	
317	146	'	92	RD--	D18.4	01 0011 1101	
325	95	_	5F	RD +	D31.2	01 0100 0101	
326	223	ß	DF	RD +	D31.6	01 0100 0110	
329	63	?	3F	RD +	D31.1	01 0100 1001	
330	191	¿	BF	RD +	D31.5	01 0100 1010	
331	31	US	1F	RD +	D31.0	01 0100 1011	
332	127	DELETE	7F	RD +	D31.3	01 0100 1100	
333	159	ÿ	9F	RD +	D31.4	01 0100 1101	
334	255	ÿ	FF	RD +	D31.7	01 0100 1110	

337	234	ê	EA	RD +	D10.7	01 0101 0001	442	176	°	B0	RD--	D16.5	01 1011 1010
338	138	Š	8A	RD +	D10.4	01 0101 0010	450	142	_	8E	RD +	D14.4	01 1100 0010
339	106	j	6A	RD +	D10.3	01 0101 0011	451	110	n	6E	RD +	D14.3	01 1100 0011
340	10	LF	0A	RD +	D10.0	01 0101 0100	452	14	SO	0E	RD +	D14.0	01 1100 0100
341	74	J	4A	RD+/-	D10.2	01 0101 0101	453	78	N	4E	RD+/-	D14.2	01 1100 0101
342	202	Ê	CA	RD+/-	D10.6	01 0101 0110	454	206	î	CE	RD+/-	D14.6	01 1100 0110
345	42	*	2A	RD+/-	D10.1	01 0101 1001	456	238	ï	EE	RD +	D14.7	01 1100 1000
346	170	a	AA	RD+/-	D10.5	01 0101 1010	457	46	.	2E	RD+/-	D14.1	01 1100 1001
347	10	LF	0A	RD--	D10.0	01 0101 1011	458	174	@	AE	RD+/-	D14.5	01 1100 1010
348	106	j	6A	RD--	D10.3	01 0101 1100	459	14	SO	0E	RD--	D14.0	01 1100 1011
349	138	Š	8A	RD--	D10.4	01 0101 1101	460	110	n	6E	RD--	D14.3	01 1100 1100
350	234	ê	EA	RD--	D10.7	01 0101 1110	461	142	_	8E	RD--	D14.4	01 1100 1101
353	250	ú	FA	RD +	D26.7	01 0110 0001	462	238	ï	EE	RD--	D14.7	01 1100 1110
354	154	š	9A	RD +	D26.4	01 0110 0010	465	225	á	E1	RD--	D1.7	01 1101 0001
355	122	z	7A	RD +	D26.3	01 0110 0011	466	129	_	81	RD--	D1.4	01 1101 0010
356	26	SUB	1A	RD +	D26.0	01 0110 0100	467	97	a	61	RD--	D1.3	01 1101 0011
357	90	Z	5A	RD+/-	D26.2	01 0110 0101	468	1	SOH	01	RD--	D1.0	01 1101 0100
358	218	Ú	DA	RD+/-	D26.6	01 0110 0110	469	65	A	41	RD--	D1.2	01 1101 0101
361	58	:	3A	RD+/-	D26.1	01 0110 1001	470	193	Á	C1	RD--	D1.6	01 1101 0110
362	186	°	BA	RD+/-	D26.5	01 0110 1010	473	33	!	21	RD--	D1.1	01 1101 1001
363	26	SUB	1A	RD--	D26.0	01 0110 1011	474	161	j	A1	RD--	D1.5	01 1101 1010
364	122	z	7A	RD--	D26.3	01 0110 1100	481	254	þ	FE	RD--	D30.7	01 1110 0001
365	154	š	9A	RD--	D26.4	01 0110 1101	482	158	_	9E	RD--	D30.4	01 1110 0010
366	250	ú	FA	RD--	D26.7	01 0110 1110	483	126	~	7E	RD--	D30.3	01 1110 0011
369	239	ï	EF	RD--	D15.7	01 0111 0001	484	30	RS	1E	RD--	D30.0	01 1110 0100
370	143	_	8F	RD--	D15.4	01 0111 0010	485	94	^	5E	RD--	D30.2	01 1110 0101
371	111	o	6F	RD--	D15.3	01 0111 0011	486	222	þ	DE	RD--	D30.6	01 1110 0110
372	15	SI	0F	RD--	D15.0	01 0111 0100	488	254	þ	FE	RD --	K30.7	01 1110 1000
373	79	O	4F	RD--	D15.2	01 0111 0101	489	62	>	3E	RD--	D30.1	01 1110 1001
374	207	Ī	CF	RD--	D15.6	01 0111 0110	490	190	¼	BE	RD--	D30.5	01 1110 1010
377	47	/	2F	RD--	D15.1	01 0111 1001	533	94	^	5E	RD +	D30.2	10 0001 0101
378	175	-	AF	RD--	D15.5	01 0111 1010	534	222	þ	DE	RD +	D30.6	10 0001 0110
389	64	@	40	RD +	D0.2	01 1000 0101	535	254	þ	FE	RD +	K30.7	10 0001 0111
390	192	À	C0	RD +	D0.6	01 1000 0110	537	62	>	3E	RD +	D30.1	10 0001 1001
393	32	SPACE	20	RD +	D0.1	01 1000 1001	538	190	¼	BE	RD +	D30.5	10 0001 1010
394	160		A0	RD +	D0.5	01 1000 1010	539	30	RS	1E	RD +	D30.0	10 0001 1011
395	0	NUL	00	RD +	D0.0	01 1000 1011	540	126	~	7E	RD +	D30.3	10 0001 1100
396	96	`	60	RD +	D0.3	01 1000 1100	541	158	_	9E	RD +	D30.4	10 0001 1101
397	128	_	80	RD +	D0.4	01 1000 1101	542	254	þ	FE	RD +	D30.7	10 0001 1110
398	224	à	E0	RD +	D0.7	01 1000 1110	549	65	A	41	RD +	D1.2	10 0010 0101
401	230	æ	E6	RD +	D6.7	01 1001 0001	550	193	Á	C1	RD +	D1.6	10 0010 0110
402	134	†	86	RD +	D6.4	01 1001 0010	553	33	!	21	RD +	D1.1	10 0010 1001
403	102	f	66	RD +	D6.3	01 1001 0011	554	161	j	A1	RD +	D1.5	10 0010 1010
404	6	ACK	06	RD +	D6.0	01 1001 0100	555	1	SOH	01	RD +	D1.0	10 0010 1011
405	70	F	46	RD+/-	D6.2	01 1001 0101	556	97	a	61	RD +	D1.3	10 0010 1100
406	198	Æ	C6	RD+/-	D6.6	01 1001 0110	557	129	_	81	RD +	D1.4	10 0010 1101
409	38	&	26	RD+/-	D6.1	01 1001 1001	558	225	á	E1	RD +	D1.7	10 0010 1110
410	166	ı	A6	RD+/-	D6.5	01 1001 1010	561	241	ñ	F1	RD +	D17.7	10 0011 0001
411	6	ACK	06	RD--	D6.0	01 1001 1011	562	145	'	91	RD +	D17.4	10 0011 0010
412	102	f	66	RD--	D6.3	01 1001 1100	563	113	q	71	RD +	D17.3	10 0011 0011
413	134	†	86	RD--	D6.4	01 1001 1101	564	17	DC1	11	RD +	D17.0	10 0011 0100
414	230	æ	E6	RD--	D6.7	01 1001 1110	565	81	Q	51	RD+/-	D17.2	10 0011 0101
417	246	ö	F6	RD +	D22.7	01 1010 0001	566	209	Ñ	D1	RD+/-	D17.6	10 0011 0110
418	150	_	96	RD +	D22.4	01 1010 0010	567	241	ñ	F1	RD--	D17.7	10 0011 0111
419	118	v	76	RD +	D22.3	01 1010 0011	569	49	ı	31	RD+/-	D17.1	10 0011 1001
420	22	SYN	16	RD +	D22.0	01 1010 0100	570	177	±	B1	RD+/-	D17.5	10 0011 1010
421	86	V	56	RD+/-	D22.2	01 1010 0101	571	17	DC1	11	RD--	D17.0	10 0011 1011
422	214	Ö	D6	RD+/-	D22.6	01 1010 0110	572	113	q	71	RD--	D17.3	10 0011 1100
425	54	6	36	RD+/-	D22.1	01 1010 1001	573	145	'	91	RD--	D17.4	10 0011 1101
426	182	¶	B6	RD+/-	D22.5	01 1010 1010	581	80	P	50	RD +	D16.2	10 0100 0101
427	22	SYN	16	RD--	D22.0	01 1010 1011	582	208	Ð	D0	RD +	D16.6	10 0100 0110
428	118	v	76	RD--	D22.3	01 1010 1100	585	48	0	30	RD +	D16.1	10 0100 1001
429	150	_	96	RD--	D22.4	01 1010 1101	586	176	°	B0	RD +	D16.5	10 0100 1010
430	246	ö	F6	RD--	D22.7	01 1010 1110	587	16	DLE	10	RD +	D16.0	10 0100 1011
433	240	ð	F0	RD--	D16.7	01 1011 0001	588	112	p	70	RD +	D16.3	10 0100 1100
434	144	_	90	RD--	D16.4	01 1011 0010	589	144	_	90	RD +	D16.4	10 0100 1101
435	112	p	70	RD--	D16.3	01 1011 0011	590	240	ð	F0	RD +	D16.7	10 0100 1110
436	16	DLE	10	RD--	D16.0	01 1011 0100	593	233	é	E9	RD +	D9.7	10 0101 0001
437	80	P	50	RD--	D16.2	01 1011 0101	594	137	‰	89	RD +	D9.4	10 0101 0010
438	208	Ð	D0	RD--	D16.6	01 1011 0110	595	105	i	69	RD +	D9.3	10 0101 0011
441	48	0	30	RD--	D16.1	01 1011 1001	596	9	HT	09	RD +	D9.0	10 0101 0100
							597	73	ı	49	RD+/-	D9.2	10 0101 0101
							598	201	É	C9	RD+/-	D9.6	10 0101 0110

Reserved\*



---

844	107	k	6B	RD--	D11.3	11 0100 1100	
845	139	ˆ	8B	RD--	D11.4	11 0100 1101	
846	235	ë	EB	RD--	D11.7	11 0100 1110	
849	228	ä	E4	RD--	D4.7	11 0101 0001	
850	132	„	84	RD--	D4.4	11 0101 0010	
851	100	d	64	RD--	D4.3	11 0101 0011	
852	4	EOT	04	RD--	D4.0	11 0101 0100	
853	68	D	44	RD--	D4.2	11 0101 0101	
854	196	Ä	C4	RD--	D4.6	11 0101 0110	
857	36	\$	24	RD--	D4.1	11 0101 1001	
858	164	¤	A4	RD--	D4.5	11 0101 1010	
865	251	û	FB	RD--	D27.7	11 0110 0001	
866	155	›	9B	RD--	D27.4	11 0110 0010	
867	123	{	7B	RD--	D27.3	11 0110 0011	
868	27	ESC	1B	RD--	D27.0	11 0110 0100	
869	91	[	5B	RD--	D27.2	11 0110 0101	
870	219	Û	DB	RD--	D27.6	11 0110 0110	
872	251	û	FB	RD --	K27.7	11 0110 1000	Reserved*
873	59	;	3B	RD--	D27.1	11 0110 1001	
874	187	»	BB	RD--	D27.5	11 0110 1010	
901	71	G	47	RD--	D7.2	11 1000 0101	
902	199	Ç	C7	RD--	D7.6	11 1000 0110	
905	39	'	27	RD--	D7.1	11 1000 1001	
906	167	§	A7	RD--	D7.5	11 1000 1010	
907	7	BEL	07	RD--	D7.0	11 1000 1011	
908	103	g	67	RD--	D7.3	11 1000 1100	
909	135	‡	87	RD--	D7.4	11 1000 1101	
910	231	ç	E7	RD--	D7.7	11 1000 1110	
913	232	è	E8	RD--	D8.7	11 1001 0001	
914	136	ˆ	88	RD--	D8.4	11 1001 0010	
915	104	h	68	RD--	D8.3	11 1001 0011	
916	8	BS	08	RD--	D8.0	11 1001 0100	
917	72	H	48	RD--	D8.2	11 1001 0101	
918	200	È	C8	RD--	D8.6	11 1001 0110	
921	40	(	28	RD--	D8.1	11 1001 1001	
922	168	¨	A8	RD--	D8.5	11 1001 1010	
929	247	÷	F7	RD--	D23.7	11 1010 0001	
930	151	—	97	RD--	D23.4	11 1010 0010	
931	119	w	77	RD--	D23.3	11 1010 0011	
932	23	ETB	17	RD--	D23.0	11 1010 0100	
933	87	W	57	RD--	D23.2	11 1010 0101	
934	215	x	D7	RD--	D23.6	11 1010 0110	
936	247	÷	F7	RD --	K23.7	11 1010 1000	Reserved*
937	55	7	37	RD--	D23.1	11 1010 1001	
938	183	.	B7	RD--	D23.5	11 1010 1010	

---

The following table lists:

## 10-Bit Values with No 8-bit Mapping Sorted by 10-Bit Value

10B Dec	10 B	COMMENT
0	00 0000 0000	ILLEGAL
1	00 0000 0001	ILLEGAL
2	00 0000 0010	ILLEGAL
3	00 0000 0011	ILLEGAL
4	00 0000 0100	ILLEGAL
5	00 0000 0101	ILLEGAL
6	00 0000 0110	ILLEGAL
7	00 0000 0111	ILLEGAL
8	00 0000 1000	ILLEGAL
9	00 0000 1001	ILLEGAL
10	00 0000 1010	ILLEGAL
11	00 0000 1011	ILLEGAL
12	00 0000 1100	ILLEGAL
13	00 0000 1101	ILLEGAL
14	00 0000 1110	ILLEGAL
15	00 0000 1111	ILLEGAL
16	00 0001 0000	ILLEGAL
17	00 0001 0001	ILLEGAL
18	00 0001 0010	ILLEGAL
19	00 0001 0011	ILLEGAL
20	00 0001 0100	ILLEGAL
21	00 0001 0101	ILLEGAL
22	00 0001 0110	ILLEGAL
23	00 0001 0111	ILLEGAL
24	00 0001 1000	ILLEGAL
25	00 0001 1001	ILLEGAL
26	00 0001 1010	ILLEGAL
27	00 0001 1011	ILLEGAL
28	00 0001 1100	ILLEGAL
29	00 0001 1101	ILLEGAL
30	00 0001 1110	ILLEGAL
31	00 0001 1111	ILLEGAL
32	00 0010 0000	ILLEGAL
33	00 0010 0001	ILLEGAL
34	00 0010 0010	ILLEGAL
35	00 0010 0011	ILLEGAL
36	00 0010 0100	ILLEGAL
37	00 0010 0101	ILLEGAL
38	00 0010 0110	ILLEGAL
39	00 0010 0111	ILLEGAL
40	00 0010 1000	ILLEGAL
41	00 0010 1001	ILLEGAL
42	00 0010 1010	ILLEGAL
43	00 0010 1011	ILLEGAL
44	00 0010 1100	ILLEGAL
45	00 0010 1101	ILLEGAL
46	00 0010 1110	ILLEGAL
47	00 0010 1111	ILLEGAL
48	00 0011 0000	ILLEGAL
49	00 0011 0001	ILLEGAL
50	00 0011 0010	ILLEGAL
51	00 0011 0011	ILLEGAL
52	00 0011 0100	ILLEGAL
53	00 0011 0101	ILLEGAL
54	00 0011 0110	ILLEGAL
55	00 0011 0111	ILLEGAL
56	00 0011 1000	ILLEGAL
57	00 0011 1001	ILLEGAL
58	00 0011 1010	ILLEGAL
59	00 0011 1011	ILLEGAL
60	00 0011 1100	ILLEGAL
61	00 0011 1101	ILLEGAL
62	00 0011 1110	ILLEGAL
63	00 0011 1111	ILLEGAL
64	00 0100 0000	ILLEGAL
65	00 0100 0001	ILLEGAL
66	00 0100 0010	ILLEGAL
67	00 0100 0011	ILLEGAL
68	00 0100 0100	ILLEGAL
69	00 0100 0101	ILLEGAL
70	00 0100 0110	ILLEGAL
71	00 0100 0111	ILLEGAL
72	00 0100 1000	ILLEGAL
73	00 0100 1001	ILLEGAL
74	00 0100 1010	ILLEGAL
75	00 0100 1011	ILLEGAL
76	00 0100 1100	ILLEGAL
77	00 0100 1101	ILLEGAL
78	00 0100 1110	ILLEGAL
79	00 0100 1111	ILLEGAL
80	00 0101 0000	ILLEGAL
81	00 0101 0001	ILLEGAL
82	00 0101 0010	ILLEGAL
83	00 0101 0011	ILLEGAL
84	00 0101 0100	ILLEGAL
88	00 0101 1000	ILLEGAL
95	00 0101 1111	ILLEGAL
96	00 0110 0000	ILLEGAL
97	00 0110 0001	ILLEGAL
98	00 0110 0010	ILLEGAL
99	00 0110 0011	ILLEGAL
100	00 0110 0100	ILLEGAL
103	00 0110 0111	ILLEGAL
104	00 0110 1000	ILLEGAL
111	00 0110 1111	ILLEGAL
112	00 0111 0000	ILLEGAL
119	00 0111 0111	ILLEGAL
120	00 0111 1000	ILLEGAL
123	00 0111 1011	ILLEGAL
124	00 0111 1100	ILLEGAL
125	00 0111 1101	ILLEGAL
126	00 0111 1110	ILLEGAL
127	00 0111 1111	ILLEGAL
128	00 1000 0000	ILLEGAL
129	00 1000 0001	ILLEGAL
130	00 1000 0010	ILLEGAL
131	00 1000 0011	ILLEGAL
132	00 1000 0100	ILLEGAL
133	00 1000 0101	ILLEGAL
134	00 1000 0110	ILLEGAL
135	00 1000 0111	ILLEGAL
136	00 1000 1000	ILLEGAL
137	00 1000 1001	ILLEGAL
138	00 1000 1010	ILLEGAL
139	00 1000 1011	ILLEGAL
140	00 1000 1100	ILLEGAL
141	00 1000 1101	ILLEGAL

---

142 00 1000 1110	ILLEGAL	276 01 0001 0100	ILLEGAL
143 00 1000 1111	ILLEGAL	280 01 0001 1000	ILLEGAL
144 00 1001 0000	ILLEGAL	287 01 0001 1111	ILLEGAL
145 00 1001 0001	ILLEGAL	288 01 0010 0000	ILLEGAL
146 00 1001 0010	ILLEGAL	289 01 0010 0001	ILLEGAL
147 00 1001 0011	ILLEGAL	290 01 0010 0010	ILLEGAL
148 00 1001 0100	ILLEGAL	291 01 0010 0011	ILLEGAL
152 00 1001 1000	ILLEGAL	292 01 0010 0100	ILLEGAL
159 00 1001 1111	ILLEGAL	295 01 0010 0111	ILLEGAL
160 00 1010 0000	ILLEGAL	296 01 0010 1000	ILLEGAL
161 00 1010 0001	ILLEGAL	303 01 0010 1111	ILLEGAL
162 00 1010 0010	ILLEGAL	304 01 0011 0000	ILLEGAL
163 00 1010 0011	ILLEGAL	312 01 0011 1000	ILLEGAL
164 00 1010 0100	ILLEGAL	318 01 0011 1110	ILLEGAL
167 00 1010 0111	ILLEGAL	319 01 0011 1111	ILLEGAL
168 00 1010 1000	ILLEGAL	320 01 0100 0000	ILLEGAL
175 00 1010 1111	ILLEGAL	321 01 0100 0001	ILLEGAL
176 00 1011 0000	ILLEGAL	322 01 0100 0010	ILLEGAL
184 00 1011 1000	ILLEGAL	323 01 0100 0011	ILLEGAL
190 00 1011 1110	ILLEGAL	324 01 0100 0100	ILLEGAL
191 00 1011 1111	ILLEGAL	327 01 0100 0111	ILLEGAL
192 00 1100 0000	ILLEGAL	328 01 0100 1000	ILLEGAL
193 00 1100 0001	ILLEGAL	335 01 0100 1111	ILLEGAL
194 00 1100 0010	ILLEGAL	336 01 0101 0000	ILLEGAL
195 00 1100 0011	ILLEGAL	343 01 0101 0111	ILLEGAL
196 00 1100 0100	ILLEGAL	344 01 0101 1000	ILLEGAL
199 00 1100 0111	ILLEGAL	351 01 0101 1111	ILLEGAL
200 00 1100 1000	ILLEGAL	352 01 0110 0000	ILLEGAL
207 00 1100 1111	ILLEGAL	359 01 0110 0111	ILLEGAL
208 00 1101 0000	ILLEGAL	360 01 0110 1000	ILLEGAL
215 00 1101 0111	ILLEGAL	367 01 0110 1111	ILLEGAL
216 00 1101 1000	ILLEGAL	368 01 0111 0000	ILLEGAL
223 00 1101 1111	ILLEGAL	375 01 0111 0111	ILLEGAL
224 00 1110 0000	ILLEGAL	376 01 0111 1000	ILLEGAL
231 00 1110 0111	ILLEGAL	379 01 0111 1011	ILLEGAL
232 00 1110 1000	ILLEGAL	380 01 0111 1100	ILLEGAL
239 00 1110 1111	ILLEGAL	381 01 0111 1101	ILLEGAL
240 00 1111 0000	ILLEGAL	382 01 0111 1110	ILLEGAL
241 00 1111 0001	ILLEGAL	383 01 0111 1111	ILLEGAL
247 00 1111 0111	ILLEGAL	384 01 1000 0000	ILLEGAL
251 00 1111 1011	ILLEGAL	385 01 1000 0001	ILLEGAL
252 00 1111 1100	ILLEGAL	386 01 1000 0010	ILLEGAL
253 00 1111 1101	ILLEGAL	387 01 1000 0011	ILLEGAL
254 00 1111 1110	ILLEGAL	388 01 1000 0100	ILLEGAL
255 00 1111 1111	ILLEGAL	391 01 1000 0111	ILLEGAL
256 01 0000 0000	ILLEGAL	392 01 1000 1000	ILLEGAL
257 01 0000 0001	ILLEGAL	399 01 1000 1111	ILLEGAL
258 01 0000 0010	ILLEGAL	400 01 1001 0000	ILLEGAL
259 01 0000 0011	ILLEGAL	407 01 1001 0111	ILLEGAL
260 01 0000 0100	ILLEGAL	408 01 1001 1000	ILLEGAL
261 01 0000 0101	ILLEGAL	415 01 1001 1111	ILLEGAL
262 01 0000 0110	ILLEGAL	416 01 1010 0000	ILLEGAL
263 01 0000 0111	ILLEGAL	423 01 1010 0111	ILLEGAL
264 01 0000 1000	ILLEGAL	424 01 1010 1000	ILLEGAL
265 01 0000 1001	ILLEGAL	431 01 1010 1111	ILLEGAL
266 01 0000 1010	ILLEGAL	432 01 1011 0000	ILLEGAL
267 01 0000 1011	ILLEGAL	439 01 1011 0111	ILLEGAL
268 01 0000 1100	ILLEGAL	440 01 1011 1000	ILLEGAL
269 01 0000 1101	ILLEGAL	443 01 1011 1011	ILLEGAL
270 01 0000 1110	ILLEGAL	444 01 1011 1100	ILLEGAL
271 01 0000 1111	ILLEGAL	445 01 1011 1101	ILLEGAL
272 01 0001 0000	ILLEGAL	446 01 1011 1110	ILLEGAL
273 01 0001 0001	ILLEGAL	447 01 1011 1111	ILLEGAL
274 01 0001 0010	ILLEGAL	448 01 1100 0000	ILLEGAL
275 01 0001 0011	ILLEGAL	449 01 1100 0001	ILLEGAL

---

## 8-Bit/10-Bit Mapping

---

455	01 1100 0111	ILLEGAL	568	10 0011 1000	ILLEGAL
463	01 1100 1111	ILLEGAL	574	10 0011 1110	ILLEGAL
464	01 1101 0000	ILLEGAL	575	10 0011 1111	ILLEGAL
471	01 1101 0111	ILLEGAL	576	10 0100 0000	ILLEGAL
472	01 1101 1000	ILLEGAL	577	10 0100 0001	ILLEGAL
475	01 1101 1011	ILLEGAL	578	10 0100 0010	ILLEGAL
476	01 1101 1100	ILLEGAL	579	10 0100 0011	ILLEGAL
477	01 1101 1101	ILLEGAL	580	10 0100 0100	ILLEGAL
478	01 1101 1110	ILLEGAL	583	10 0100 0111	ILLEGAL
479	01 1101 1111	ILLEGAL	584	10 0100 1000	ILLEGAL
480	01 1110 0000	ILLEGAL	591	10 0100 1111	ILLEGAL
487	01 1110 0111	ILLEGAL	592	10 0101 0000	ILLEGAL
491	01 1110 1011	ILLEGAL	599	10 0101 0111	ILLEGAL
492	01 1110 1100	ILLEGAL	600	10 0101 1000	ILLEGAL
493	01 1110 1101	ILLEGAL	607	10 0101 1111	ILLEGAL
494	01 1110 1110	ILLEGAL	608	10 0110 0000	ILLEGAL
495	01 1110 1111	ILLEGAL	615	10 0110 0111	ILLEGAL
496	01 1111 0000	ILLEGAL	616	10 0110 1000	ILLEGAL
497	01 1111 0001	ILLEGAL	623	10 0110 1111	ILLEGAL
498	01 1111 0010	ILLEGAL	624	10 0111 0000	ILLEGAL
499	01 1111 0011	ILLEGAL	631	10 0111 0111	ILLEGAL
500	01 1111 0100	ILLEGAL	632	10 0111 1000	ILLEGAL
501	01 1111 0101	ILLEGAL	635	10 0111 1011	ILLEGAL
502	01 1111 0110	ILLEGAL	636	10 0111 1100	ILLEGAL
503	01 1111 0111	ILLEGAL	637	10 0111 1101	ILLEGAL
504	01 1111 1000	ILLEGAL	638	10 0111 1110	ILLEGAL
505	01 1111 1001	ILLEGAL	639	10 0111 1111	ILLEGAL
506	01 1111 1010	ILLEGAL	640	10 1000 0000	ILLEGAL
507	01 1111 1011	ILLEGAL	641	10 1000 0001	ILLEGAL
508	01 1111 1100	ILLEGAL	642	10 1000 0010	ILLEGAL
509	01 1111 1101	ILLEGAL	643	10 1000 0011	ILLEGAL
510	01 1111 1110	ILLEGAL	644	10 1000 0100	ILLEGAL
511	01 1111 1111	ILLEGAL	647	10 1000 0111	ILLEGAL
512	10 0000 0000	ILLEGAL	648	10 1000 1000	ILLEGAL
513	10 0000 0001	ILLEGAL	655	10 1000 1111	ILLEGAL
514	10 0000 0010	ILLEGAL	656	10 1001 0000	ILLEGAL
515	10 0000 0011	ILLEGAL	663	10 1001 0111	ILLEGAL
516	10 0000 0100	ILLEGAL	664	10 1001 1000	ILLEGAL
517	10 0000 0101	ILLEGAL	671	10 1001 1111	ILLEGAL
518	10 0000 0110	ILLEGAL	672	10 1010 0000	ILLEGAL
519	10 0000 0111	ILLEGAL	679	10 1010 0111	ILLEGAL
520	10 0000 1000	ILLEGAL	680	10 1010 1000	ILLEGAL
521	10 0000 1001	ILLEGAL	687	10 1010 1111	ILLEGAL
522	10 0000 1010	ILLEGAL	688	10 1011 0000	ILLEGAL
523	10 0000 1011	ILLEGAL	695	10 1011 0111	ILLEGAL
524	10 0000 1100	ILLEGAL	696	10 1011 1000	ILLEGAL
525	10 0000 1101	ILLEGAL	699	10 1011 1011	ILLEGAL
526	10 0000 1110	ILLEGAL	700	10 1011 1100	ILLEGAL
527	10 0000 1111	ILLEGAL	701	10 1011 1101	ILLEGAL
528	10 0001 0000	ILLEGAL	702	10 1011 1110	ILLEGAL
529	10 0001 0001	ILLEGAL	703	10 1011 1111	ILLEGAL
530	10 0001 0010	ILLEGAL	704	10 1100 0000	ILLEGAL
531	10 0001 0011	ILLEGAL	705	10 1100 0001	ILLEGAL
532	10 0001 0100	ILLEGAL	711	10 1100 0111	ILLEGAL
536	10 0001 1000	ILLEGAL	719	10 1100 1111	ILLEGAL
543	10 0001 1111	ILLEGAL	720	10 1101 0000	ILLEGAL
544	10 0010 0000	ILLEGAL	727	10 1101 0111	ILLEGAL
545	10 0010 0001	ILLEGAL	728	10 1101 1000	ILLEGAL
546	10 0010 0010	ILLEGAL	731	10 1101 1011	ILLEGAL
547	10 0010 0011	ILLEGAL	732	10 1101 1100	ILLEGAL
548	10 0010 0100	ILLEGAL	733	10 1101 1101	ILLEGAL
551	10 0010 0111	ILLEGAL	734	10 1101 1110	ILLEGAL
552	10 0010 1000	ILLEGAL	735	10 1101 1111	ILLEGAL
559	10 0010 1111	ILLEGAL	736	10 1110 0000	ILLEGAL
560	10 0011 0000	ILLEGAL	743	10 1110 0111	ILLEGAL

---

747	10 1110 1011	ILLEGAL	881	11 0111 0001	ILLEGAL
748	10 1110 1100	ILLEGAL	882	11 0111 0010	ILLEGAL
749	10 1110 1101	ILLEGAL	883	11 0111 0011	ILLEGAL
750	10 1110 1110	ILLEGAL	884	11 0111 0100	ILLEGAL
751	10 1110 1111	ILLEGAL	885	11 0111 0101	ILLEGAL
752	10 1111 0000	ILLEGAL	886	11 0111 0110	ILLEGAL
753	10 1111 0001	ILLEGAL	887	11 0111 0111	ILLEGAL
754	10 1111 0010	ILLEGAL	888	11 0111 1000	ILLEGAL
755	10 1111 0011	ILLEGAL	889	11 0111 1001	ILLEGAL
756	10 1111 0100	ILLEGAL	890	11 0111 1010	ILLEGAL
757	10 1111 0101	ILLEGAL	891	11 0111 1011	ILLEGAL
758	10 1111 0110	ILLEGAL	892	11 0111 1100	ILLEGAL
759	10 1111 0111	ILLEGAL	893	11 0111 1101	ILLEGAL
760	10 1111 1000	ILLEGAL	894	11 0111 1110	ILLEGAL
761	10 1111 1001	ILLEGAL	895	11 0111 1111	ILLEGAL
762	10 1111 1010	ILLEGAL	896	11 1000 0000	ILLEGAL
763	10 1111 1011	ILLEGAL	897	11 1000 0001	ILLEGAL
764	10 1111 1100	ILLEGAL	898	11 1000 0010	ILLEGAL
765	10 1111 1101	ILLEGAL	899	11 1000 0011	ILLEGAL
766	10 1111 1110	ILLEGAL	900	11 1000 0100	ILLEGAL
767	10 1111 1111	ILLEGAL	903	11 1000 0111	ILLEGAL
768	11 0000 0000	ILLEGAL	904	11 1000 1000	ILLEGAL
769	11 0000 0001	ILLEGAL	911	11 1000 1111	ILLEGAL
770	11 0000 0010	ILLEGAL	912	11 1001 0000	ILLEGAL
771	11 0000 0011	ILLEGAL	919	11 1001 0111	ILLEGAL
772	11 0000 0100	ILLEGAL	920	11 1001 1000	ILLEGAL
776	11 0000 1000	ILLEGAL	923	11 1001 1011	ILLEGAL
782	11 0000 1110	ILLEGAL	924	11 1001 1100	ILLEGAL
783	11 0000 1111	ILLEGAL	925	11 1001 1101	ILLEGAL
784	11 0001 0000	ILLEGAL	926	11 1001 1110	ILLEGAL
791	11 0001 0111	ILLEGAL	927	11 1001 1111	ILLEGAL
792	11 0001 1000	ILLEGAL	928	11 1010 0000	ILLEGAL
799	11 0001 1111	ILLEGAL	935	11 1010 0111	ILLEGAL
800	11 0010 0000	ILLEGAL	939	11 1010 1011	ILLEGAL
807	11 0010 0111	ILLEGAL	940	11 1010 1100	ILLEGAL
808	11 0010 1000	ILLEGAL	941	11 1010 1101	ILLEGAL
815	11 0010 1111	ILLEGAL	942	11 1010 1110	ILLEGAL
816	11 0011 0000	ILLEGAL	943	11 1010 1111	ILLEGAL
823	11 0011 0111	ILLEGAL	944	11 1011 0000	ILLEGAL
824	11 0011 1000	ILLEGAL	945	11 1011 0001	ILLEGAL
827	11 0011 1011	ILLEGAL	946	11 1011 0010	ILLEGAL
828	11 0011 1100	ILLEGAL	947	11 1011 0011	ILLEGAL
829	11 0011 1101	ILLEGAL	948	11 1011 0100	ILLEGAL
830	11 0011 1110	ILLEGAL	949	11 1011 0101	ILLEGAL
831	11 0011 1111	ILLEGAL	950	11 1011 0110	ILLEGAL
832	11 0100 0000	ILLEGAL	951	11 1011 0111	ILLEGAL
833	11 0100 0001	ILLEGAL	952	11 1011 1000	ILLEGAL
839	11 0100 0111	ILLEGAL	953	11 1011 1001	ILLEGAL
847	11 0100 1111	ILLEGAL	954	11 1011 1010	ILLEGAL
848	11 0101 0000	ILLEGAL	955	11 1011 1011	ILLEGAL
855	11 0101 0111	ILLEGAL	956	11 1011 1100	ILLEGAL
856	11 0101 1000	ILLEGAL	957	11 1011 1101	ILLEGAL
859	11 0101 1011	ILLEGAL	958	11 1011 1110	ILLEGAL
860	11 0101 1100	ILLEGAL	959	11 1011 1111	ILLEGAL
861	11 0101 1101	ILLEGAL	960	11 1100 0000	ILLEGAL
862	11 0101 1110	ILLEGAL	961	11 1100 0001	ILLEGAL
863	11 0101 1111	ILLEGAL	962	11 1100 0010	ILLEGAL
864	11 0110 0000	ILLEGAL	963	11 1100 0011	ILLEGAL
871	11 0110 0111	ILLEGAL	964	11 1100 0100	ILLEGAL
875	11 0110 1011	ILLEGAL	965	11 1100 0101	ILLEGAL
876	11 0110 1100	ILLEGAL	966	11 1100 0110	ILLEGAL
877	11 0110 1101	ILLEGAL	967	11 1100 0111	ILLEGAL
878	11 0110 1110	ILLEGAL	968	11 1100 1000	ILLEGAL
879	11 0110 1111	ILLEGAL	969	11 1100 1001	ILLEGAL
880	11 0111 0000	ILLEGAL	970	11 1100 1010	ILLEGAL

---

## 8-Bit/10-Bit Mapping

---

971	11 1100 1011	ILLEGAL
972	11 1100 1100	ILLEGAL
973	11 1100 1101	ILLEGAL
974	11 1100 1110	ILLEGAL
975	11 1100 1111	ILLEGAL
976	11 1101 0000	ILLEGAL
977	11 1101 0001	ILLEGAL
978	11 1101 0010	ILLEGAL
979	11 1101 0011	ILLEGAL
980	11 1101 0100	ILLEGAL
981	11 1101 0101	ILLEGAL
982	11 1101 0110	ILLEGAL
983	11 1101 0111	ILLEGAL
984	11 1101 1000	ILLEGAL
985	11 1101 1001	ILLEGAL
986	11 1101 1010	ILLEGAL
987	11 1101 1011	ILLEGAL
988	11 1101 1100	ILLEGAL
989	11 1101 1101	ILLEGAL
990	11 1101 1110	ILLEGAL
991	11 1101 1111	ILLEGAL
992	11 1110 0000	ILLEGAL
993	11 1110 0001	ILLEGAL
994	11 1110 0010	ILLEGAL
995	11 1110 0011	ILLEGAL
996	11 1110 0100	ILLEGAL
997	11 1110 0101	ILLEGAL
998	11 1110 0110	ILLEGAL
999	11 1110 0111	ILLEGAL
1000	11 1110 1000	ILLEGAL
1001	11 1110 1001	ILLEGAL
1002	11 1110 1010	ILLEGAL
1003	11 1110 1011	ILLEGAL
1004	11 1110 1100	ILLEGAL
1005	11 1110 1101	ILLEGAL
1006	11 1110 1110	ILLEGAL
1007	11 1110 1111	ILLEGAL
1008	11 1111 0000	ILLEGAL
1009	11 1111 0001	ILLEGAL
1010	11 1111 0010	ILLEGAL
1011	11 1111 0011	ILLEGAL
1012	11 1111 0100	ILLEGAL
1013	11 1111 0101	ILLEGAL
1014	11 1111 0110	ILLEGAL
1015	11 1111 0111	ILLEGAL
1016	11 1111 1000	ILLEGAL
1017	11 1111 1001	ILLEGAL
1018	11 1111 1010	ILLEGAL
1019	11 1111 1011	ILLEGAL
1020	11 1111 1100	ILLEGAL
1021	11 1111 1101	ILLEGAL
1022	11 1111 1110	ILLEGAL
1023	11 1111 1111	ILLEGAL

The following table lists:

## Legal 10-Bit Values Sorted by 8-Bit Hex Code

10B Dec	8B Dec	ASCII+	HEX	Previous Disparity	Data Byte Name	FC	10 B	COMMENT
3950		NUL	00	RD +	D0.0		01 1000 1011	
628	0	NUL	00	RD--	D0.0		10 0111 0100	
468	1	SOH	01	RD--	D1.0		01 1101 0100	
555	1	SOH	01	RD +	D1.0		10 0010 1011	
299	2	STX	02	RD +	D2.0		01 0010 1011	
724	2	STX	02	RD--	D2.0		10 1101 0100	
788	3	ETX	03	RD +	D3.0		11 0001 0100	
795	3	ETX	03	RD--	D3.0		11 0001 1011	
171	4	EOT	04	RD +	D4.0		00 1010 1011	
852	4	EOT	04	RD--	D4.0		11 0101 0100	
660	5	ENQ	05	RD +	D5.0		10 1001 0100	
667	5	ENQ	05	RD--	D5.0		10 1001 1011	
404	6	ACK	06	RD +	D6.0		01 1001 0100	
411	6	ACK	06	RD--	D6.0		01 1001 1011	
116	7	BEL	07	RD +	D7.0		00 0111 0100	
907	7	BEL	07	RD--	D7.0		11 1000 1011	
107	8	BS	08	RD +	D8.0		00 0110 1011	
916	8	BS	08	RD--	D8.0		11 1001 0100	
596	9	HT	09	RD +	D9.0		10 0101 0100	
603	9	HT	09	RD--	D9.0		10 0101 1011	
436	16	DLE	10	RD--	D16.0		01 1011 0100	
587	16	DLE	10	RD +	D16.0		10 0100 1011	
564	17	DC1	11	RD +	D17.0		10 0011 0100	
571	17	DC1	11	RD--	D17.0		10 0011 1011	
308	18	DC2	12	RD +	D18.0		01 0011 0100	
315	18	DC2	12	RD--	D18.0		01 0011 1011	
804	19	DC3	13	RD +	D19.0		11 0010 0100	
811	19	DC3	13	RD--	D19.0		11 0010 1011	
180	20	DC4	14	RD +	D20.0		00 1011 0100	
187	20	DC4	14	RD--	D20.0		00 1011 1011	
676	21	NAK	15	RD +	D21.0		10 1010 0100	
683	21	NAK	15	RD--	D21.0		10 1010 1011	
420	22	SYN	16	RD +	D22.0		01 1010 0100	
427	22	SYN	16	RD--	D22.0		01 1010 1011	
91	23	ETB	17	RD +	D23.0		00 0101 1011	
932	23	ETB	17	RD--	D23.0		11 1010 0100	
203	24	CAN	18	RD +	D24.0		00 1100 1011	
820	24	CAN	18	RD--	D24.0		11 0011 0100	
612	25	EM	19	RD +	D25.0		10 0110 0100	
619	25	EM	19	RD--	D25.0		10 0110 1011	
393	32	SPACE	20	RD +	D0.1		01 1000 1001	
633	32	SPACE	20	RD--	D0.1		10 0111 1001	
473	33	!	21	RD--	D1.1		01 1101 1001	
553	33	!	21	RD +	D1.1		10 0010 1001	
297	34	"	22	RD +	D2.1		01 0010 1001	
729	34	"	22	RD--	D2.1		10 1101 1001	
793	35	#	23	RD+/-	D3.1		11 0001 1001	
169	36	\$	24	RD +	D4.1		00 1010 1001	
857	36	\$	24	RD--	D4.1		11 0101 1001	
665	37	%	25	RD+/-	D5.1		10 1001 1001	
							1001	
409	38	&	26	RD+/-	D6.1		01 1001 1001	
121	39	'	27	RD +	D7.1		00 0111 1001	
905	39	'	27	RD--	D7.1		11 1000 1001	
105	40	(	28	RD +	D8.1		00 0110 1001	
921	40	(	28	RD--	D8.1		11 1001 1001	
601	41	)	29	RD+/-	D9.1		10 0101 1001	
441	48	0	30	RD--	D16.1		01 1011 1001	
585	48	0	30	RD +	D16.1		10 0100 1001	
569	49	1	31	RD+/-	D17.1		10 0011 1001	
313	50	2	32	RD+/-	D18.1		01 0011 1001	
809	51	3	33	RD+/-	D19.1		11 0010 1001	
185	52	4	34	RD+/-	D20.1		00 1011 1001	
681	53	5	35	RD+/-	D21.1		10 1010 1001	
425	54	6	36	RD+/-	D22.1		01 1010 1001	
89	55	7	37	RD +	D23.1		00 0101 1001	
937	55	7	37	RD--	D23.1		11 1010 1001	
201	56	8	38	RD +	D24.1		00 1100 1001	
825	56	8	38	RD--	D24.1		11 0011 1001	
617	57	9	39	RD+/-	D25.1		10 0110 1001	
389	64	@	40	RD +	D0.2		01 1000 0101	
629	64	@	40	RD--	D0.2		10 0111 0101	
469	65	A	41	RD--	D1.2		01 1101 0101	
549	65	A	41	RD +	D1.2		10 0010 0101	
293	66	B	42	RD +	D2.2		01 0010 0101	
725	66	B	42	RD--	D2.2		10 1101 0101	
789	67	C	43	RD+/-	D3.2		11 0001 0101	
165	68	D	44	RD +	D4.2		00 1010 0101	
853	68	D	44	RD--	D4.2		11 0101 0101	
661	69	E	45	RD+/-	D5.2		10 1001 0101	
405	70	F	46	RD+/-	D6.2		01 1001 0101	
117	71	G	47	RD +	D7.2		00 0111 0101	
901	71	G	47	RD--	D7.2		11 1000 0101	
101	72	H	48	RD +	D8.2		00 0110 0101	
917	72	H	48	RD--	D8.2		11 1001 0101	
597	73	I	49	RD+/-	D9.2		10 0101 0101	
437	80	P	50	RD--	D16.2		01 1011 0101	
581	80	P	50	RD +	D16.2		10 0100 0101	
565	81	Q	51	RD+/-	D17.2		10 0011 0101	
309	82	R	52	RD+/-	D18.2		01 0011 0101	
805	83	S	53	RD+/-	D19.2		11 0010 0101	
181	84	T	54	RD+/-	D20.2		00 1011 0101	
677	85	U	55	RD+/-	D21.2		10 1010 0101	
421	86	V	56	RD+/-	D22.2		01 1010 0101	
85	87	W	57	RD +	D23.2		00 0101 0101	
933	87	W	57	RD--	D23.2		11 1010 0101	
197	88	X	58	RD +	D24.2		00 1100 0101	
821	88	X	58	RD--	D24.2		11 0011 0101	
613	89	Y	59	RD+/-	D25.2		10 0110 0101	
396	96	`	60	RD +	D0.3		01 1000 1100	
627	96	`	60	RD--	D0.3		10 0111 0011	
467	97	a	61	RD--	D1.3		01 1101 0011	
556	97	a	61	RD +	D1.3		10 0010 1100	
300	98	b	62	RD +	D2.3		01 0010 1100	
723	98	b	62	RD--	D2.3		10 1101 0011	
787	99	c	63	RD +	D3.3		11 0001 0011	
796	99	c	63	RD--	D3.3		11 0001 1100	
172	100	d	64	RD +	D4.3		00 1010 1100	
851	100	d	64	RD--	D4.3		11 0101 0011	

## 8-Bit/10-Bit Mapping

659	101	e	65	RD +	D5.3	10 1001 0011	610	153	™	99	RD +	D25.4	10 0110 0010
668	101	e	65	RD--	D5.3	10 1001 1100	621	153	™	99	RD--	D25.4	10 0110 1101
403	102	f	66	RD +	D6.3	01 1001 0011	340	10	LF	0A	RD +	D10.0	01 0101 0100
412	102	f	66	RD--	D6.3	01 1001 1100	347	10	LF	0A	RD--	D10.0	01 0101 1011
115	103	g	67	RD +	D7.3	00 0111 0011	836	11	VT	0B	RD +	D11.0	11 0100 0100
908	103	g	67	RD--	D7.3	11 1000 1100	843	11	VT	0B	RD--	D11.0	11 0100 1011
108	104	h	68	RD +	D8.3	00 0110 1100	212	12	FF	0C	RD +	D12.0	00 1101 0100
915	104	h	68	RD--	D8.3	11 1001 0011	219	12	FF	0C	RD--	D12.0	00 1101 1011
595	105	i	69	RD +	D9.3	10 0101 0011	708	13	CR	0D	RD +	D13.0	10 1100 0100
604	105	i	69	RD--	D9.3	10 0101 1100	715	13	CR	0D	RD--	D13.0	10 1100 1011
435	112	p	70	RD--	D16.3	01 1011 0011	452	14	SO	0E	RD +	D14.0	01 1100 0100
588	112	p	70	RD +	D16.3	10 0100 1100	459	14	SO	0E	RD--	D14.0	01 1100 1011
563	113	q	71	RD +	D17.3	10 0011 0011	372	15	SI	0F	RD--	D15.0	01 0111 0100
572	113	q	71	RD--	D17.3	10 0011 1100	651	15	SI	0F	RD +	D15.0	10 1000 1011
307	114	r	72	RD +	D18.3	01 0011 0011	356	26	SUB	1A	RD +	D26.0	01 0110 0100
316	114	r	72	RD--	D18.3	01 0011 1100	363	26	SUB	1A	RD--	D26.0	01 0110 1011
803	115	s	73	RD +	D19.3	11 0010 0011	155	27	ESC	1B	RD +	D27.0	00 1001 1011
812	115	s	73	RD--	D19.3	11 0010 1100	868	27	ESC	1B	RD--	D27.0	11 0110 0100
179	116	t	74	RD +	D20.3	00 1011 0011	228	28	FS	1C	RD +	D28.0	00 1110 0100
188	116	t	74	RD--	D20.3	00 1011 1100	235	28	FS	1C	RD--	D28.0	00 1110 1011
675	117	u	75	RD +	D21.3	10 1010 0011	244	28	FS	1C	RD --	K28.0	00 1111 0100Reserved*
684	117	u	75	RD--	D21.3	10 1010 1100	779	28	FS	1C	RD +	K28.0	11 0000 1011
419	118	v	76	RD +	D22.3	01 1010 0011	283	29	GS	1D	RD +	D29.0	01 0001 1011
428	118	v	76	RD--	D22.3	01 1010 1100	740	29	GS	1D	RD--	D29.0	10 1110 0100
92	119	w	77	RD +	D23.3	00 0101 1100	484	30	RS	1E	RD--	D30.0	01 1110 0100
931	119	w	77	RD--	D23.3	11 1010 0011	539	30	RS	1E	RD +	D30.0	10 0001 1011
204	120	x	78	RD +	D24.3	00 1100 1100	331	31	US	1F	RD +	D31.0	01 0100 1011
819	120	x	78	RD--	D24.3	11 0011 0011	692	31	US	1F	RD--	D31.0	10 1011 0100
611	121	y	79	RD +	D25.3	10 0110 0011	345	42	*	2A	RD+/--	D10.1	01 0101 1001
620	121	y	79	RD--	D25.3	10 0110 1100	841	43	+	2B	RD+/--	D11.1	11 0100 1001
397	128	-	80	RD +	D0.4	01 1000 1101	217	44	,	2C	RD+/--	D12.1	00 1101 1001
626	128	-	80	RD--	D0.4	10 0111 0010	713	45	-	2D	RD+/--	D13.1	10 1100 1001
466	129	-	81	RD--	D1.4	01 1101 0010	457	46	.	2E	RD+/--	D14.1	01 1100 1001
557	129	-	81	RD +	D1.4	10 0010 1101	377	47	/	2F	RD--	D15.1	01 0111 1001
301	130	,	82	RD +	D2.4	01 0010 1101	649	47	/	2F	RD +	D15.1	10 1000 1001
722	130	,	82	RD--	D2.4	10 1101 0010	361	58	:	3A	RD+/--	D26.1	01 0110 1001
786	131	f	83	RD +	D3.4	11 0001 0010	153	59	;	3B	RD +	D27.1	00 1001 1001
797	131	f	83	RD--	D3.4	11 0001 1101	873	59	;	3B	RD--	D27.1	11 0110 1001
173	132	"	84	RD +	D4.4	00 1010 1101	233	60	<	3C	RD+/--	D28.1	00 1110 1001
850	132	"	84	RD--	D4.4	11 0101 0010	249	60	<	3C	RD --	K28.1	00 1111 1001Reserved*
658	133	...	85	RD +	D5.4	10 1001 0010	774	60	<	3C	RD +	K28.1	11 0000 0110
669	133	...	85	RD--	D5.4	10 1001 1101	281	61	=	3D	RD +	D29.1	01 0001 1001
402	134	†	86	RD +	D6.4	01 1001 0010	745	61	=	3D	RD--	D29.1	10 1110 1001
413	134	†	86	RD--	D6.4	01 1001 1101	489	62	>	3E	RD--	D30.1	01 1110 1001
114	135	‡	87	RD +	D7.4	00 0111 0010	537	62	>	3E	RD +	D30.1	10 0001 1001
909	135	‡	87	RD--	D7.4	11 1000 1101	329	63	?	3F	RD +	D31.1	01 0100 1001
109	136	~	88	RD +	D8.4	00 0110 1101	697	63	?	3F	RD--	D31.1	10 1011 1001
914	136	~	88	RD--	D8.4	11 1001 0010	341	74	J	4A	RD+/--	D10.2	01 0101 0101
594	137	‰	89	RD +	D9.4	10 0101 0010	837	75	K	4B	RD+/--	D11.2	11 0100 0101
605	137	‰	89	RD--	D9.4	10 0101 1101	213	76	L	4C	RD+/--	D12.2	00 1101 0101
434	144	-	90	RD--	D16.4	01 1011 0010	709	77	M	4D	RD+/--	D13.2	10 1100 0101
589	144	-	90	RD +	D16.4	10 0100 1101	453	78	N	4E	RD+/--	D14.2	01 1100 0101
562	145	'	91	RD +	D17.4	10 0011 0010	373	79	O	4F	RD--	D15.2	01 0111 0101
573	145	'	91	RD--	D17.4	10 0011 1101	645	79	O	4F	RD +	D15.2	10 1000 0101
306	146	,	92	RD +	D18.4	01 0011 0010	357	90	Z	5A	RD+/--	D26.2	01 0110 0101
317	146	,	92	RD--	D18.4	01 0011 1101	149	91	[	5B	RD +	D27.2	00 1001 0101
802	147	"	93	RD +	D19.4	11 0010 0010	869	91	[	5B	RD--	D27.2	11 0110 0101
813	147	"	93	RD--	D19.4	11 0010 1101	229	92	\	5C	RD+/--	D28.2	00 1110 0101
178	148	"	94	RD +	D20.4	00 1011 0010	245	92	\	5C	RD --	K28.2	00 1111 0101Reserved*
189	148	"	94	RD--	D20.4	00 1011 1101	778	92	\	5C	RD +	K28.2	11 0000 1010
674	149	•	95	RD +	D21.4	10 1010 0010	277	93	]	5D	RD +	D29.2	01 0001 0101
685	149	•	95	RD--	D21.4	10 1010 1101	741	93	]	5D	RD--	D29.2	10 1110 0101
418	150	-	96	RD +	D22.4	01 1010 0010	485	94	^	5E	RD--	D30.2	01 1110 0101
429	150	-	96	RD--	D22.4	01 1010 1101							
93	151	—	97	RD +	D23.4	00 0101 1101							
930	151	—	97	RD--	D23.4	11 1010 0010							
205	152	~	98	RD +	D24.4	00 1100 1101							
818	152	~	98	RD--	D24.4	11 0011 0010							

533	94	^	5E	RD +	D30.2	10 0001 0101	410	166	ı	A6	RD+/-	D6.5	01 1001 1010
325	95	_	5F	RD +	D31.2	01 0100 0101	122	167	§	A7	RD +	D7.5	00 0111 1010
693	95	_	5F	RD--	D31.2	10 1011 0101	906	167	§	A7	RD--	D7.5	11 1000 1010
339	106	j	6A	RD +	D10.3	01 0101 0011	106	168	~	A8	RD +	D8.5	00 0110 1010
348	106	j	6A	RD--	D10.3	01 0101 1100	922	168	~	A8	RD--	D8.5	11 1001 1010
835	107	k	6B	RD +	D11.3	11 0100 0011	602	169	©	A9	RD+/-	D9.5	10 0101 1010
844	107	k	6B	RD--	D11.3	11 0100 1100	346	170	<sup>a</sup>	AA	RD+/-	D10.5	01 0101 1010
211	108	l	6C	RD +	D12.3	00 1101 0011	842	171	«	AB	RD+/-	D11.5	11 0100 1010
220	108	l	6C	RD--	D12.3	00 1101 1100	218	172	¬	AC	RD+/-	D12.5	00 1101 1010
707	109	m	6D	RD +	D13.3	10 1100 0011	714	173	-	AD	RD+/-	D13.5	10 1100 1010
716	109	m	6D	RD--	D13.3	10 1100 1100	458	174	®	AE	RD+/-	D14.5	01 1100 1010
451	110	n	6E	RD +	D14.3	01 1100 0011	378	175	-	AF	RD--	D15.5	01 0111 1010
460	110	n	6E	RD--	D14.3	01 1100 1100	650	175	-	AF	RD +	D15.5	10 1000 1010
371	111	o	6F	RD--	D15.3	01 0111 0011	442	176	°	B0	RD--	D16.5	01 1011 1010
652	111	o	6F	RD +	D15.3	10 1000 1100	586	176	°	B0	RD +	D16.5	10 0100 1010
355	122	z	7A	RD +	D26.3	01 0110 0011	570	177	±	B1	RD+/-	D17.5	10 0011 1010
364	122	z	7A	RD--	D26.3	01 0110 1100	314	178	<sup>z</sup>	B2	RD+/-	D18.5	01 0011 1010
156	123	{	7B	RD +	D27.3	00 1001 1100	810	179	<sup>3</sup>	B3	RD+/-	D19.5	11 0010 1010
867	123	{	7B	RD--	D27.3	11 0110 0011	186	180	'	B4	RD+/-	D20.5	00 1011 1010
227	124		7C	RD +	D28.3	00 1110 0011	682	181	μ	B5	RD+/-	D21.5	10 1010 1010
236	124		7C	RD--	D28.3	00 1110 1100	426	182	¶	B6	RD+/-	D22.5	01 1010 1010
243	124		7C	RD --	K28.3	00 1111 0011 Reserved*	90	183	·	B7	RD +	D23.5	00 0101 1010
780	124		7C	RD +	K28.3	11 0000 1100	938	183	·	B7	RD--	D23.5	11 1010 1010
284	125	}	7D	RD +	D29.3	01 0001 1100	202	184	,	B8	RD +	D24.5	00 1100 1010
739	125	}	7D	RD--	D29.3	10 1110 0011	826	184	,	B8	RD--	D24.5	11 0011 1010
483	126	~	7E	RD--	D30.3	01 1110 0011	618	185	<sup>1</sup>	B9	RD+/-	D25.5	10 0110 1010
540	126	~	7E	RD +	D30.3	10 0001 1100	362	186	°	BA	RD+/-	D26.5	01 0110 1010
332	127	DELETE	7F	RD +	D31.3	01 0100 1100	154	187	»	BB	RD +	D27.5	00 1001 1010
691	127	DELETE	7F	RD--	D31.3	10 1011 0011	874	187	»	BB	RD--	D27.5	11 0110 1010
338	138	Š	8A	RD +	D10.4	01 0101 0010	234	188	<sup>¼</sup>	BC	RD+/-	D28.5	00 1110 1010
349	138	Š	8A	RD--	D10.4	01 0101 1101	250	188	<sup>¼</sup>	BC	RD --	K28.5	00 1111 1010 Sync
834	139	‘	8B	RD +	D11.4	11 0100 0010	773	188	<sup>¼</sup>	BC	RD +	K28.5	11 0000 0101 (Not Used)
845	139	‘	8B	RD--	D11.4	11 0100 1101	282	189	<sup>½</sup>	BD	RD +	D29.5	01 0001 1010
210	140	Œ	8C	RD +	D12.4	00 1101 0010	746	189	<sup>½</sup>	BD	RD--	D29.5	10 1110 1010
221	140	Œ	8C	RD--	D12.4	00 1101 1101	490	190	<sup>¾</sup>	BE	RD--	D30.5	01 1110 1010
706	141	-	8D	RD +	D13.4	10 1100 0010	538	190	<sup>¾</sup>	BE	RD +	D30.5	10 0001 1010
717	141	-	8D	RD--	D13.4	10 1100 1101	330	191	ı	BF	RD +	D31.5	01 0100 1010
450	142	-	8E	RD +	D14.4	01 1100 0010	698	191	ı	BF	RD--	D31.5	10 1011 1010
461	142	-	8E	RD--	D14.4	01 1100 1101	390	192	À	C0	RD +	D0.6	01 1000 0110
370	143	-	8F	RD--	D15.4	01 0111 0010	630	192	À	C0	RD--	D0.6	10 0111 0110
653	143	-	8F	RD +	D15.4	10 1000 1101	470	193	Á	C1	RD--	D1.6	01 1101 0110
354	154	š	9A	RD +	D26.4	01 0110 0010	550	193	Á	C1	RD +	D1.6	10 0010 0110
365	154	š	9A	RD--	D26.4	01 0110 1101	294	194	Â	C2	RD +	D2.6	01 0010 0110
157	155	›	9B	RD +	D27.4	00 1001 1101	726	194	Â	C2	RD--	D2.6	10 1101 0110
866	155	›	9B	RD--	D27.4	11 0110 0010	790	195	Ã	C3	RD+/-	D3.6	11 0001 0110
226	156	œ	9C	RD +	D28.4	00 1110 0010	166	196	Ä	C4	RD +	D4.6	00 1010 0110
237	156	œ	9C	RD--	D28.4	00 1110 1101	854	196	Ä	C4	RD--	D4.6	11 0101 0110
242	156	œ	9C	RD --	K28.4	00 1111 0010 Reserved*	662	197	Å	C5	RD+/-	D5.6	10 1001 0110
781	156	œ	9C	RD +	K28.4	11 0000 1101	406	198	Æ	C6	RD+/-	D6.6	01 1001 0110
285	157	-	9D	RD +	D29.4	01 0001 1101	118	199	Ç	C7	RD +	D7.6	00 0111 0110
738	157	-	9D	RD--	D29.4	10 1110 0010	902	199	Ç	C7	RD--	D7.6	11 1000 0110
482	158	-	9E	RD--	D30.4	01 1110 0010	102	200	È	C8	RD +	D8.6	00 0110 0110
541	158	-	9E	RD +	D30.4	10 0001 1101	918	200	È	C8	RD--	D8.6	11 1001 0110
333	159	ÿ	9F	RD +	D31.4	01 0100 1101	598	201	É	C9	RD+/-	D9.6	10 0101 0110
690	159	ÿ	9F	RD--	D31.4	10 1011 0010	342	202	Ê	CA	RD+/-	D10.6	01 0101 0110
394	160		A0	RD +	D0.5	01 1000 1010	838	203	Ë	CB	RD+/-	D11.6	01 0100 0110
634	160		A0	RD--	D0.5	10 0111 1010	214	204	Ì	CC	RD+/-	D12.6	00 1101 0110
474	161	i	A1	RD--	D1.5	01 1101 1010	710	205	Í	CD	RD+/-	D13.6	10 1100 0110
554	161	i	A1	RD +	D1.5	10 0010 1010	454	206	Î	CE	RD+/-	D14.6	01 1100 0110
298	162	ç	A2	RD +	D2.5	01 0010 1010	374	207	Ï	CF	RD--	D15.6	01 0111 0110
730	162	ç	A2	RD--	D2.5	10 1101 1010	646	207	Ï	CF	RD +	D15.6	10 1000 0110
794	163	£	A3	RD+/-	D3.5	11 0001 1010	438	208	Ð	D0	RD--	D16.6	01 1011 0110
170	164	¤	A4	RD +	D4.5	00 1010 1010	582	208	Ð	D0	RD +	D16.6	10 0100 0110
858	164	¤	A4	RD--	D4.5	11 0101 1010							
666	165	¥	A5	RD+/-	D5.5	10 1001 1010							

## 8-Bit/10-Bit Mapping

566	209	Ñ	D1	RD+/-	D17.6	10 0011 0110	430	246	ö	F6	RD--	D22.7	01 1010 1110
310	210	Ò	D2	RD+/-	D18.6	01 0011 0110	87	247	÷	F7	RD +	K23.7	00 0101 0111
806	211	Ó	D3	RD+/-	D19.6	11 0010 0110	94	247	÷	F7	RD +	D23.7	00 0101 1110
182	212	Ô	D4	RD+/-	D20.6	00 1011 0110	929	247	÷	F7	RD--	D23.7	11 1010 0001
678	213	Õ	D5	RD+/-	D21.6	10 1010 0110	936	247	÷	F7	RD --	K23.7	11 1010 1000Reserved*
422	214	Ö	D6	RD+/-	D22.6	01 1010 0110	206	248	ø	F8	RD +	D24.7	00 1100 1110
86	215	×	D7	RD +	D23.6	00 0101 0110	817	248	ø	F8	RD--	D24.7	11 0011 0001
934	215	×	D7	RD--	D23.6	11 1010 0110	609	249	ù	F9	RD +	D25.7	10 0110 0001
198	216	Ø	D8	RD +	D24.6	00 1100 0110	622	249	ù	F9	RD--	D25.7	10 0110 1110
822	216	Ø	D8	RD--	D24.6	11 0011 0110	353	250	ú	FA	RD +	D26.7	01 0110 0001
614	217	Ù	D9	RD+/-	D25.6	10 0110 0110	366	250	ú	FA	RD--	D26.7	01 0110 1110
358	218	Ú	DA	RD+/-	D26.6	01 0110 0110	151	251	û	FB	RD +	K27.7	00 1001 0111
150	219	Û	DB	RD +	D27.6	00 1001 0110	158	251	û	FB	RD +	D27.7	00 1001 1110
870	219	Û	DB	RD--	D27.6	11 0110 0110	865	251	û	FB	RD--	D27.7	11 0110 0001
230	220	Ü	DC	RD+/-	D28.6	00 1110 0110	872	251	û	FB	RD --	K27.7	11 0110 1000Reserved*
246	220	Û	DC	RD --	K28.6	00 1111 0110Reserved*	225	252	ü	FC	RD +	D28.7	00 1110 0001
777	220	Û	DC	RD +	K28.6	11 0000 1001	238	252	ü	FC	RD--	D28.7	00 1110 1110
278	221	Ý	DD	RD +	D29.6	01 0001 0110	248	252	ü	FC	RD --	K28.7	00 1111 1000Test
742	221	Ý	DD	RD--	D29.6	10 1110 0110	775	252	ü	FC	RD +	K28.7	11 0000 0111
486	222	Þ	DE	RD--	D30.6	01 1110 0110	279	253	ý	FD	RD +	K29.7	01 0001 0111
534	222	Þ	DE	RD +	D30.6	10 0001 0110	286	253	ý	FD	RD +	D29.7	01 0001 1110
326	223	Ë	DF	RD +	D31.6	01 0100 0110	737	253	ý	FD	RD--	D29.7	10 1110 0001
694	223	Ë	DF	RD--	D31.6	10 1011 0110	744	253	ý	FD	RD --	K29.7	10 1110 1000Reserved*
398	224	à	E0	RD +	D0.7	01 1000 1110	481	254	þ	FE	RD--	D30.7	01 1110 0001
625	224	à	E0	RD--	D0.7	10 0111 0001	488	254	þ	FE	RD --	K30.7	01 1110 1000Reserved*
465	225	á	E1	RD--	D1.7	01 1101 0001	535	254	þ	FE	RD +	K30.7	10 0001 0111
558	225	á	E1	RD +	D1.7	10 0010 1110	542	254	þ	FE	RD +	D30.7	10 0001 1110
302	226	â	E2	RD +	D2.7	01 0010 1110	334	255	ÿ	FF	RD +	D31.7	01 0100 1110
721	226	â	E2	RD--	D2.7	10 1101 0001	689	255	ÿ	FF	RD--	D31.7	10 1011 0001
785	227	ã	E3	RD +	D3.7	11 0001 0001							
798	227	ã	E3	RD--	D3.7	11 0001 1110							
174	228	ä	E4	RD +	D4.7	00 1010 1110							
849	228	ä	E4	RD--	D4.7	11 0101 0001							
657	229	å	E5	RD +	D5.7	10 1001							
						0001							
670	229	å	E5	RD--	D5.7	10 1001 1110							
401	230	æ	E6	RD +	D6.7	01 1001							
						0001							
414	230	æ	E6	RD--	D6.7	01 1001 1110							
113	231	ç	E7	RD +	D7.7	00 0111 0001							
910	231	ç	E7	RD--	D7.7	11 1000 1110							
110	232	è	E8	RD +	D8.7	00 0110 1110							
913	232	è	E8	RD--	D8.7	11 1001 0001							
593	233	é	E9	RD +	D9.7	10 0101							
						0001							
606	233	é	E9	RD--	D9.7	10 0101 1110							
337	234	ê	EA	RD +	D10.7	01 0101							
						0001							
350	234	ê	EA	RD--	D10.7	01 0101 1110							
840	235	ë	EB	RD +	D11.7	11 0100 1000							
846	235	ë	EB	RD--	D11.7	11 0100 1110							
209	236	ì	EC	RD +	D12.7	00 1101 0001							
222	236	ì	EC	RD--	D12.7	00 1101 1110							
712	237	í	ED	RD +	D13.7	10 1100 1000							
718	237	í	ED	RD--	D13.7	10 1100 1110							
456	238	î	EE	RD +	D14.7	01 1100 1000							
462	238	î	EE	RD--	D14.7	01 1100 1110							
369	239	ï	EF	RD--	D15.7	01 0111 0001							
654	239	ï	EF	RD +	D15.7	10 1000 1110							
433	240	ð	F0	RD--	D16.7	01 1011 0001							
590	240	ð	F0	RD +	D16.7	10 0100 1110							
561	241	ñ	F1	RD +	D17.7	10 0011 0001							
567	241	ñ	F1	RD--	D17.7	10 0011 0111							
305	242	ò	F2	RD +	D18.7	01 0011 0001							
311	242	ò	F2	RD--	D18.7	01 0011 0111							
801	243	ó	F3	RD +	D19.7	11 0010 0001							
814	243	ó	F3	RD--	D19.7	11 0010 1110							
177	244	ô	F4	RD +	D20.7	00 1011 0001							
183	244	ô	F4	RD--	D20.7	00 1011 0111							
673	245	õ	F5	RD +	D21.7	10 1010							
						0001							
686	245	õ	F5	RD--	D21.7	10 1010 1110							
417	246	ö	F6	RD +	D22.7	01 1010							
						0001							

The following table lists:

## Legal 10-bit Values Sorted by K/D Code

10B Dec	8B Dec	ASCII+	HEX	Previous Disparity	Data Byte FC	10 B Name	COMMENT
395	0	NUL	00	RD+	D0.0	01 1000 1011	
628	0	NUL	00	RD--	D0.0	10 0111 0100	
393	32	SPACE	20	RD+	D0.1	01 1000 1001	
633	32	SPACE	20	RD--	D0.1	10 0111 1001	
389	64	@	40	RD+	D0.2	01 1000 0101	
629	64	@	40	RD--	D0.2	10 0111 0101	
396	96	`	60	RD+	D0.3	01 1000 1100	
627	96	`	60	RD--	D0.3	10 0111 0011	
397	128	_	80	RD+	D0.4	01 1000 1101	
626	128	_	80	RD--	D0.4	10 0111 0010	
394	160	A	A0	RD+	D0.5	01 1000 1010	
634	160	A	A0	RD--	D0.5	10 0111 1010	
390	192	À	C0	RD+	D0.6	01 1000 0110	
630	192	À	C0	RD--	D0.6	10 0111 0110	
398	224	à	E0	RD+	D0.7	01 1000 1110	
625	224	à	E0	RD--	D0.7	10 0111 0001	
468	1	SOH	01	RD--	D1.0	01 1101 0100	
555	1	SOH	01	RD+	D1.0	10 0010 1011	
473	33	!	21	RD--	D1.1	01 1101 1001	
553	33	!	21	RD+	D1.1	10 0010 1001	
469	65	A	41	RD--	D1.2	01 1101 0101	
549	65	A	41	RD+	D1.2	10 0010 0101	
467	97	a	61	RD--	D1.3	01 1101 0011	
556	97	a	61	RD+	D1.3	10 0010 1100	
466	129	_	81	RD--	D1.4	01 1101 0010	
557	129	_	81	RD+	D1.4	10 0010 1101	
474	161	i	A1	RD--	D1.5	01 1101 1010	
554	161	i	A1	RD+	D1.5	10 0010 1010	
470	193	Á	C1	RD--	D1.6	01 1101 0110	
550	193	Á	C1	RD+	D1.6	10 0010 0110	
465	225	á	E1	RD--	D1.7	01 1101 0001	
558	225	á	E1	RD+	D1.7	10 0010 1110	
340	10	LF	0A	RD+	D10.0	01 0101 0100	
347	10	LF	0A	RD--	D10.0	01 0101 1011	
345	42	*	2A	RD+/-	D10.1	01 0101 1001	
341	74	J	4A	RD+/-	D10.2	01 0101 0101	
339	106	j	6A	RD+	D10.3	01 0101 0011	
348	106	j	6A	RD--	D10.3	01 0101 1100	
338	138	Š	8A	RD+	D10.4	01 0101 0010	
349	138	Š	8A	RD--	D10.4	01 0101 1101	
346	170	ª	AA	RD+/-	D10.5	01 0101 1010	
342	202	Ê	CA	RD+/-	D10.6	01 0101 0110	
337	234	ê	EA	RD+	D10.7	01 0101 0001	
350	234	ê	EA	RD--	D10.7	01 0101 1110	
836	11	VT	0B	RD+	D11.0	11 0100 0100	
843	11	VT	0B	RD--	D11.0	11 0100 1011	
841	43	+	2B	RD+/-	D11.1	11 0100 1001	
837	75	K	4B	RD+/-	D11.2	11 0100 0101	
835	107	k	6B	RD+	D11.3	11 0100 0011	
844	107	k	6B	RD--	D11.3	11 0100 1100	
834	139	ƙ	8B	RD+	D11.4	11 0100 0010	
845	139	ƙ	8B	RD--	D11.4	11 0100 1101	
842	171	«	AB	RD+/-	D11.5	11 0100 1010	
838	203	Ë	CB	RD+/-	D11.6	11 0100 0110	
840	235	ë	EB	RD+	D11.7	11 0100 1000	
846	235	ë	EB	RD--	D11.7	11 0100 1110	
212	12	FF	0C	RD+	D12.0	00 1101 0100	
219	12	FF	0C	RD--	D12.0	00 1101 1011	

217	44	,	2C	RD+/-	D12.1	00 1101 1001	
213	76	L	4C	RD+/-	D12.2	00 1101 0101	
211	108	l	6C	RD+	D12.3	00 1101 0011	
220	108	l	6C	RD--	D12.3	00 1101 1100	
210	140	œ	8C	RD+	D12.4	00 1101 0010	
221	140	œ	8C	RD--	D12.4	00 1101 1101	
218	172	ŕ	AC	RD+/-	D12.5	00 1101 1010	
214	204	ì	CC	RD+/-	D12.6	00 1101 0110	
209	236	ì	EC	RD+	D12.7	00 1101 0001	
222	236	ì	EC	RD--	D12.7	00 1101 1110	
708	13	CR	0D	RD+	D13.0	10 1100 0100	
715	13	CR	0D	RD--	D13.0	10 1100 1011	
713	45	-	2D	RD+/-	D13.1	10 1100 1001	
709	77	M	4D	RD+/-	D13.2	10 1100 0101	
707	109	m	6D	RD+	D13.3	10 1100 0011	
716	109	m	6D	RD--	D13.3	10 1100 1100	
706	141	_	8D	RD+	D13.4	10 1100 0010	
717	141	_	8D	RD--	D13.4	10 1100 1101	
714	173	-	AD	RD+/-	D13.5	10 1100 1010	
710	205	í	CD	RD+/-	D13.6	10 1100 0110	
712	237	í	ED	RD+	D13.7	10 1100 1000	
718	237	í	ED	RD--	D13.7	10 1100 1110	
452	14	SO	0E	RD+	D14.0	01 1100 0100	
459	14	SO	0E	RD--	D14.0	01 1100 1011	
457	46	.	2E	RD+/-	D14.1	01 1100 1001	
453	78	N	4E	RD+/-	D14.2	01 1100 0101	
451	110	n	6E	RD+	D14.3	01 1100 0011	
460	110	n	6E	RD--	D14.3	01 1100 1100	
450	142	_	8E	RD+	D14.4	01 1100 0010	
461	142	_	8E	RD--	D14.4	01 1100 1101	
458	174	@	AE	RD+/-	D14.5	01 1100 1010	
454	206	î	CE	RD+/-	D14.6	01 1100 0110	
456	238	î	EE	RD+	D14.7	01 1100 1000	
462	238	î	EE	RD--	D14.7	01 1100 1110	
372	15	SI	0F	RD--	D15.0	01 0111 0100	
651	15	SI	0F	RD+	D15.0	10 1000 1011	
377	47	/	2F	RD--	D15.1	01 0111 1001	
649	47	/	2F	RD+	D15.1	10 1000 1001	
373	79	O	4F	RD--	D15.2	01 0111 0101	
645	79	O	4F	RD+	D15.2	10 1000 0101	
371	111	o	6F	RD--	D15.3	01 0111 0011	
652	111	o	6F	RD+	D15.3	10 1000 1100	
370	143	_	8F	RD--	D15.4	01 0111 0010	
653	143	_	8F	RD+	D15.4	10 1000 1101	
378	175	-	AF	RD--	D15.5	01 0111 1010	
650	175	-	AF	RD+	D15.5	10 1000 1010	
374	207	ï	CF	RD--	D15.6	01 0111 0110	
646	207	ï	CF	RD+	D15.6	10 1000 0110	
369	239	ï	EF	RD--	D15.7	01 0111 0001	
654	239	ï	EF	RD+	D15.7	10 1000 1110	
436	16	DLE	10	RD--	D16.0	01 1011 0100	
587	16	DLE	10	RD+	D16.0	10 0100 1011	
441	48	o	30	RD--	D16.1	01 1011 1001	
585	48	o	30	RD+	D16.1	10 0100 1001	
437	80	P	50	RD--	D16.2	01 1011 0101	
581	80	P	50	RD+	D16.2	10 0100 0101	
435	112	p	70	RD--	D16.3	01 1011 0011	
588	112	p	70	RD+	D16.3	10 0100 1100	
434	144	_	90	RD--	D16.4	01 1011 0010	
589	144	_	90	RD+	D16.4	10 0100 1101	
442	176	°	B0	RD--	D16.5	01 1011 1010	
586	176	°	B0	RD+	D16.5	10 0100 1010	
438	208	Ð	D0	RD--	D16.6	01 1011 0110	
582	208	Ð	D0	RD+	D16.6	10 0100 0110	
433	240	ð	F0	RD--	D16.7	01 1011 0001	
590	240	ð	F0	RD+	D16.7	10 0100 1110	
564	17	DC1	11	RD+	D17.0	10 0011 0100	
571	17	DC1	11	RD--	D17.0	10 0011 1011	
569	49	1	31	RD+/-	D17.1	10 0011 1001	
565	81	Q	51	RD+/-	D17.2	10 0011 0101	
563	113	q	71	RD+	D17.3	10 0011 0011	
572	113	q	71	RD--	D17.3	10 0011 1100	
562	145	'	91	RD+	D17.4	10 0011 0010	

## 8-Bit/10-Bit Mapping

573	145	'	91	RD--	D17.4	10 0011 1101	419	118	v	76	RD +	D22.3	01 1010 0011
570	177	±	B1	RD+/-	D17.5	10 0011 1010	428	118	v	76	RD--	D22.3	01 1010 1100
566	209	Ñ	D1	RD+/-	D17.6	10 0011 0110	418	150	-	96	RD +	D22.4	01 1010 0010
561	241	ñ	F1	RD +	D17.7	10 0011 0001	429	150	-	96	RD--	D22.4	01 1010 1101
567	241	ñ	F1	RD--	D17.7	10 0011 0111	426	182	¶	B6	RD+/-	D22.5	01 1010 1010
308	18	DC2	12	RD +	D18.0	01 0011 0100	422	214	Ö	D6	RD+/-	D22.6	01 1010 0110
315	18	DC2	12	RD--	D18.0	01 0011 1011	417	246	ö	F6	RD +	D22.7	01 1010 0001
313	50	2	32	RD+/-	D18.1	01 0011 1001	430	246	ö	F6	RD--	D22.7	01 1010 1110
309	82	R	52	RD+/-	D18.2	01 0011 0101	91	23	ETB	17	RD +	D23.0	00 0101 1011
307	114	r	72	RD +	D18.3	01 0011 0011	932	23	ETB	17	RD--	D23.0	11 1010 0100
316	114	r	72	RD--	D18.3	01 0011 1100	89	55	7	37	RD +	D23.1	00 0101 1001
306	146	'	92	RD +	D18.4	01 0011 0010	937	55	7	37	RD--	D23.1	11 1010 1001
317	146	'	92	RD--	D18.4	01 0011 1101	85	87	W	57	RD +	D23.2	00 0101 0101
314	178	²	B2	RD+/-	D18.5	01 0011 1010	933	87	W	57	RD--	D23.2	11 1010 0101
310	210	Ò	D2	RD+/-	D18.6	01 0011 0110	92	119	w	77	RD +	D23.3	00 0101 1100
305	242	ò	F2	RD +	D18.7	01 0011 0001	931	119	w	77	RD--	D23.3	11 1010 0011
311	242	ò	F2	RD--	D18.7	01 0011 0111	93	151	—	97	RD +	D23.4	00 0101 1101
804	19	DC3	13	RD +	D19.0	11 0010 0100	930	151	—	97	RD--	D23.4	11 1010 0010
811	19	DC3	13	RD--	D19.0	11 0010 1011	90	183	·	B7	RD +	D23.5	00 0101 1010
809	51	3	33	RD+/-	D19.1	11 0010 1001	938	183	·	B7	RD--	D23.5	11 1010 1010
805	83	S	53	RD+/-	D19.2	11 0010 0101	86	215	x	D7	RD +	D23.6	00 0101 0110
803	115	s	73	RD +	D19.3	11 0010 0011	934	215	x	D7	RD--	D23.6	11 1010 0110
812	115	s	73	RD--	D19.3	11 0010 1100	94	247	÷	F7	RD +	D23.7	00 0101 1110
802	147	"	93	RD +	D19.4	11 0010 0010	929	247	÷	F7	RD--	D23.7	11 1010 0001
813	147	"	93	RD--	D19.4	11 0010 1101	203	24	CAN	18	RD +	D24.0	00 1100 1011
810	179	³	B3	RD+/-	D19.5	11 0010 1010	820	24	CAN	18	RD--	D24.0	11 0011 0100
806	211	Ó	D3	RD+/-	D19.6	11 0010 0110	201	56	8	38	RD +	D24.1	00 1100 1001
801	243	ó	F3	RD +	D19.7	11 0010 0001	825	56	8	38	RD--	D24.1	11 0011 1001
814	243	ó	F3	RD--	D19.7	11 0010 1110	197	88	X	58	RD +	D24.2	00 1100 0101
299	2	STX	02	RD +	D2.0	01 0010 1011	821	88	X	58	RD--	D24.2	11 0011 0101
724	2	STX	02	RD--	D2.0	10 1101 0100	204	120	x	78	RD +	D24.3	00 1100 1100
297	34	"	22	RD +	D2.1	01 0010 1001	819	120	x	78	RD--	D24.3	11 0011 0011
729	34	"	22	RD--	D2.1	10 1101 1001	205	152	~	98	RD +	D24.4	00 1100 1101
293	66	B	42	RD +	D2.2	01 0010 0101	818	152	~	98	RD--	D24.4	11 0011 0010
725	66	B	42	RD--	D2.2	10 1101 0101	202	184	,	B8	RD +	D24.5	00 1100 1010
300	98	b	62	RD +	D2.3	01 0010 1100	826	184	,	B8	RD--	D24.5	11 0011 1010
723	98	b	62	RD--	D2.3	10 1101 0011	198	216	Ø	D8	RD +	D24.6	00 1100 0110
301	130	,	82	RD +	D2.4	01 0010 1101	822	216	Ø	D8	RD--	D24.6	11 0011 0110
722	130	,	82	RD--	D2.4	10 1101 0010	206	248	ø	F8	RD +	D24.7	00 1100 1110
298	162	¢	A2	RD +	D2.5	01 0010 1010	817	248	ø	F8	RD--	D24.7	11 0011 0001
730	162	¢	A2	RD--	D2.5	10 1101 1010	612	25	EM	19	RD +	D25.0	10 0110 0100
294	194	Â	C2	RD +	D2.6	01 0010 0110	619	25	EM	19	RD--	D25.0	10 0110 1011
726	194	Â	C2	RD--	D2.6	10 1101 0110	617	57	9	39	RD+/-	D25.1	10 0110 1001
302	226	â	E2	RD +	D2.7	01 0010 1110	613	89	Y	59	RD+/-	D25.2	10 0110 0101
721	226	â	E2	RD--	D2.7	10 1101 0001	611	121	y	79	RD +	D25.3	10 0110 0011
180	20	DC4	14	RD +	D20.0	00 1011 0100	620	121	y	79	RD--	D25.3	10 0110 1100
187	20	DC4	14	RD--	D20.0	00 1011 1011	610	153	™	99	RD +	D25.4	10 0110 0010
185	52	4	34	RD+/-	D20.1	00 1011 1001	621	153	™	99	RD--	D25.4	10 0110 1101
181	84	T	54	RD+/-	D20.2	00 1011 0101	618	185	ı	B9	RD+/-	D25.5	10 0110 1010
179	116	t	74	RD +	D20.3	00 1011 0011	614	217	Û	D9	RD+/-	D25.6	10 0110 0110
188	116	t	74	RD--	D20.3	00 1011 1100	609	249	ü	F9	RD +	D25.7	10 0110 0001
178	148	"	94	RD +	D20.4	00 1011 0010	622	249	ü	F9	RD--	D25.7	10 0110 1110
189	148	"	94	RD--	D20.4	00 1011 1101	356	26	SUB	1A	RD +	D26.0	01 0110 0100
186	180	'	B4	RD+/-	D20.5	00 1011 1010	363	26	SUB	1A	RD--	D26.0	01 0110 1011
182	212	Ô	D4	RD+/-	D20.6	00 1011 0110	361	58	:	3A	RD+/-	D26.1	01 0110 1001
177	244	ô	F4	RD +	D20.7	00 1011 0001	357	90	Z	5A	RD+/-	D26.2	01 0110 0101
183	244	ô	F4	RD--	D20.7	00 1011 0111	355	122	z	7A	RD +	D26.3	01 0110 0011
676	21	NAK	15	RD +	D21.0	10 1010 0100	364	122	z	7A	RD--	D26.3	01 0110 1100
683	21	NAK	15	RD--	D21.0	10 1010 1011	354	154	š	9A	RD +	D26.4	01 0110 0010
681	53	5	35	RD+/-	D21.1	10 1010 1001	365	154	š	9A	RD--	D26.4	01 0110 1101
677	85	U	55	RD+/-	D21.2	10 1010 0101	362	186	°	BA	RD+/-	D26.5	01 0110 1010
675	117	u	75	RD +	D21.3	10 1010 0011	358	218	Û	DA	RD+/-	D26.6	01 0110 0110
684	117	u	75	RD--	D21.3	10 1010 1100	353	250	ú	FA	RD +	D26.7	01 0110 0001
674	149	•	95	RD +	D21.4	10 1010 0010	366	250	ú	FA	RD--	D26.7	01 0110 1110
685	149	•	95	RD--	D21.4	10 1010 1101	155	27	ESC	1B	RD +	D27.0	00 1001 1011
682	181	µ	B5	RD+/-	D21.5	10 1010 1010	868	27	ESC	1B	RD--	D27.0	11 0110 0100
678	213	Õ	D5	RD+/-	D21.6	10 1010 0110	153	59	;	3B	RD +	D27.1	00 1001 1001
673	245	õ	F5	RD +	D21.7	10 1010 0001	873	59	;	3B	RD--	D27.1	11 0110 1001
686	245	õ	F5	RD--	D21.7	10 1010 1110	149	91	[	5B	RD +	D27.2	00 1001 0101
420	22	SYN	16	RD +	D22.0	01 1010 0100	869	91	[	5B	RD--	D27.2	11 0110 0101
427	22	SYN	16	RD--	D22.0	01 1010 1011	156	123	{	7B	RD +	D27.3	00 1001 1100
425	54	6	36	RD+/-	D22.1	01 1010 1001	867	123	{	7B	RD--	D27.3	11 0110 0011
421	86	V	56	RD+/-	D22.2	01 1010 0101	157	155	›	9B	RD +	D27.4	00 1001 1101

866	155	›	9B	RD--	D27.4	11	0110	0010	330	191	¿	BF	RD +	D31.5	01	0100	1010
154	187	»	BB	RD +	D27.5	00	1001	1010	698	191	¿	BF	RD--	D31.5	10	1011	1010
874	187	»	BB	RD--	D27.5	11	0110	1010	326	223	ß	DF	RD +	D31.6	01	0100	0110
150	219	Û	DB	RD +	D27.6	00	1001	0110	694	223	ß	DF	RD--	D31.6	10	1011	0110
870	219	Û	DB	RD--	D27.6	11	0110	0110	334	255	ÿ	FF	RD +	D31.7	01	0100	1110
158	251	û	FB	RD +	D27.7	00	1001	1110	689	255	ÿ	FF	RD--	D31.7	10	1011	0001
865	251	û	FB	RD--	D27.7	11	0110	0001	171	4	EOT	04	RD +	D4.0	00	1010	1011
228	28	FS	1C	RD +	D28.0	00	1110	0100	852	4	EOT	04	RD--	D4.0	11	0101	0100
235	28	FS	1C	RD--	D28.0	00	1110	1011	169	36	\$	24	RD +	D4.1	00	1010	1001
233	60	<	3C	RD+/-	D28.1	00	1110	1001	857	36	\$	24	RD--	D4.1	11	0101	1001
229	92	\	5C	RD+/-	D28.2	00	1110	0101	165	68	D	44	RD +	D4.2	00	1010	0101
227	124		7C	RD +	D28.3	00	1110	0011	853	68	D	44	RD--	D4.2	11	0101	0101
236	124		7C	RD--	D28.3	00	1110	1100	172	100	d	64	RD +	D4.3	00	1010	1100
226	156	œ	9C	RD +	D28.4	00	1110	0010	851	100	d	64	RD--	D4.3	11	0101	0011
237	156	œ	9C	RD--	D28.4	00	1110	1101	173	132	„	84	RD +	D4.4	00	1010	1101
234	188	¼	BC	RD+/-	D28.5	00	1110	1010	850	132	„	84	RD--	D4.4	11	0101	0010
230	220	Û	DC	RD+/-	D28.6	00	1110	0110	170	164	¤	A4	RD +	D4.5	00	1010	1010
225	252	ü	FC	RD +	D28.7	00	1110	0001	858	164	¤	A4	RD--	D4.5	11	0101	1010
238	252	ü	FC	RD--	D28.7	00	1110	1110	166	196	Ä	C4	RD +	D4.6	00	1010	0110
283	29	GS	1D	RD +	D29.0	01	0001	1011	854	196	Ä	C4	RD--	D4.6	11	0101	0110
740	29	GS	1D	RD--	D29.0	10	1110	0100	174	228	ä	E4	RD +	D4.7	00	1010	1110
281	61	=	3D	RD +	D29.1	01	0001	1001	849	228	ä	E4	RD--	D4.7	11	0101	0001
745	61	=	3D	RD--	D29.1	10	1110	1001	660	5	ENQ	05	RD +	D5.0	10	1001	0100
277	93	]	5D	RD +	D29.2	01	0001	0101	667	5	ENQ	05	RD--	D5.0	10	1001	1011
741	93	]	5D	RD--	D29.2	10	1110	0101	665	37	%	25	RD+/-	D5.1	10	1001	1001
284	125	}	7D	RD +	D29.3	01	0001	1100	661	69	E	45	RD+/-	D5.2	10	1001	0101
739	125	}	7D	RD--	D29.3	10	1110	0011	659	101	e	65	RD +	D5.3	10	1001	0011
285	157	_	9D	RD +	D29.4	01	0001	1101	668	101	e	65	RD--	D5.3	10	1001	1100
738	157	_	9D	RD--	D29.4	10	1110	0010	658	133	...	85	RD +	D5.4	10	1001	0010
282	189	½	BD	RD +	D29.5	01	0001	1010	669	133	...	85	RD--	D5.4	10	1001	1101
746	189	½	BD	RD--	D29.5	10	1110	1010	666	165	¥	A5	RD+/-	D5.5	10	1001	1010
278	221	Ý	DD	RD +	D29.6	01	0001	0110	662	197	À	C5	RD+/-	D5.6	10	1001	0110
742	221	Ý	DD	RD--	D29.6	10	1110	0110	657	229	à	E5	RD +	D5.7	10	1001	0001
286	253	ý	FD	RD +	D29.7	01	0001	1110	670	229	à	E5	RD--	D5.7	10	1001	1110
737	253	ý	FD	RD--	D29.7	10	1110	0001	404	6	ACK	06	RD +	D6.0	01	1001	0100
788	3	ETX	03	RD +	D3.0	11	0001	0100	411	6	ACK	06	RD--	D6.0	01	1001	1011
795	3	ETX	03	RD--	D3.0	11	0001	1011	409	38	&	26	RD+/-	D6.1	01	1001	1001
793	35	#	23	RD+/-	D3.1	11	0001	1001	405	70	F	46	RD+/-	D6.2	01	1001	0101
789	67	C	43	RD+/-	D3.2	11	0001	0101	403	102	f	66	RD +	D6.3	01	1001	0011
787	99	c	63	RD +	D3.3	11	0001	0011	412	102	f	66	RD--	D6.3	01	1001	1100
796	99	c	63	RD--	D3.3	11	0001	1100	402	134	†	86	RD +	D6.4	01	1001	0010
786	131	f	83	RD +	D3.4	11	0001	0010	413	134	†	86	RD--	D6.4	01	1001	1101
797	131	f	83	RD--	D3.4	11	0001	1101	410	166	‡	A6	RD+/-	D6.5	01	1001	1010
794	163	£	A3	RD+/-	D3.5	11	0001	1010	406	198	Æ	C6	RD+/-	D6.6	01	1001	0110
790	195	Å	C3	RD+/-	D3.6	11	0001	0110	401	230	æ	E6	RD +	D6.7	01	1001	0001
785	227	ā	E3	RD +	D3.7	11	0001	0001	414	230	æ	E6	RD--	D6.7	01	1001	1110
798	227	ā	E3	RD--	D3.7	11	0001	1110	116	7	BEL	07	RD +	D7.0	00	0111	0100
484	30	RS	1E	RD--	D30.0	01	1110	0100	907	7	BEL	07	RD--	D7.0	11	1000	1011
539	30	RS	1E	RD +	D30.0	10	0001	1011	121	39	'	27	RD +	D7.1	00	0111	1001
489	62	>	3E	RD--	D30.1	01	1110	1001	905	39	'	27	RD--	D7.1	11	1000	1001
537	62	>	3E	RD +	D30.1	10	0001	1001	117	71	G	47	RD +	D7.2	00	0111	0101
485	94	^	5E	RD--	D30.2	01	1110	0101	901	71	G	47	RD--	D7.2	11	1000	0101
533	94	^	5E	RD +	D30.2	10	0001	0101	115	103	g	67	RD +	D7.3	00	0111	0011
483	126	~	7E	RD--	D30.3	01	1110	0011	908	103	g	67	RD--	D7.3	11	1000	1100
540	126	~	7E	RD +	D30.3	10	0001	1100	114	135	‡	87	RD +	D7.4	00	0111	0010
482	158	_	9E	RD--	D30.4	01	1110	0010	909	135	‡	87	RD--	D7.4	11	1000	1101
541	158	_	9E	RD +	D30.4	10	0001	1101	122	167	§	A7	RD +	D7.5	00	0111	1010
490	190	¾	BE	RD--	D30.5	01	1110	1010	906	167	§	A7	RD--	D7.5	11	1000	1010
538	190	¾	BE	RD +	D30.5	10	0001	1010	118	199	Ç	C7	RD +	D7.6	00	0111	0110
486	222	þ	DE	RD--	D30.6	01	1110	0110	902	199	Ç	C7	RD--	D7.6	11	1000	0110
534	222	þ	DE	RD +	D30.6	10	0001	0110	113	231	ç	E7	RD +	D7.7	00	0111	0001
481	254	þ	FE	RD--	D30.7	01	1110	0001	910	231	ç	E7	RD--	D7.7	11	1000	1110
542	254	þ	FE	RD +	D30.7	10	0001	1110	107	8	BS	08	RD +	D8.0	00	0110	1011
331	31	US	1F	RD +	D31.0	01	0100	1011	916	8	BS	08	RD--	D8.0	11	1001	0100
692	31	US	1F	RD--	D31.0	10	1011	0100	105	40	(	28	RD +	D8.1	00	0110	1001
329	63	?	3F	RD +	D31.1	01	0100	1001	921	40	(	28	RD--	D8.1	11	1001	1001
697	63	?	3F	RD--	D31.1	10	1011	1001	101	72	H	48	RD +	D8.2	00	0110	0101
325	95	-	5F	RD +	D31.2	01	0100	0101	917	72	H	48	RD--	D8.2	11	1001	0101
693	95	-	5F	RD--	D31.2	10	1011	0101	108	104	h	68	RD +	D8.3	00	0110	1100
332	127	DELETE	7F	RD +	D31.3	01	0100	1100	915	104	h	68	RD--	D8.3	11	1001	0011
691	127	DELETE	7F	RD--	D31.3	10	1011	0011	109	136	^	88	RD +	D8.4	00	0110	1101
333	159	ÿ	9F	RD +	D31.4	01	0100	1101	914	136	^	88	RD--	D8.4	11	1001	0010
690	159	ÿ	9F	RD--	D31.4	10	1011	0010	106	168	˘	A8	RD +	D8.5	00	0110	1010

## 8-Bit/10-Bit Mapping

---

922	168	¨	A8	RD--	D8.5	11 1001 1010
102	200	È	C8	RD +	D8.6	00 0110 0110
918	200	È	C8	RD--	D8.6	11 1001 0110
110	232	è	E8	RD +	D8.7	00 0110 1110
913	232	è	E8	RD--	D8.7	11 1001 0001
596	9	HT	09	RD +	D9.0	10 0101 0100
603	9	HT	09	RD--	D9.0	10 0101 1011
601	41	)	29	RD+/-	D9.1	10 0101 1001
597	73	l	49	RD+/-	D9.2	10 0101 0101
595	105	i	69	RD +	D9.3	10 0101 0011
604	105	i	69	RD--	D9.3	10 0101 1100
594	137	% <sub>oo</sub>	89	RD +	D9.4	10 0101 0010
605	137	% <sub>oo</sub>	89	RD--	D9.4	10 0101 1101
602	169	©	A9	RD+/-	D9.5	10 0101 1010
598	201	É	C9	RD+/-	D9.6	10 0101 0110
593	233	é	E9	RD +	D9.7	10 0101 0001
606	233	é	E9	RD--	D9.7	10 0101 1110
87	247	÷	F7	RD +	K23.7	00 0101 0111
936	247	÷	F7	RD --	K23.7	11 1010 1000 Reserved*
151	251	û	FB	RD +	K27.7	00 1001 0111
872	251	û	FB	RD --	K27.7	11 0110 1000 Reserved*
244	28	FS	1C	RD --	K28.0	00 1111 0100 Reserved*
779	28	FS	1C	RD +	K28.0	11 0000 1011
249	60	<	3C	RD --	K28.1	00 1111 1001 Reserved*
774	60	<	3C	RD +	K28.1	11 0000 0110
245	92	\	5C	RD --	K28.2	00 1111 0101 Reserved*
778	92	\	5C	RD +	K28.2	11 0000 1010
243	124		7C	RD --	K28.3	00 1111 0011 Reserved*
780	124		7C	RD +	K28.3	11 0000 1100
242	156	œ	9C	RD --	K28.4	00 1111 0010 Reserved*
781	156	œ	9C	RD +	K28.4	11 0000 1101
250	188	¼	BC	RD --	K28.5	00 1111 1010 Sync
773	188	¼	BC	RD +	K28.5	11 0000 0101 (Not Used)
246	220	Û	DC	RD --	K28.6	00 1111 0110 Reserved*
777	220	Û	DC	RD +	K28.6	11 0000 1001
248	252	ü	FC	RD --	K28.7	00 1111 1000 Test
775	252	ü	FC	RD +	K28.7	11 0000 0111
279	253	ý	FD	RD +	K29.7	01 0001 0111
744	253	ý	FD	RD --	K29.7	10 1110 1000 Reserved*
488	254	þ	FE	RD --	K30.7	01 1110 1000 Reserved*
535	254	þ	FE	RD +	K30.7	10 0001 0111

# ***Appendix C***

## Fibre Channel Legal Arbitrated Loop Physical Addresses

This appendix contains legal (neutral disparity) arbitrated loop physical addresses (APLAs) sorted from highest (at the top) to the lowest (at the bottom) priority.

Fibre Channel Legal Arbitrated Loop Physical Addresses

Loop ID	ALPAA HEX	Name	RD -- Code	RD/+ Code	Previous Running Disparity RD+ Code
7E	00	D0.0	10 0111 0100		01 1000 1011
7D	01	D1.0	01 1101 0100		10 0010 1011
7C	02	D2.0	10 1101 0100		01 0010 1011
7B	04	D4.0	11 0101 0100		00 1010 1011
7A	08	D8.0	11 1001 0100		00 0110 1011
79	0F	D15.0	01 0111 0100		10 1000 1011
78	10	D16.0	01 1011 0100		10 0100 1011
77	17	D23.0	11 1010 0100		00 0101 1011
76	18	D24.0	11 0011 0100		00 1100 1011
75	1B	D27.0	11 0110 0100		00 1001 1011
74	1D	D29.0	10 1110 0100		01 0001 1011
73	1E	D30.0	01 1110 0100		10 0001 1011
72	1F	D31.0	10 1011 0100		01 0100 1011
71	23	D3.1		11 0001 1001	
70	25	D5.1		10 1001 1001	
6F	26	D6.1		01 1001 1001	
6E	27	D7.1	11 1000 1001		00 0111 1001
6D	29	D9.1		10 0101 1001	
6C	2A	D10.1		01 0101 1001	
6B	2B	D11.1		11 0100 1001	
6A	2C	D12.1		00 1101 1001	
69	2D	D13.1		10 1100 1001	
68	2E	D14.1		01 1100 1001	
67	31	D17.1		10 0011 1001	
66	32	D18.1		01 0011 1001	
65	33	D19.1		11 0010 1001	
64	34	D20.1		00 1011 1001	
63	35	D21.1		10 1010 1001	
62	36	D22.1		01 1010 1001	
61	39	D25.1		10 0110 1001	
60	3A	D26.1		01 0110 1001	
5F	3C	D28.1		00 1110 1001	
5E	43	D3.2		11 0001 0101	
5D	45	D5.2		10 1001 0101	
5C	46	D6.2		01 1001 0101	
5B	47	D7.2	11 1000 0101		00 0111 0101
5A	49	D9.2		10 0101 0101	
59	4A	D10.2		01 0101 0101	
58	4B	D11.2		11 0100 0101	
57	4C	D12.2		00 1101 0101	
56	4D	D13.2		10 1100 0101	
55	4E	D14.2		01 1100 0101	
54	51	D17.2		10 0011 0101	
53	52	D18.2		01 0011 0101	
52	53	D19.2		11 0010 0101	
51	54	D20.2		00 1011 0101	
50	55	D21.2		10 1010 0101	
4F	56	D22.2		01 1010 0101	
4E	59	D25.2		10 0110 0101	
4D	5A	D26.2		01 0110 0101	
4C	5C	D28.2		00 1110 0101	
4B	63	D3.3	11 0001 1100		11 0001 0011
4A	65	D5.3	10 1001 1100		10 1001 0011
49	66	D6.3	01 1001 1100		01 1001 0011
48	67	D7.3	11 1000 1100		00 0111 0011
47	69	D9.3	10 0101 1100		10 0101 0011
46	6A	D10.3	01 0101 1100		01 0101 0011
45	6B	D11.3	11 0100 1100		11 0100 0011
44	6C	D12.3	00 1101 1100		00 1101 0011
43	6D	D13.3	10 1100 1100		10 1100 0011
42	6E	D14.3	01 1100 1100		01 1100 0011
41	71	D17.3	10 0011 1100		10 0011 0011
40	72	D18.3	01 0011 1100		01 0011 0011
3F	73	D19.3	11 0010 1100		11 0010 0011
3E	74	D20.3	00 1011 1100		00 1011 0011
3D	75	D21.3	10 1010 1100		10 1010 0011
3C	76	D22.3	01 1010 1100		01 1010 0011

3B	79	D25.3	10 0110 1100		10 0110 0011
3A	7A	D26.3	01 0110 1100		01 0110 0011
39	7C	D28.3	00 1110 1100		00 1110 0011
38	80	D0.4	10 0111 0010		01 1000 1101
37	81	D1.4	01 1101 0010		10 0010 1101
36	82	D2.4	10 1101 0010		01 0010 1101
35	84	D4.4	11 0101 0010		00 1010 1101
34	88	D8.4	11 1001 0010		00 0110 1101
33	8F	D15.4	01 0111 0010		10 1000 1101
32	90	D16.4	01 1011 0010		10 0100 1101
31	97	D23.4	11 1010 0010		00 0101 1101
30	98	D24.4	11 0011 0010		00 1100 1101
2F	9B	D27.4	11 0110 0010		00 1001 1101
2E	9D	D29.4	10 1110 0010		01 0001 1101
2D	9E	D30.4	01 1110 0010		10 0001 1101
2C	9F	D31.4	10 1011 0010		01 0100 1101
2B	A3	D3.5		11 0001 1010	
2A	A5	D5.5		10 1001 1010	
29	A6	D6.5		01 1001 1010	
28	A7	D7.5	11 1000 1010		00 0111 1010
27	A9	D9.5		10 0101 1010	
26	AA	D10.5		01 0101 1010	
25	AB	D11.5		11 0100 1010	
24	AC	D12.5		00 1101 1010	
23	AD	D13.5		10 1100 1010	
22	AE	D14.5		01 1100 1010	
21	B1	D17.5		10 0011 1010	
20	B2	D18.5		01 0011 1010	
1F	B3	D19.5		11 0010 1010	
1E	B4	D20.5		00 1011 1010	
1D	B5	D21.5		10 1010 1010	
1C	B6	D22.5		01 1010 1010	
1B	B9	D25.5		10 0110 1010	
1A	BA	D26.5		01 0110 1010	
19	BC	D28.5		00 1110 1010	
18	C3	D3.6		11 0001 0110	
17	C5	D5.6		10 1001 0110	
16	C6	D6.6		01 1001 0110	
15	C7	D7.6	11 1000 0110		00 0111 0110
14	C9	D9.6		10 0101 0110	
13	CA	D10.6		01 0101 0110	
12	CB	D11.6		11 0100 0110	
11	CC	D12.6		00 1101 0110	
10	CD	D13.6		10 1100 0110	
0F	CE	D14.6		01 1100 0110	
0E	D1	D17.6		10 0011 0110	
0D	D2	D18.6		01 0011 0110	
0C	D3	D19.6		11 0010 0110	
0B	D4	D20.6		00 1011 0110	
0A	D5	D21.6		10 1010 0110	
09	D6	D22.6		01 1010 0110	
08	D9	D25.6		10 0110 0110	
07	DA	D26.6		01 0110 0110	
06	DC	D28.6		00 1110 0110	
05	E0	D0.7	10 0111 0001		01 1000 1110
04	E1	D1.7	01 1101 0001		10 0010 1110
03	E2	D2.7	10 1101 0001		01 0010 1110
02	E4	D4.7	11 0101 0001		00 1010 1110
01	E8	D8.7	11 1001 0001		00 0110 1110
00	EF	D15.7	01 0111 0001		10 1000 1110

# Appendix D

## Gigabit Ethernet Ordered Sets - Partial List

Gigabit Ethernet defines certain combinations of characters called Ordered Sets. The table in this appendix shows a partial list.

Name	Function	Beginning RD	Ordered Set	8 Bit Hex
C1	Configuration - flip disparity	Positive	K28.5 D21.5 config_reg[7:0] config_reg[15:8]	
C2	Configuration - sustain disparity	Negative	K28.5 D2.2 config_reg	
I1	Idle - correct disparity	Positive	K28.5 D5.6	0xBC 0xC5
I2	Idle - preserve disparity	Negative	K28.5 D16.2	0xBC 0x50
R	Carrier extend	Negative Positive	K23.7	0xF7
S	Start of packet	Negative	K27.7	0xFB
T	End of packet	Negative Positive	K29.7	0xFD
V	Error propagation	Negative Positive	K30.7	0xFE



# Appendix E

## Primitive Encoding

The table in this appendix (Table 2) describes a set of the K28.5-based Primitive encoding whose 40-bit values (after 8b10b encoding with either starting running disparity) have a Hamming distance (that is, the number of bits different in two patterns) of at least 8. Unassigned encodings might be used by future versions of this standard (Reprinted from American National Standard T10/1562-D).

**Table 2: Primitives with Hamming Distance of 8**

1st	2nd	3rd	4th	Assignment
K28.5	D01.3	D01.3	D01.3	ALIGN (2)
K28.5	D01.4	D01.4	D01.4	ACK
K28.5	D01.4	D02.0	D31.4	RRDY (RESERVED 0)
K28.5	D01.4	D04.7	D24.0	NAK (RESERVED 1)
K28.5	D01.4	D07.3	D30.0	CREDIT_BLOCKED
K28.5	D01.4	D16.7	D07.3	NAK (RESERVED 2)
K28.5	D01.4	D24.0	D16.7	RRDY (NORMAL)
K28.5	D01.4	D27.4	D04.7	NAK (CRC ERROR)
K28.5	D01.4	D30.0	D02.0	RRDY (RESERVED 1)
K28.5	D01.4	D31.4	D29.7	NAK (RESERVED 0)

**Table 2: Primitives with Hamming Distance of 8**

1st	2nd	3rd	4th	Assignment
K28.5	D02.0	D01.4	D29.7	ERROR
K28.5	D02.0	D02.0	D02.0	HARD_RESET
K28.5	D02.0	D04.7	D01.4	CLOSE (RESERVED 1)
K28.5	D02.0	D07.3	D04.7	CLOSE (CLEAR AFFILIATION)
K28.5	D02.0	D16.7	D31.4	
K28.5	D02.0	D24.0	D07.3	BREAK
K28.5	D02.0	D29.7	D16.7	
K28.5	D02.0	D30.0	D27.4	CLOSE (NORMAL)
K28.5	D02.0	D31.4	D30.0	CLOSE (RESERVED 0)
K28.5	D04.7	D01.4	D24.0	BROADCAST (RESERVED 1)
K28.5	D04.7	D02.0	D01.4	BROADCAST (CHANGE)
K28.5	D04.7	D04.7	D04.7	BROADCAST (RESERVED 2)
K28.5	D04.7	D07.3	D29.7	BROADCAST (RESERVED 0)
K28.5	D04.7	D16.7	D02.0	BROADCAST (RESERVED 3)
K28.5	D04.7	D24.0	D31.4	BROADCAST (RESERVED CHANGE 0)
K28.5	D04.7	D27.4	D07.3	BROADCAST (RESERVED CHANGE 1)
K28.5	D04.7	D29.7	D30.0	BROADCAST (RESERVED 4)
K28.5	D04.7	D31.4	D27.4	
K28.5	D07.0	D07.0	D07.0	ALIGN (1)
K28.5	D07.3	D01.4	D31.4	
K28.5	D07.3	D02.0	D04.7	
K28.5	D07.3	D04.7	D30.0	
K28.5	D07.3	D07.3	D07.3	
K28.5	D07.3	D24.0	D29.7	
K28.5	D07.3	D27.4	D16.7	
K28.5	D07.3	D29.7	D27.4	
K28.5	D07.3	D30.0	D24.0	
K28.5	D07.3	D31.4	D02.0	
K28.5	D10.2	D10.2	D27.3	ALIGN (0)
K28.5	D16.7	D01.4	D02.0	
K28.5	D16.7	D02.0	D07.3	
K28.5	D16.7	D04.7	D31.4	

**Table 2: Primitives with Hamming Distance of 8**

1st	2nd	3rd	4th	Assignment
K28.5	D16.7	D16.7	D16.7	OPEN_ACCEPT
K28.5	D16.7	D24.0	D27.4	
K28.5	D16.7	D27.4	D30.0	
K28.5	D16.7	D29.7	D24.0	
K28.5	D16.7	D30.0	D04.7	
K28.5	D16.7	D31.4	D01.4	
K28.5	D24.0	D01.4	D16.7	
K28.5	D24.0	D02.0	D29.7	
K28.5	D24.0	D04.7	D07.3	SOF
K28.5	D24.0	D07.3	D31.4	EOAF
K28.5	D24.0	D16.7	D27.4	EOF
K28.5	D24.0	D24.0	D24.0	
K28.5	D24.0	D27.4	D02.0	
K28.5	D24.0	D29.7	D04.7	
K28.5	D24.0	D30.0	D01.4	SOAF
K28.5	D27.3	D27.3	D27.3	ALIGN (3)
K28.5	D27.4	D01.4	D07.3	AIP (RESERVED WAITING ON PARTIAL)
K28.5	D27.4	D04.7	D02.0	
K28.5	D27.4	D07.3	D24.0	AIP (WAITING ON CONNECTION)
K28.5	D27.4	D16.7	D30.0	AIP (RESERVED 1)
K28.5	D27.4	D24.0	D04.7	AIP (WAITING ON PARTIAL)
K28.5	D27.4	D27.4	D27.4	AIP (NORMAL)
K28.5	D27.4	D29.7	D01.4	AIP (RESERVED 2)
K28.5	D27.4	D30.0	D29.7	AIP (WAITING ON DEVICE)
K28.5	D27.4	D31.4	D16.7	AIP (RESERVED 0)
K28.5	D29.7	D02.0	D30.0	OPEN_REJECT (RESERVED CONTINUE 0)
K28.5	D29.7	D04.7	D27.4	OPEN_REJECT (RESERVED STOP 1)
K28.5	D29.7	D07.3	D16.7	OPEN_REJECT (RESERVED INITIALIZE 1)
K28.5	D29.7	D16.7	D04.7	OPEN_REJECT (PATHWAY BLOCKED)
K28.5	D29.7	D24.0	D01.4	OPEN_REJECT (RESERVED CONTINUE 1)
K28.5	D29.7	D27.4	D24.0	OPEN_REJECT (RETRY)
K28.5	D29.7	D29.7	D29.7	OPEN_REJECT (NO DESTINATION)

**Table 2: Primitives with Hamming Distance of 8**

1st	2nd	3rd	4th	Assignment
K28.5	D29.7	D30.0	D31.4	OPEN_REJECT (RESERVED INITIALIZE 0)
K28.5	D29.7	D31.4	D07.3	OPEN_REJECT (RESERVED STOP 0)
K28.5	D30.0	D01.4	D04.7	DONE (ACK/NAK TIMEOUT)
K28.5	D30.0	D02.0	D16.7	
K28.5	D30.0	D07.3	D27.4	DONE (CREDIT TIMEOUT)
K28.5	D30.0	D16.7	D01.4	DONE (RESERVED 0)
K28.5	D30.0	D24.0	D02.0	
K28.5	D30.0	D27.4	D29.7	DONE (RESERVED TIMEOUT 0)
K28.5	D30.0	D29.7	D31.4	DONE (RESERVED 1)
K28.5	D30.0	D30.0	D30.0	DONE (NORMAL)
K28.5	D30.0	D31.4	D24.0	DONE (RESERVED TIMEOUT 1)
K28.5	D31.3	D01.3	D07.0	NOTIFY (RESERVED 1)
K28.5	D31.3	D07.0	D01.3	NOTIFY (RESERVED 0)
K28.5	D31.3	D10.2	D10.2	NOTIFY (RESERVED 2)
K28.5	D31.3	D31.3	D31.3	NOTIFY (ENABLE SPINUP)
K28.5	D31.4	D01.4	D30.0	OPEN_REJECT (RESERVED ABANDON 3)
K28.5	D31.4	D02.0	D27.4	OPEN_REJECT (RESERVED ABANDON 0)
K28.5	D31.4	D04.7	D29.7	OPEN_REJECT (CONNECTION RATE NOT SUPPORTED)
K28.5	D31.4	D07.3	D02.0	OPEN_REJECT (RESERVED ABANDON 2)
K28.5	D31.4	D16.7	D24.0	OPEN_REJECT (WRONG DESTINATION)
K28.5	D31.4	D27.4	D01.4	OPEN_REJECT (STP RESOURCES BUSY)
K28.5	D31.4	D29.7	D07.3	OPEN_REJECT (PROTOCOL NOT SUPPORTED)
K28.5	D31.4	D30.0	D16.7	OPEN_REJECT (RESERVED ABANDON 1)
K28.5	D31.4	D31.4	D31.4	OPEN_REJECT (BAD DESTINATION)

# ***Index***

**Numbers**

## 10GigE

- creating Jammer configurations, 162
- decode switches menu, 179, 344, 352, 368
- Jam definition, 184
- Jammer configuration window, 164
- pause, 171
- repeat mode, 170
- rollback option, 170
- test suite toolbar, 165
- timeout option, 170, 340, 362
- trigger button, 168

## 16G FC

- configuration window, 203
- creating Jammer configurations, 202
- decode switches menu, 220
- FEC, 24
- Jam definition, 227
- Jammer configuration window, 204
- pause, 211
- repeat mode, 210
- rollback option, 210
- test suite toolbar, 205
- timeout option, 210
- trigger button, 208

## 8-bit/10-bit mapping, 375

**A**

- All Jam Modes, 280
- APLAs, 393
- Apply Global Bit Error Jam, 84, 109, 139, 156, 193, 237
- Apply Global Match Mask Jam, 83, 108, 193, 237
- Apply Global Replace Jam, 138, 154
- arbitrated loop physical addresses, 393
- arm button, 71, 94, 120, 168, 208, 256
  - Delay Emulator, 339, 361
- arm condition, 173, 213, 347, 363
- arm condition, PCIe, 260
- arm conditions, 73, 99, 125, 143
- arm name, 26
- arm status, 26
- arm-trigger timeout, 26

**B**

- Binary Editor, 74, 100, 129, 146, 174, 179, 197, 214, 220, 261, 263, 267, 269, 273, 279, 344, 348, 352, 365, 367
- bit errors, 80, 105, 133, 150, 190, 234

**C**

- Carrier Extend(s), 106, 191, 235
- Classify button
  - Delay Emulator, 339
- clock rate
  - Delay Emulator, 310
  - Jammer, 10, 23, 25
- Code Violation, 138, 155
- Condition button, 71
- config type (Delay Emulator), 310
- configuration
  - 10GigE Jammer, 164
  - 16G FC Jammer, 204
  - Delay Emulator, 336
  - FC Jammer, 66
  - Gigabit Ethernet Jammer, 88
  - Jammer, 68, 91
  - PCIe Jammer, 252
  - reorder, 359
  - SAS/SATA Jammer, 114
- configuration file menu, PCIe, 254
- configuration manager
  - Jammer, 15, 301
- configuration window
  - Jammer, 68, 91
  - SAS Jammer, 116
- configuring tests, 67, 90, 115, 163, 203, 251, 335
  - reorder, 357
- control character conditions, 176, 182, 216, 222
- control character, jamming, 185, 228
- CRC
  - recalculate checksum, 198
- CRC definitions, 281
- CRC options, 81, 106, 135, 139, 152, 156, 191, 235
- Create Error Jam, 138, 155, 274, 280
- creating 10GigE Jammer configurations, 162
- creating 16G FC Jammer configurations, 202
- creating Delay Emulator configurations, 334, 356
- creating FC Jammer configurations, 66
- creating Gigabit Ethernet Jammer configurations, 88
- creating PCIe Jammer configurations, 250
- creating SAS/SATA Jammer configurations, 114

**D**

- decode switches
  - FCoE interpretations, 180
  - FC-SW accept interpretation, 181, 221, 345, 353, 369
- Delay capabilities, 297

Delay Configuration window, 335, 336

#### Delay Emulator

- cabling, 298
- capabilities, 296
- configuration files, 329
- configuration window, 336, 359
- creating configurations, 334, 356
- delay graph, 318
- parameters, 309
- parameters status table, 307
- ports manager, 313
- real time tab, 317
- running test suite, 331
- Test Suite toolbar, 336
- triggering capabilities, 297

Delimiters/CRC Tab, 105, 190, 234

digital retiming device, 296

Disable LRC, 238

Disparity Error, 138, 155, 274, 280, 281

Domains and External Triggering, 291

## E

edit Delay Emulator configuration, 334, 356

edit Jammer configuration

- 10GigE, 162
- 16G FC, 202
- FC, 66
- Gigabit Ethernet, 88
- PCIe, 250
- SAS/SATA, 114

editing the tests stack, 69

Embedded Protocol(s) tab, 109, 194, 238

## F

FC, GE Configuration window, 67, 90, 163

FCoE interpretations, 180, 198, 241

FCoE payload, 195

FC-SW accept interpretation, 181, 221, 345, 353, 369

#### Fibre Channel

- edit Jammer configuration, 66
- pause, 73

Fibre Channel arbitrated loop physical address, 393

Fibre Channel Ordered Sets, 373

file menu, PCIe, 254

frame condition, save, 75, 101, 129, 175, 181, 215, 221, 346, 349, 354, 365, 369

frame conditions, 74, 100, 128, 173, 179, 213, 220, 344, 347, 352, 364, 367  
SATA, 146

frame jamming, 11

frame modification, 289

frame truncation, 289

full frame Jam support, 272

## G

Gen 1/2 tab, PCIe, 276, 281

Gen 3 tab, PCIe, 277, 282

#### Gigabit Ethernet

- edit Jammer configuration, 88

#### Gigabit Ethernet

- Ordered Sets, 395
- pause, 97
- payload, 195
- Repeat Mode, 96
- Rollback option, 96
- Test Suite toolbar, 92
- timeout option, 96
- Trigger button, 94

global bit errors, 80, 105, 133, 150, 190, 234

Global Match/Mask Option, 79, 104, 189, 233

Global Option, 132, 149

Global Tab, 79, 104, 132, 149, 189, 233

## H

hashed address, 118

Header/Payload tab, 82, 107, 135, 152, 191, 235, 272

## I

Inject Error, 274, 280

Inject Errors, 281

Insert Code Violation Jam, 83

Invert Jam, 83, 108, 138, 155, 193, 237, 275

IP, 110, 195

IP checksum, 110, 195

IP header IHL field, 111, 196

IP header IP Protocol field value, 110, 195

IP header Total Length field, 110, 195

IP payload, 195

## J

Jam Behavior, 131, 186, 231

Jam button, 77, 103, 140, 158, 184, 185, 227, 228, 229, 243, 283

Jam Definition, 130

- FC, 77
- Gigabit Ethernet, 103
- SATA, 148

## Jam definition

- 10GigE, 184
- 16G FC, 227
- PCIe, 272

## Jam name, 26

## Jam Status, 23

## Jammer

- capabilities, 10
- displaying and hiding parameters, 59, 328
- using the log manager, 50, 320
- using the Window menu, 55, 324

## Jammer blade LEDs, 24

## Jammer capture, 286

## Jammer Configuration window, 68, 91, 164, 204, 252

## Jammer Tests Stack, 68, 91, 116, 164, 204, 253, 336, 359

## Jamming a control character, 185, 228

## Jamming a Primitive Sequence, 140, 158

## Jamming an Ordered Set, 77, 103, 184, 227, 243, 283

## Jamming capabilities, 11, 12

**L**

## LCRC modification, 277

## LCRC modification, PCIe, 277, 278

## LEDs

- Jammer blade, 24

## line rates, 10

## Link State (Delay Emulator), 309

## logging

- Jammer, 50, 320

## loop, 69

**M**

## MAC layer, 11, 296

## match/mask, global option, 79, 104, 189, 233

## mode, 70, 93, 119, 167, 207, 255

- Delay Emulator, 339, 361

## Modified Frame, Replace Frame with, 79, 104, 132, 149, 186, 231

**N**

## New Payload Size, 195

## number of Dwords, 272

**O**

## Ordered Set

- jamming, 77, 103, 184, 227, 243, 283

## Ordered Set conditions, 75, 102, 175, 182, 184, 215, 216, 217, 222, 223, 227, 240, 265, 271

## Ordered Sets

- Fibre Channel, 373
- Gigabit Ethernet, 395

## Ordered Sets, jamming, 12

## output voltage, 47

**P**

## parameters status context menu

- Jammer, 27, 311

## parameters status table

- Jammer, 21, 307

## pass through, 8, 11

## Pass Through Jam, 83, 108, 138, 155, 193, 237, 274, 280

## pause, 73, 97, 123, 171, 211

## pause, PCIe, 258

## Payload Size, 136, 153

## Payload Words Tab, 135, 152

## PCI trigger condition, 266

- DLLP, 269
- ordered set, 271
- TLP, 267

## PCIe

- creating Jammer configurations, 250
- Jammer configuration window, 252
- pause, 258
- rollback option, 257
- test suite toolbar, 253
- timeout option, 258
- trigger button, 256

## PCIe arm condition, 260

- DLLP, 263
- ordered set, 265
- TLP, 261

## PCIe configuration window, 251

## PCIe Jam definition, 272

- DLLP, 278
- ordered set, 283
- TLP, 272

## PCIe link speed, 24

## PCIe link width, 24

## PCIe timeout button, 258

## ports manager

- Jammer, 45

## Primitive Sequence

- jamming, 140, 158
- Redundant, 126, 143
- Triple, 126, 143

## primitive sequence

- continued, 160

- repeated, 160
- single, 159
- protocol indicator
  - Jammer, 23
- R**
- Recalculate Checksum, 109, 194
- recalculate CRC checksum, 198
- Recalculate IP checksum for valid IP embedded frames, 109, 194
- Recalculate LRC, 238
- Recalculate TCP checksum for valid TCP embedded frames, 110, 195
- reorder
  - Delay Emulator configuration window, 359
  - Test Suite toolbar, 359
- Reorder capabilities, 297
- reorder configuration window, 357
- reorder definition, 370
- Repeat button, 257
- Repeat Mode, 96, 123
- repeat mode, 170, 210
- Replace 10b Jam, 138, 155
- Replace 66 bit Jam, 193
- Replace 8b Jam, 83, 109, 137, 154, 193, 237
- Replace Frame with ARB(ff), 86
- Replace Frame with Idles, 86, 112, 140, 157, 196, 242
- Replace Frame with Modified Frame, 79, 104, 132, 149, 186, 231
- Replace Frame with Modified Traffic - Fibre Channel, 289
- Replace Frame with Truncated Frame, 86, 110, 139, 156, 195, 241
- Replace Jam, 155, 275, 280
- Replace Jam with CRC, 83, 138, 156
- Replace LRC, 238
- Replace w/ Modified Traffic, 289
- replacing a frame with multiple frames, 290
- replacing a frame with Ordered Sets, 290
- reverse jam, 71, 94, 120, 168, 208
- Rollback option, 96, 122
- rollback option, 170, 210
- rollback, PCIe, 257
- frame condition, save, 129
- frame conditions, 128
- Hashed Address, 118
- Jam Definition, 130
- Template Library, 128
- trigger conditions, 125
- User Library, 129, 147
- SAS Jammer Configuration window, 116
- SAS Trigger condition, 130
- SAS/SATA
  - pause, 123
  - Repeat Mode, 123
  - Rollback option, 122
  - Test Suite toolbar, 117
  - Test Suite Tools, 116
  - timeout option, 122
  - Trigger button, 120
- SAS/SATA Configuration window, 115
- SAS/SATA edit Jammer configuration, 114
- SATA, 143
  - frame condition, save, 147
  - frame conditions, 146
  - Jam Definition, 148
  - primitive sequence, Jamming, 158
  - Template Library, 146
  - trigger conditions, 143
- Set Bits To 0's Jam, 275
- Set Bits To 0s Jam, 84, 109, 139, 156, 193, 237
- Set Bits To 1's Jam, 275
- Set Bits To 1s Jam, 84, 109, 139, 156, 193, 237
- Setting Up the Xgig Jammer and Xgig Analyzer to Capture a Jam, 286
- Settings category
  - Jammer, 25, 310
- Signal LED A
  - Jammer, 24
- Signal LED B
  - Jammer, 24
- SOF/CRC/EOF Tab, 80, 134, 151
- SOP modification, PCIe, 276
- SOP/SFP/EOP, 106, 191, 235
- State category
  - Jammer, 23
- State category (Delay Emulator), 309
- Switch to button, 194, 238
- T**
- TCP, 110, 195
- TCP header Data Offset field, 111, 196
- S**
- SAS, 125
  - Binary Editor, 129

TCP payload, 195  
Template Library, 74, 100, 128, 146, 174, 179, 214, 220, 261, 263, 267, 269, 344, 348, 352, 365, 367  
Test Repeat Count  
    Delay Emulator, 309  
Test Suite Tools, SAS/SATA, 116  
Test Timeout, 26  
    Delay Emulator, 309  
Test Timeout Mode  
    Delay Emulator, 309  
testing strategies, 288  
Testing Strategies for the Xgig Jammer, 288  
tests stack, 68, 91, 164, 204, 253, 336, 359  
tests stack, SAS/SATA, 116  
Time Since Test Started  
    Delay Emulator, 309  
timeout, 96, 122, 170, 210, 340, 362  
Timeout button, 72, 96, 122, 170, 210, 341, 362  
timeout, PCIe, 258  
TLP full frame Jam support, 272  
toolbar  
    Delay Emulator, 336  
toolbar, 10GigE, 165  
toolbar, 16G FC, 205  
toolbar, Gigabit Ethernet, 92  
toolbar, PCIe, 253  
toolbar, reorder, 359  
toolbar, SAS/SATA, 117  
traffic patterns, 10  
Trigger button, 71, 94, 120  
trigger button, 168, 208, 256  
    Delay Emulator, 339, 361  
trigger condition, 266  
Trigger conditions, 177, 218, 342, 350, 366  
trigger conditions, 73, 99, 125, 143  
Trigger Definition, 77, 103, 130, 184, 227, 272  
Trigger Domain A/B, 73  
Trigger from Domain A/B, 73  
Trigger name, 26  
Trigger occurred, 26  
Trigger timed out, 26  
Triggering capabilities, 11  
Tuning and Equalization, 39

## U

User Library, 75, 101, 129, 147, 175, 181, 199, 215, 221, 241, 262, 264, 268, 270, 346, 349, 354, 365, 369





**October 2015**  
**Version 8.1**  
**English**

**Viavi Solutions**

<b>North America:</b>	<b>1.844.GO VIAVI / 1.844.468.4284</b>
<b>Latin America</b>	<b>+52 55 5543 6644</b>
<b>EMEA</b>	<b>+49 7121 862273</b>
<b>APAC</b>	<b>+1 512 201 6534</b>
<b>All Other Regions:</b>	<b><a href="http://viavisolutions.com/contacts">viavisolutions.com/contacts</a></b>
<b>email</b>	<b><a href="mailto:customer.care@viavisolutions.com">customer.care@viavisolutions.com</a></b>